



Addressable Fire Alarm Control Panel

User's Manual








Foreword

General

This manual introduces the functions and operations of the Addressable Fire Alarm Control Panel (hereinafter referred to as "the Device").

Safety Instructions

The following categorized signal words with defined meaning might appear in the manual.

Signal Words	Meaning
 DANGER	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
 CAUTION	Indicates a potential risk which, if not avoided, could result in property damage, data loss, lower performance, or unpredictable result.
 TIPS	Provides methods to help you solve a problem or save you time.
 NOTE	Provides additional information as the emphasis and supplement to the text.

Revision History

Version	Revision Content	Release Time
V1.0.0	First release.	Februray 2023

About the Manual

- The manual is for reference only. If there is inconsistency between the manual and the actual product, the actual product shall prevail.
- We are not liable for any loss caused by the operations that do not comply with the manual.
- The manual would be updated according to the latest laws and regulations of related jurisdictions. For detailed information, refer to the paper manual, CD-ROM, QR code or our official website. If there is inconsistency between paper manual and the electronic version, the electronic version shall prevail.
- All the designs and software are subject to change without prior written notice. The product updates might cause some differences between the actual product and the manual. Please contact the customer service for the latest program and supplementary documentation.
- There still might be deviation in technical data, functions and operations description, or errors

in print. If there is any doubt or dispute, we reserve the right of final explanation.

- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and the company names in the manual are the properties of their respective owners.
- Please visit our website, contact the supplier or customer service if there is any problem occurring when using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

Important Safeguards and Warnings

This section introduces content covering the proper handling of the device, hazard prevention, and prevention of property damage. Read carefully before using the device, comply with the guidelines when using it, and keep the manual safe for future reference.

Operation Requirements



- Make sure that the power supply of the device works properly before use.
- Transport, use and store the device under allowed humidity and temperature conditions.
- Prevent liquids from splashing or dripping on the device. Make sure that there are no objects filled with liquid on top of the device to avoid liquids flowing into it.
- Do not disassemble the device.

Installation Requirements



WARNING

- Strictly abide by local electrical safety standards, and make sure that the voltage in the area is steady and conforms to the power requirements of the device.
- Do not connect the device to more than one power supply. Otherwise, the device might become damaged.



- Observe all safety procedures and wear required protective equipment provided for your use while working at heights.
- Do not expose the device to direct sunlight or heat sources.
- Do not install the device in humid, dusty or smoky places.
- Install the device in a well-ventilated place, and do not block the ventilator of the device.

Maintenance Requirements



- Use the accessories suggested by the manufacturer. Installation and maintenance must be performed by qualified professionals.
- Clean the device with a soft dry cloth or a clean soft cloth dipped in neutral detergent.
- Contact your local dealer or the service center nearest to you if the device needs internal configuration or maintenance. Do not dismantle or modify the device without a qualified professional present to avoid the risk of danger or damage to the device. We will assume no responsibility for any problems caused by unauthorized modifications or maintenance.

Table of Contents

Foreword.....	I
Important Safeguards and Warnings.....	III
1. Product Information.....	1
1.1 Introduction.....	1
1.2 Features.....	1
2. Technical Information	2
3. Structure	3
3.1 Dimensions	3
3.2 Composition.....	3
3.3 Front Panel	4
3.4 Manual Module Panel	6
3.5 Device Linkage Panel	6
4. Device Installation and Debug	8
4.1 Packing List.....	8
4.2 Inspection.....	8
4.3 Installation.....	8
4.3.1 Principle.....	8
4.3.2 Wiring.....	9
4.3.3 Battery.....	9
4.4 System Debugging	10
4.4.1 Preparation.....	10
4.4.2 Device Register	11
4.4.3 Registration Check.....	11
4.4.4 Define.....	11
4.4.5 Simulation Experiment.....	11
5. Operation	12
5.1 Menu	12
5.2 Querying	13
5.2.1 Device.....	13
5.2.2 Log.....	16
5.2.3 Linkage	19
5.2.4 FACP Info.....	20
5.3 Operation.....	21
5.3.1 Active & Stop	21
5.3.2 Disable	22
5.3.3 Log Print	23
5.3.4 System Test.....	23
5.4 Settings.....	23
5.4.1 Password	24
5.4.2 Display.....	25
5.4.3 Time	26

5.4.4	Print.....	26
5.4.5	Project Information Settings.....	27
5.4.6	Language	27
5.5	Networking.....	27
5.5.1	Controller Network.....	27
5.5.2	IP Network	27
5.6	Linkage.....	28
5.6.1	New Linkage Relation	28
5.6.2	Modify Linkage Relation.....	30
5.6.3	Delete Linkage Relation	30
5.7	Debugging.....	30
5.7.1	System Mode.....	31
5.7.2	User Login.....	32
5.7.3	Register Device	33
5.7.4	Register Network.....	34
5.7.5	Define.....	34
5.7.6	Configuration Synchronize.....	37
5.7.7	Super Tool	38
6.	FAQ.....	40
7.	Maintenance	42
	Appendix 1 Device Type Table.....	43
	Appendix 2 Cybersecurity Recommendations	45

1.Product Information

1.1 Introduction

Addressable Fire Alarm Control Panel is designed to provide early warning fire detection, display fire information and inform people to evacuate. With two-wire and polarity-free technology, it connects with other mated products to construct a fire alarm control system. This system offers flexibility in both design and operation to meet the demands of various projects.

It is suitable for residential and industrial buildings such as hotels, shopping malls, hospitals, office buildings, schools, banks, libraries, factories, and warehouses.

1.2 Features

- Two-wire and polarity-free: The system loop line adopts two-wire and polarity-free communication power supply technology without external power supply. Strong anti-interference, convenient wiring, improved system reliability and stability, easy construction and installation, reduced project cost, and convenient maintenance.
- Intuitive display: 480 × 272 4.3" LCD screen provides a highly intuitive interface, allowing the user to fully set up the system without the need of any external tool.
- Ultra-long history record: Save historical events for a long time that can be inquired and printed in various ways such as time and type.
- Intelligent power supply: With automatic switching between the main and backup power and the charging and discharging functions, it ensures the stable power supply of the system to the greatest extent.
- Flexible linkage logic: The logic programming is flexible, which can realize a variety of customized linkage requirements, simple and convenient programming, and reduced debugging workload.
- Protection design: Short circuit, open circuit and overcurrent protection to ensure stable operation.


2. Technical Information

Parameter	Introduction
Working Voltage	DC 12V~48V
System Capacity	400 field devices
Main Power Supply	AC 90-240V/50Hz, 60Hz
Backup Power Supply	2 lead-acid batteries (12V/5Ah each)
Display	480 × 272 4.3" LCD screen
Printer	Micro thermal printer
Dimensions (with base)	333.0 mm × 115.0 mm × 480.0 mm (13.11" × 4.53" × 18.90")
Operating Temperature	-10°C to +40°C (+14°F to +104°F)
Operating Humidity	≤ 95% RH (no condensation)
Protection	IP30

3. Structure

3.1 Dimensions

Figure 3-1 Dimensions (mm[inch])



3.2 Composition

- Single loop: 200 devices, a total of 2 loops
- Manual module panel: 16 buttons to start field devices
- Direct linkage panel: 14 buttons to control fire alarm devices
- 1 Alarm Output: DC24V
- 1 Fault Output: DC24V
- RS-485: Enable networking with control module
- CANH, CANL: Enable communication with other control panel
- DC24V: DC24V/300mA outputs to field devices

3.3 Front Panel

Figure 3-2 Front panel




Table 3-1 Front panel introduction

No.	Introduction
1	<ul style="list-style-type: none"> Send message: Remain lit when control panel sends message. Receive message: Remain lit when control panel receives message. Maintenance: Remain lit when control panel is in maintenance mode. Communication: Remain lit when control panel connects to other panels. Response: Remain lit after the key is pressed. Test: Remain lit when control panel is in self-test mode.
2	Display operation screen.


No.	Introduction
3	<ul style="list-style-type: none"> • ↑, ↓, ←, →: Turn pages or navigate between the options on the screen. • Enter: Enter the selected menu and confirm operations. • Numerical and alphabetic keys: Enter numbers, letters and marks. • Fire Message: Search fire alarm information. • Active Device: Enter active/stop menu. • Disable: Disable/enable device. • Tab: Change the display among different windows when there are multiple messages. • Menu: Enter main menu. • Esc: Exit from the current menu or return to the previous menu. • Delete: Delete the input. • +, x, *, #: Edit linkage relation.
4	Manual module panel.
5	Device linkage panel.
6	Print various event information such as fire alarm, fault, startup and feedback. The information content includes event type, device information and occurrence time. The paper is installed by default. If the printing paper is exhausted, you can purchase and install thermal printing paper. For details, see "7 Maintenance".
7	Alarm sound outlet.
8	<ul style="list-style-type: none"> • Active linkage: Start linkage signal in accordance with the reset logic. • ACK: Confirm the received fault and alarm information, and identify the confirmed information. • Test: Test the LCD, speaker and all LEDs. • Mute: Silence the speaker of the panel. • Reset: Reset the panel. • Check: Check the relevant information of the panel.

No.	Introduction
9	<ul style="list-style-type: none"> • Main power: Remain lit for AC 90V~240V power on. • Battery power: Remain lit for backup battery on. • Fire alarm: Remain lit after receiving fire information. The LED turns off when the panel is reset. • Fault: Remain lit when a trouble condition is detected. The LED turns off when the panel is reset or the fault is addressed. • Mute: Remain lit when the speaker is silenced. If there is new fire alarm, the speaker will be re-activated and this LED will turn off. • System fault: Remain lit when the memory of the panel is in trouble or system program cannot be executed. • Active: Remain lit when the panel sends active command. The LED turns off if no feedback signal is received within 10s of sending the start command. • Delay: Remain lit when there is a sounder or an output in delay mode. The LED turns off when the delay time expires. • Supervisory: Remain lit when there is supervisory signal. The LED turns off when the panel is reset. • Disable: Remain lit when there is a connected device or an output or the delay mode is disabled. • Manual: Remain lit when the panel is in manual state. • Auto: Remain lit when the panel is in auto state.

3.4 Manual Module Panel

Control field devices. Each group controls 1 button and 2 indicator lights.

Figure 3-3 Manual module panel




3.5 Device Linkage Panel

The device linkage panel is used to control fire pumps, smoke exhausters, blowers, etc. The address of the device linkage panel can be adjusted according to the switch, and the address can be set from 1 to 14. The device linkage panel can directly control fire equipment when the main control system is paralyzed.

Each group of outputs of the device linkage panel has the function of open circuit and short circuit fault detection, which can maximize the reliability of the connection between the device linkage panel and fire equipment. Each device linkage panel has a total of 7 control groups. Each control group has 2 buttons and 3 indicator lights. The device linkage panel realizes direct control of field devices through input and output modules.

Figure 3-4 Device linkage panel



4.Device Installation and Debug

4.1 Packing List

Check the package according to the following checklist. If you find anything damaged or lost, contact customer service.



Keep accessories properly for future use.

Table 4-1 Checklist

Item	Quantity
Addressable fire alarm control panel	1
User's manual	1
Key	2
Key to the FACP	2
Backup insurance	2
Button label	3
Printer paper	1

4.2 Inspection

- Do not power the system until the installation is completed.
- The Addressable Fire Alarm Control Panel receives main power from 90V-240V supply. The positive and negative poles of the backup battery are correctly connected.
- Turn on the backup battery first and then the main power (turn off the main power first and then the backup battery).
- The voltage of the manual module panel and device linkage panel terminals should be about 27V.
- Carry out self-test to check whether all parts are successfully inspected.
- The defective detectors should be dealt with according to "FAQ" and "Maintenance", and then test again. If it still fails to pass the test, it should be returned to the factory for repair.

4.3 Installation

4.3.1 Principle

- The FACP adopts wall-mounted installation. It should be installed in the fire control room or the place where people are on duty. Keep away from the environment with electromagnetic interference.

- The design should be strictly implemented in accordance with relevant provisions and regulations, and connect the device correctly according to the construction drawing.

4.3.2 Wiring


Before connecting the signal line and direct control line to the FACP, the insulation test should be carried out.

The insulation resistance between loops is more than 10 KΩ, and insulation resistance between loops and ground is more than 10 MΩ.



Do not measure the line resistance of the installed device by a megger.

Figure 4-1 Wiring terminal



Bus terminal

BUS1, BUS2: Connect detector, module, sounder strobe, etc.


Device linkage panel terminal

DBn (n=1-7) : Control fire pumps, smoke exhausters, blowers, etc.

Other terminal

- GZ_P, GND: Fault output, DC24V.
- HJ_P, GND: Fire alarm output, DC24V.
- 28V, GND: Power output, DC28V.
- CANH, CANL: Connect to other FACP.
- 232TX, 232RX, GND: Communication port between control panel and CRT.
- 485A1, 485B1, 485A2, 485B2: RS-485 networking port for communication among control panels.

Main electrical terminal

L、N、: AC 90V~240V power supply.

4.3.3 Battery




Connect the final battery after completing installation.

Step 1 Connect fuse.

Step 2 Connect the red and black power wires reserved in the wire slot to the positive and negative terminals of the battery respectively.

Figure 4-2 Battery



4.4 System Debugging

4.4.1 Preparation

After connection and verification, the system may be switched on for debugging, mainly including logging and testing of detector and module, and setup of linkage relation.

4.4.2 Device Register

Select **Debugging > Register Device** to register the field devices. For the specific operation method, please see 5.7.3 Register Device.

4.4.3 Registration Check

After the device is successfully registered, check the login result and network state. For details of the field device query, please see 5.2.1 Device.

4.4.4 Define

After ensuring that all the devices are registered and online, define the field device, including the user code, description information and device parameters, and set the manual module panel and device linkage panel. For details, please see 5.7.5 Define.

4.4.5 Simulation Experiment

Simulate alarm test. If Addressable Smoke Detector, Addressable Manual Call Point and Addressable Sounder Strobe work normally, test the panel function by pressing Addressable Manual Call Point or simulating fire alarm by Addressable Smoke Detector. The fire light is lit and alarm is triggered, representing that the fire function is normal. After completing testing start/stop function, and defining manual module panel and device linkage panel, the manual module panel and device linkage panel button can be used to fast start and stop field devices.

5.Operation

This chapter introduces the operations included in the main menu.

It consists of many menus for management and programming operations. They are as below:

- Querying
- Operation
- Settings
- Networking
- Linkage
- Debugging

5.1 Menu

The main menu of FACP includes Querying, Operation, Settings, Networking, Linkage and Debugging.

- When there is neither fire alarm nor other event information, the interface shows that the system is working normally.

When the system is in normal state, press **Menu** to enter the main menu interface.

Figure 5-1 Menu




Figure 5-2 Main menu



- When there is alarm, the interface displays alarm information.
 1. Press **↑** and **↓** to select the event.
 2. Press **←** and **→** to see brief information of all events.
 3. Press **Enter** to see information in details.

5.2 Querying

Press **Menu** to enter the **Querying** interface, including Device, Log, Linkage and FACP information.


Figure 5-3 Querying



5.2.1 Device

Select **Querying** > **Device**, to see the information of all devices in details. Support the query by loop, by type and by address. Query information includes S/N, user code, LA code, device information and parameters.


Figure 5-4 Device



5.2.1.1 Query by Loop

Step 1 Select **Querying > Device > Query by Loop**.

Figure 5-5 Query by loop




Step 2 Enter **Loop Number**, and press **Enter**.

See the brief information of all devices in this loop.

Step 3 Press **Enter** again to see the detailed information.

Figure 5-6 Devices information



Devices Information	
Device ID:	010010881300071247793500
Device Type:	In/OutputMod
LA Code:	001
User Code:	0010102401
Device Info:	Loop 01 No. 001
Device Param:	NO No input check No output check
Panel key:	Not define panel key
Device Stat. :	Offline Reg. Fault


5.2.1.2 Query by Type

Step 1 Select **Querying > Device > Query by Type**.

Step 2 Enter **Type Number**, and press **Enter**.

See the brief information of all devices with same type.

Figure 5-7 Query by type



Enter : Char. >> Query by Type <<

Please Enter Type Number:

Smoke Detector: 01	Heat Detector: 02	MCP: 03
Fire Hydrant Button: 04	Siren: 05	Repeater: 06
Input Module: 07	Output Module: 08	Other: Follow User Manual

Access Level (1)

Step 3 Press **↑** or **↓** to select target device, and press **Enter**.

See detailed information of this target device.


5.2.1.3 Query by Address

Step 1 Select **Querying > Device > Query by Address**.

Step 2 Enter Loop Number and Logic Address, and press **Enter**.


See the brief information of all devices with same address.

Figure 5-8 Query by address



Step 3 Press **↑** or **↓** to select target device, and press **Enter**.
See detailed information of this target device.

Figure 5-9 Address list




LA	User Code	Device Type	Device Info
001	0010102401	In/OutputMod	Loop 01 No. 001

5.2.2 Log

Select **Querying > Log**, to see the **FACP Log** and **Network Log**, including fire alarm, fault, active, feedback, supervisory and others. It can keep 5000 pieces of information at most.

Figure 5-10 Log Query




5.2.2.1 FACP Log

The device enables to query by time, type, device and address when acquires fire alarm and fault logs.

Step 1 Select **Querying > Log > FACP Log**.

Figure 5-11 FACP log



Step 2 Select query type, and press **Enter**.

See the brief information of all devices in this loop.

- Query by Time: Displays a record of all events according to the latest event occurrence time.

Figure 5-12 Query by time

Query by Time					10:34:54
NO.	Time	User Code	Device Type	Record Type	
00001	01-22 12:00	0010102401	In/OutputMod	Fault	
00002	01-22 12:00	0010102401	In/OutputMod	Fault	
00003	01-22 12:00	0010102401	In/OutputMod	Fault	
00004	01-22 12:00	0010102401	In/OutputMod	Fault	
00005	01-22 12:00	0010102401	Printer	Fault	
[↑ ↓] Select [Tap] Next Page [Cancel] Exit					

- Query by Type: Displays all records of the same type of event according to the latest event occurrence time. Enter the record type number, press **Enter** to view all fault events.

Table 5-1 Type number

Type Number	Event type
Fire Alarm	00
Supervisory	01
Active	02
Feedback	03
Delay	04
Fault	05
Disable	06

- Query by Device: Displays all records of the device according to the latest event occurrence time.
- Query by Address: Displays the historical event records of a device with a specific logic address in a loop. Enter the loop number and logic address of the target device, and press **Enter** to view the historical record information of the device.

Step 3 Press ↑ or ↓ to select target device, and press **Enter**.

See detailed information of this target device.

Figure 5-13 Record information




5.2.2.2 Network Log

Display event information transmitted to this FACP by other panels in the network. The operation is similar to querying FACP Log, please refer to 5.2.2.1 FACP Log.

5.2.3 Linkage

Linkage includes query by linkage relation, query by button on manual module panel and query by button on device linkage panel.

Figure 5-14 Linkage



5.2.3.1 Query by Linkage Relation

- Step 1** Select **Querying > Linkage > Query by Linkage Relation** to see linkage relation.
- Step 2** Press **↑** or **↓** to select target linkage relation, and press **Enter**.

See detailed information of this linkage relation.

5.2.3.2 Query by Button on Manual Module Panel

Select **Querying > Linkage> Query by Button on Manual Module Panel** to see information of manual module panel.


5.2.3.3 Query by Button on Device Linkage Panel

Select **Querying > Linkage> Query by Button on Device Linkage Panel** to see information of device linkage panel.

5.2.4 FACP Info

FACP Info includes project information and version information.

Figure 5-15 FACP Info



5.2.4.1 Project Information

Select **Querying > FACP Info > Project Info Query** to see detailed information of this project, for example, project name, project address, contact, and telephone.


5.2.4.2 Version Information

Select **Querying > FACP Info > Version Info** to see the hardware / software version of FACP and FACP ID.

5.3 Operation

Press **Menu** to enter the **Operation** interface, including Active & Stop, Disable, Log Print and System Test.

Figure 5-16 Operation




5.3.1 Active & Stop

Active & Stop menu includes active / stop device by user code, and active / stop device by logic address.



Active & Stop operations can only active and stop devices that support startup commands and are registered online. If the device is not registered online, when the device is activated, it will prompt that the device is offline. After the device is normally registered and online, the Active & Stop operations can respond normally.

Figure 5-17 Active & Stop



The active and stop operation is similar. The following uses the user code to active the device as an example.

Step 1 Select **Operation > Active & Stop > Active Device by User Code**.


Step 2 Enter user code, and press **Enter**.

Activate this device.

5.3.2 Disable

Disable operation is used for faulty field devices that are not able to be repaired in time. In such cases, they should be isolated temporarily and released after the problems are resolved. Devices can be disabled or enabled by user code and logic address.

Figure 5-18 Disable



The operation method of disabling device is similar. The following takes isolating a device by user code as an example.

Step 1 Select **Operation > Disable > Disable Device by User Code**.

- Step 2 Enter user code, and press **Enter**.
Disable this device.

5.3.3 Log Print

Print the specified event information for the specified time period.


Step 1 Select **Operation > Log Print**.

Step 1 Select the event type to be printed.

Step 2 Enter Start time and End time, and press **Enter**.

Print the recode of this event type during this period.

Figure 5-19 Print by time and type



5.3.4 System Test

In the process of system debugging, in order to check whether the FACP works normally, the self-test can be carried out. When the FACP is in self-test state, main control board, indicator light, speaker, flash memory, printer, and LCD are tested respectively.

Step 1 Select **Operation > System Test** or press **Test**.

FACP is in self-test mode, the Test LED is constantly on.


Press **Esc** to cancel the test process.

Step 2 After completing self-test, the Test LED turns off.

5.4 Settings

Press **Menu** to enter **Settings** interface, including Password, Display, Time, Print, Project and Language.

Figure 5-20 Settings



5.4.1 Password


Password Setting includes setting the system operator password, administrator password, and super user password.

Different operations require different minimum operation authorities, and high-level authority has the right to perform low-level authority operations. Enter the password first to obtain the operation authority, among which the system default first-level operation authority does not require a password.



The passwords for all levels of operation authority should be mastered and kept secret by specialized personnel. After the user completes the operation, the panel keyboard should be locked to restore the operation authority to the first level, so as to prevent unrelated personnel from operating the panel.

Figure 5-21 Password setting



5.4.1.1 System Operator Password Setting

The system operator can only perform basic common operations such as system viewing, muting, and resetting. There is no password by default.

Step 1 Select **Settings > Password > System Operator Pwd Setting**.

Step 2 Enter old password. Enter new password and then confirm it.

Step 3 Press **Enter** to save the new password.

5.4.1.2 System Administrator Password Setting

System administrator can perform operations such as registration, definition, and linkage programming for loop devices. There is no password by default. To set the system administrator password, please refer to 5.4.1.1 System Operator Pwd Setting.


5.4.1.3 Super User Password Setting

When the manufacturer replaces the core device, the super user password is required, and the password is not open to the user.

5.4.2 Display

Set the brightness of the LCD screen of the panel as well as the update time of the lock screen, the cursor update time, and the unattended exit update time when the panel is not operated.

Figure 5-22 Display setting




5.4.2.1 Brightness Level

Step 1 Select **Settings > Display > Brightness Level** to set brightness.

Step 2 Press **←** or **→** to adjust brightness. The setting is automatically saved when it is completed.

Figure 5-23 Brightness level



5.4.2.2 Display Refresh Time

Step 1 Select **Settings > Display > Display Refresh Time**.

Step 2 Press ↑ or ↓ to adjust refresh time and enter number. Press **Enter** to save the setting.


5.4.3 Time

Step 1 Select **Settings > Time**.

Step 2 Enter time and press ← or →.

Press **Enter** to save time setting.

Figure 5-24 Time




5.4.4 Print

When the event with designated type occurs, the information is printed automatically.

Step 1 Select **Settings > Print**.

Step 2 Select print types, and press **Enter**.

Figure 5-25 Print Setting



5.4.5 Project Information Settings

Select **Settings > Project Info Settings** to set project name, address, contact, and telephone.

5.4.6 Language

Select **Settings > Language** to set language, including Chinese, English and Russian.

5.5 Networking

Select Networking to set Controller and IP networking.

5.5.1 Controller Network

Select **Networking > Controller Network** to set the mode, address, the main/additional mode.


5.5.2 IP Network

The control panel can connect with platform. Select **Networking > IP Network** to set the connection method and platform information. The fire, fault, supervision and disabled information can send to platform immediately.

5.6 Linkage

Press **Menu** to enter **Linkage** interface, including New Linkage Relation, Modify Linkage Relation and Delete Linkage Relation.

Figure 5-26 Linkage programming



5.6.1 New Linkage Relation

The linkage relation consists of input items and output items, which are connected by "=". Each input and output item consists of a user code and a four-digit suffix.

Step 1 Select **Linkage > New Linkage Relation**.

Step 2 Edit linkage relation.



The four-digit suffix of the input item will automatically pop up to match the device type. The first two digits of the four-digit suffix of the output item are 01, and the last two digits are the delay time (hexadecimal).

Step 3 Press **Enter** to keep settings.

Figure 5-27 New linkage relation









Table 5-2 Symbol introduction

Symbol	Introduction
×	And.
+	Or.  It can only appear in input part.
=	<p>The left part of "=" is the input part. When there are multiple input items, each input item is connected by "×" or "+", the logical symbol "×" stands for "and", and "+" stands for "or", "+" can only appear in the input part.</p> <p>The right part of "=" is the output part. When there are multiple output items, each output item is connected by "×".</p> <p> TIPS</p> <p>To realize the two fire alarm signals sent by 1st smoke detector and 2nd addressable manual call point on the Floor 3, Unit 2, Building 1, activate 4th addressable sounder strobe and delay 6 seconds to start 5th input / output module on the Floor 3, Unit 2, Building 1, the linkage relation is: 01203 001 01 4002 × 01203 002 03 0100=01203 004 05 0100 × 01203 005 09 0106.</p> <p> The definition of numbers can be customized.</p>
*	<p>Represents any number between 0 and 9.</p> <p> TIPS</p> <p>To realize the two fire alarm signals sent by smoke detector and addressable manual call point on the Floor 3, Unit 2, Building 1, activate all addressable sounder strobes and delay 6 seconds to start all input / output modules on the Floor 3, Unit 2, Building 1, the linkage relation is: 01203 *** 01 4002 × 01203 *** 03 0100=01203 *** 05 0100 × 01203 *** 09 0106.</p>

Symbol	Introduction
#	<p>Indicates that the user code is consistent in the same position and must appear in the same position in all input user codes or output user codes.</p> <p> TIPS</p> <p>To realize the two fire alarm signals sent by smoke detector and addressable manual call point on the same floor of the same unit in Building 1, activate all addressable sounder strobes and delay 6 seconds to start all input / output modules on the same floor of the same unit in Building 1, the linkage relation is: 01### *** 01 4002 × 01###*** 03 0100=01### *** 05 0100 × 01### *** 09 0106.</p>

5.6.2 Modify Linkage Relation

While system debugging or device replacing, modify the linkage relation according to the actual situation.

Step 1 Select **Linkage > Modify Linkage Relation**.

Step 2 Modify the linkage relation.

Step 3 Press **Enter** to keep settings.

5.6.3 Delete Linkage Relation

When the linkage relation is not applicable, the linkage relation can be deleted.

Step 1 Select **Linkage > Delete Linkage Relation**.

Step 2 Delete the linkage relation.

Step 3 Press **Enter** to keep settings.

5.7 Debugging

Press **Menu** to enter **Debugging** interface, including System Mode, User Login, Reg. Device, Register Network, Define, Configuration Synchronization and Super Tool.

Figure 5-28 Debugging (1)






Figure 5-29 Debugging (2)



5.7.1 System Mode

Step 1 Select **Debugging > System Mode**.

Figure 5-30 System Mode



Step 2 Select system mode.

- Select **Debugging Mode**: When FACP is in debugging and maintenance mode, the LCD does not display fault information and Maintenance LED flashes.
- Select **Normal Mode**: When FACP is in debugging and maintenance mode, the LCD displays fault information and Maintenance LED turns off.

Step 3 Press **Enter** to keep settings.

5.7.2 User Login

Step 1 Select **Debugging > User Login**.

Step 2 Select login mode, and press **Enter**.

Enter the password, and press **Enter** to obtain corresponding operation authority.

Figure 5-31 User Login



Table 5-3 Operation

No.	Operation	I	II	III	IV
1	Query information	M	M	M	M
2	Mute device	M	M	M	M
3	Rest	P	M	M	M
4	Manual control	P	M	M	M
5	Test, isolate mode	P	M	M	M
6	Set time	P	M	M	M
7	Power on/off	P	M	M	M
8	Enter or modify data	P	P	M	M
9	Set delay mode	P	P	M	M
10	Programming	P	P	M	M
11	Modify or change software/hardware	P	P	P	M




- P is prohibited, M is allowed.
- Keys and operation numbers are required to enter the state of level II and level III operation functions. The key or number of operations used to enter the state of level III operation can be used to enter the state of level II operation functions, but the keys or number of operations used for level II operation state cannot be used. After entering the state of level III and level IV operation function.

5.7.3 Register Device

It includes register device in loop and channel registration of device linkage panel.

Figure 5-32 Register Device



5.7.3.1 Register Device in Loop

Step 1 Select **Debugging > Reg. Device > Register Device in Loop**.

Step 2 Select register mode, and press **Enter**.

- Select Register Again: Bus device LA remains unchanged.
- Select New Registration: Register based on the internal project information, synchronizing it to the bus device according to the loop and logic address, including device user code, description information, and key parameters. After completing the configuration information of the control panel and supplementing missing equipment in the loop, New Registration can directly deliver and synchronize the information that the panel has to define for the newly added equipment to the newly added equipment. Please refer to Select Register Again.

Step 3 Press **Enter** to keep settings.

5.7.3.2 Register on Device Linkage Panel

When the device linkage panel channel connection module is increased or reduced, the device linkage panel channel registration needs to be performed, and the information of the device linkage device is registered in the FACP, including the device user code, description information, and key parameters.

5.7.4 Register Network

Select **System Debugging > Register Network** to register other control panels in the local area network with this device. Network registration only registers the information of the control panel, not the information of the node devices connected to this panel.



The logic addresses of the control panels to be registered cannot be repeated. If there is repetition, modify the address in the **Super Tool > Modify Device Address on Bus** interface.


5.7.5 Define

Define or modify the user code, description information, key parameters, etc. of the device. It includes four definition functions: local device, manual module panel, and device linkage panel.



It can only define registered devices.

Figure 5-33 Define




5.7.5.1 Define Local Device

Define the user code, operation parameters and description information of the field device.

Step 1 Select **Debugging > Define > Define Local Device**.

Figure 5-34 Define local device



Step 2 Configure define method.

- Select **Automatically Define**, press **Enter**.
Automatically define user code, description information and operation parameters for all devices.
- Select **Device Inherited Define**, define the device on the basis of the original definition.
- Select **Device Continuously Define**, the first 5 digits of the user code follow the code of the previous device. The 6th/7th/8th digits of the user code represent the logic address of the device, which is automatically added to the previous one and filled continuously. At the same time, the device type number in the user code remains unchanged.

1. Configure the device type description to match the device type.
2. After completing the definition, press the **Esc** to exit, and the interface prompts "Synchronize device definition information?". Press "←" or "→" to select "Yes".
3. Press **Enter** to save and synchronize device information.



If the device information synchronization operation is not performed, although the panel saves the definition, the device itself keeps the original information unchanged.

5.7.5.2 Define Manual Module Panel

Set the manual module panel device controlled by each button on the manual module panel, and only bind the device that can execute the startup command.


Step 1 Select **Debugging > Define > Define Manual Module Panel**.

Step 2 Enter numbers and key code, and press **Enter**.

Enter the user code of the manual module panel device controlled by the button and the action delay at the user number.

- Press **Enter** to save the current setting and go to the next key setting.
- Press **Esc** to exit the definition of the current bus keyboard key.

Figure 5-35 Manual module panel




5.7.5.3 Define Device Linkage Panel

The operation of the key definition of the device linkage panel are similar to those of the manual module panel, please refer to 5.6.5.2 Define Manual Module Panel.



When defining the device linkage panel, make sure that the user number and description information of each key of the device linkage panel are consistent with the actual output wiring of the device linkage panel.


Figure 5-36 Device linkage panel



5.7.6 Configuration Synchronize

It includes export / import configurations by U disk, and deliver configuration to device.

Figure 5-37 Synchronize Configuration



5.7.6.1 Export Configurations by U Disk

Export and save the project configuration file by U disk, which is mainly used to query and check the device information in the debugging software of the host computer, or export the project configuration file for archive backup.

Step 1 Insert the U disk into the USB port behind the control panel.

Step 2 Select **Debugging > Config Sync. > Export Configurations by U Disk**, and press **Enter**.
Save the project configuration file to U disk.

5.7.6.2 Import Configurations by U Disk

In the field application, the configuration information of all field devices can be edited in advance through the host computer debugging software, the configuration file can be put into the U disk, the configuration information can be imported by U disk, and then the configuration information can be sent to the field device to modify device user code, device description information, device parameters and other information. The procedure for importing configuration information from U disk is similar to that of "Exporting configurations by U disk". For details, see 5.7.6.1 Export Configurations by U disk.


5.7.6.3 Deliver Configurations to Device

Select **Debugging > Config Sync. > Deliver Configurations to Device**, the control panel supports to deliver the project configuration to field devices.

5.7.7 Super Tool

It includes Update Firmware, Modify Device Address on Bus, Automatically Assign Address, Silence Mode Switch, Monitor Comm. Success Rate, and Fire Alarm Siren.

Figure 5-38 Super Tool (1)



5.7.7.1 Update Firmware

Update Firmware is used for upgrading program version by professionals. Insert the U disk containing the update file into the USB port of the manual module panel, and select the upgrade program and press **Enter** to update.

5.7.7.2 Modify Device Address on Bus

Modify Address is used for modifying logic address of bus device.

Step 1 Select **Debugging > Super Tool > Modify Device Address on Bus**.

- Step 2 Enter the loop number and logic address of target device, and press **Enter**.
- Step 3 Enter the new logic address, and press **Enter** to keep settings.
- Step 4 After completing modification, register device and the device has new logic address.



The modification result can be queried in **Device** interface.

5.7.7.3 Automatically Assign Address

When the field bus device does not write the logic address or the logic address of the existing device is repeated, use Automatically Assign Address to register all the bus devices. The system rewrites the logic address of all devices in sequence according to the S/N of each loop bus device.



The Automatically Assign Address will clear the written logic address and re-written new logic address according to device S/N. If all bus devices have written logic address, this function should be disabled to avoid unnecessary rework.

5.7.7.4 Silence Mode Switch

During system debugging, there may be fault or false alarm, triggering audible alarm. Enabling silence mode can temporarily stop the sound of speaker. After completing debugging, please reset silence mode.

5.7.7.5 Monitor Communication Success Rate

Communication success rate represents the ratio of the successful communications between the device and the control panel to the total communications, determining normal communication. If the communication success rate is above 90%, it means that the communication is normal; otherwise, it is abnormal, and the line needs to be checked.

5.7.7.6 Fire Alarm Siren

Select **Fire Alarm Siren Broadcasting Panel**, disable or enable siren by fire alarm.

6.FAQ

Problem	Analysis	Solutions
No display or abnormal display after starting up	<ul style="list-style-type: none"> Abnormal power supply Loose connection with LCD cable 	<ul style="list-style-type: none"> Check 220V AC power supply Check the connection cable
Display Main Power Fault after starting up	<ul style="list-style-type: none"> No 220V AC power supply The fuse of Main power is blown out 	<ul style="list-style-type: none"> Check and connect the cables Replace the AC fuse
Display Battery Fault after starting up	<ul style="list-style-type: none"> Loose connection with battery Battery discharged or damaged 	<ul style="list-style-type: none"> Check the relative parts and ensure the correct connection Power up for more than 24 hours with the AC power supply, if the fault still exists, replace the batteries
No alarm sound	<ul style="list-style-type: none"> Loose connection with Speaker terminals Speaker damaged FACP is in silence mode 	<ul style="list-style-type: none"> Insert the terminal Replace speaker Disable silence mode
Unable to register filed devices	<ul style="list-style-type: none"> Loose connection with filed devices The cable of field devices damaged 	<ul style="list-style-type: none"> Check and connect Check and replace the cable
Printer fails to work	<ul style="list-style-type: none"> Printing type is not set Loose connection with printer No paper in printer or paper is incorrectly put 	<ul style="list-style-type: none"> Set the printing types Check and connect the printer Replace or correctly put printing paper
Registered device is offline	<ul style="list-style-type: none"> Device disconnected Device damaged Loose connection with base 	<ul style="list-style-type: none"> Check the connection Replace the device Re-install the device and make sure the proper installation
LA repeated equipment information	The logic address is repetitive	Find the repetitive device and modify its logic address
Replace device	S/N of devices with the same number in the same circuit is inconsistent due to the replaced device	Replace original device or register
Fire/Fault output reports open circuit	Fire/Fault output terminal is not connected with 10K Ω resistor	Check Fire/Fault output terminal

Problem	Analysis	Solutions
Bus line Fault	Bus line is short circuit	Check the circuit

7.Maintenance

To keep your device in good working condition, please follow these requirements.

- Simulate alarm test: Test the device once half a year (recommended).
- Maintain mini printer: 57 mm × 35 mm thermal printing paper is adopted. When the printing paper is insufficient, please replace it in time.

Step 1 Press the button on the right side of the printer to open the printer compartment cover.


Step 2 Put in new printing paper, with the thermal side of the printing paper facing up, and place it above the roller to avoid passing under the roller.

Step 3 Close the cover, and slightly expose the paper to the paper output port of the printer.



Do not tilt the printing paper.

Figure 7-1 Printing paper dimension (mm[inch])



- Battery check: A visual inspection should be made once a quarter and discharging once half a year to ensure they are in good serviceable condition.



The battery has under-voltage protection function. When the battery is under-voltage, the panel will report the under-voltage fault information.

When reporting a backup power failure, check the connector and wiring of the backup battery. When the backup battery continuously works for more than 8 hours, it may also report a backup power failure due to low voltage.

- Fuse maintenance: Check the fuse when the main and backup power supply is abnormal. If the fuse is burnt out, replace the fuse with same specification.

Appendix 1 Device Type Table

Device name	Type	Device name	Type
Fire alarm control panel	00	Fire telephone jack socket	38
Point-type photoelectric smoke detector	01	Broadcast control panel	3a
Point-type heat detector	02	Broadcast power amplifier	3b
Manual fire alarm button	03	Broadcast speaker	3c
Fire hydrant button	04	Fire sprinkler pump	40
Sounder strobe	05	Water flow indicator	41
Repeater panel	06	Butterfly Valve	42
Input module	07	Alarm valve	43
Output module	08	Pressure switch	44
Input/output module	09	Fire stabilizer pump	45
Isolator module	0A	Fire pump	46
Relay module	0B	Smoke exhaust fan	51
Graphic display device	0C	Air blower	52
Line-type beam smoke detector	10	Smoke exhaust fire damper	53
Aspirating smoke detector	11	Normally-closed air outlet	54
Ultraviolet Flame Detector	12	Smoke exhaust air outlet	55
Infrared flame detector	13	Electronically controlled smoke barrier	56
Multi-sensor smoke and heat detector	15	Elevator	58
Multi-sensor flame detector	16	Positive pressure ventilation fan	59
Fiber optic linear heat detector	17	Fire rolling shutter half-fall	91
Video smoke detection equipment	18	Fire rolling shutter full drop	92
Gas extinguishing control panel	19	Solenoid valve	93
Spray indication	30	Air exhaust valve	94
Emergency active-stop button	31	Access control	98

Device name	Type	Device name	Type
Multi-sensor smoke and heat detector	32	70 degree normally open smoke exhaust fire damper	9D
Gas alarm control panel	33	70 degree normally closed smoke exhaust fire damper	9E
Fire telephone control panel	34	280 degree normally open smoke exhaust fire damper	9F
Fire extension telephone	35	Combustible gas detector	A0
Fire telephone mobile handset	37	Point-type combustible gas detector	A1

Appendix 2 Cybersecurity Recommendations

Cybersecurity is more than just a buzzword: it's something that pertains to every device that is connected to the internet. IP video surveillance is not immune to cyber risks, but taking basic steps toward protecting and strengthening networks and networked appliances will make them less susceptible to attacks. Below are some tips and recommendations from Dahua on how to create a more secured security system.

Mandatory actions to be taken for basic device network security:

1. Use Strong Passwords

Please refer to the following suggestions to set passwords.

- The length should not be less than 8 characters.
- Include at least two types of characters; character types include upper and lower case letters, numbers and symbols.
- Do not contain the account name or the account name in reverse order.
- Do not use continuous characters, such as 123, abc, etc.
- Do not use overlapped characters, such as 111, aaa, etc.

2. Update Firmware and Client Software in Time

- According to the standard procedure in Tech-industry, we recommend to keep your device (such as NVR, DVR, IP camera, etc.) firmware up-to-date to ensure the system is equipped with the latest security patches and fixes. When the device is connected to the public network, it is recommended to enable the "auto-check for updates" function to obtain timely information of firmware updates released by the manufacturer.
- We suggest that you download and use the latest version of client software.

"Nice to have" recommendations to improve your device network security:

1. Physical Protection

We suggest that you perform physical protection to device, especially storage devices. For example, place the device in a special computer room and cabinet, and implement well-done access control permission and key management to prevent unauthorized personnel from carrying out physical contacts such as damaging hardware, unauthorized connection of removable device (such as USB flash disk, serial port), etc.

2. Change Passwords Regularly

We suggest that you change passwords regularly to reduce the risk of being guessed or cracked.

3. Set and Update Passwords Reset Information Timely

The device supports password reset function. Please set up related information for password reset in time, including the end user's mailbox and password protection questions. If the information changes, please modify it in time. When setting password protection questions, it is suggested not to use those that can be easily guessed.

4. Enable Account Lock

The account lock feature is enabled by default, and we recommend you to keep it on to guarantee the account security. If an attacker attempts to log in with the wrong password several times, the corresponding account and the source IP address will be locked.

5. Change Default HTTP and Other Service Ports

We suggest you to change default HTTP and other service ports into any set of numbers

between 1024–65535, reducing the risk of outsiders being able to guess which ports you are using.

6. Enable HTTPS

We suggest you to enable HTTPS, so that you visit Web service through a secure communication channel.

7. MAC Address Binding

We recommend you to bind the IP and MAC address of the gateway to the device, thus reducing the risk of ARP spoofing.

8. Assign Accounts and Privileges Reasonably

According to business and management requirements, reasonably add users and assign a minimum set of permissions to them.

9. Disable Unnecessary Services and Choose Secure Modes

If not needed, it is recommended to turn off some services such as SNMP, SMTP, UPnP, etc., to reduce risks.

If necessary, it is highly recommended that you use safe modes, including but not limited to the following services:

- SNMP: Choose SNMP v3, and set up strong encryption passwords and authentication passwords.
- SMTP: Choose TLS to access mailbox server.
- FTP: Choose SFTP, and set up strong passwords.
- AP hotspot: Choose WPA2-PSK encryption mode, and set up strong passwords.

10. Audio and Video Encrypted Transmission

If your audio and video data contents are very important or sensitive, we recommend that you use encrypted transmission function, to reduce the risk of audio and video data being stolen during transmission.

Reminder: encrypted transmission will cause some loss in transmission efficiency.

11. Secure Auditing

- Check online users: we suggest that you check online users regularly to see if the device is logged in without authorization.
- Check device log: By viewing the logs, you can know the IP addresses that were used to log in to your devices and their key operations.

12. Network Log

Due to the limited storage capacity of the device, the stored log is limited. If you need to save the log for a long time, it is recommended that you enable the network log function to ensure that the critical logs are synchronized to the network log server for tracing.

13. Construct a Safe Network Environment

In order to better ensure the safety of device and reduce potential cyber risks, we recommend:

- Disable the port mapping function of the router to avoid direct access to the intranet devices from external network.
- The network should be partitioned and isolated according to the actual network needs. If there are no communication requirements between two sub networks, it is suggested to use VLAN, network GAP and other technologies to partition the network, so as to achieve the network isolation effect.
- Establish the 802.1x access authentication system to reduce the risk of unauthorized access to private networks.

- Enable IP/MAC address filtering function to limit the range of hosts allowed to access the device.

More information

Please visit Dahua official website security emergency response center for security announcements and the latest security recommendations.

ENABLING A SAFER SOCIETY AND SMARTER LIVING

ZHEJIANG DAHUA VISION TECHNOLOGY CO., LTD.

Address: No.1199 Bin'an Road, Binjiang District, Hangzhou, P. R. China | Website: www.dahuasecurity.com | Postcode: 310053

Email: overseas@dahuatech.com | Fax: +86-571-87688815 | Tel: +86-571-87688883