

# User Manual LCD Shelf Display

Date: February 2024

Doc Version: 1.1

English

Thank you for choosing our product. Please read the instructions carefully before operation. Follow these instructions to ensure that the product is functioning properly. The images shown in this manual are for illustrative purposes only.



For further details, please visit our Company's website www.zkdigimax.com..

# Copyright © 2024 ZKDIGIMAX PTE.LTD. All rights reserved.

Without the prior written consent of ZKDIGIMAX, no portion of this manual can be copied or forwarded in any way or form. All parts of this manual belong to ZKDIGIMAX (hereinafter the "Company" or "ZKDIGIMAX").

## **Trademark**

**EXAMPLE IMAX** is a registered trademark of ZKDIGIMAX. Other trademarks involved in this manual are owned by their respective owners.

## Disclaimer

This manual contains information on the operation and maintenance of the ZKDIGIMAX equipment. The copyright in all the documents, drawings, etc. in relation to the ZKDIGIMAX supplied equipment vests in and is the property of ZKDIGIMAX. The contents hereof should not be used or shared by the receiver with any third party without express written permission of ZKDIGIMAX.

The contents of this manual must be read as a whole before starting the operation and maintenance of the supplied equipment. If any of the content(s) of the manual seems unclear or incomplete, please contact ZKDIGIMAX before starting the operation and maintenance of the said equipment.

It is an essential pre-requisite for the satisfactory operation and maintenance that the operating and maintenance personnel are fully familiar with the design and that the said personnel have received thorough training in operating and maintaining the device/unit/equipment. It is further essential for the safe operation of the device/unit/ equipment that personnel has read, understood and followed the safety instructions contained in the manual.

In case of any conflict between terms and conditions of this manual and the contract specifications, drawings, instruction sheets or any other contract-related documents, the contract conditions/documents shall prevail. The contract specific conditions/ documents shall apply in priority.

ZKDIGIMAX offers no warranty, guarantee or representation regarding the completeness of any information contained in this manual or any of the amendments made thereto. ZKDIGIMAX does not extend the warranty of any kind, including, without limitation, any warranty of design, merchantability or fitness for a particular purpose.

ZKDIGIMAX does not assume responsibility for any errors or omissions in the information or documents which are referenced by or linked to this manual. The entire risk as to the results and performance obtained from using the information is assumed by the user.

ZKDIGIMAX in no event shall be liable to the user or any third party for any incidental, consequential, indirect, special, or exemplary damages, including, without limitation, loss of business, loss of profits, business interruption, loss of business information or any pecuniary loss, arising out of, in connection with,

or relating to the use of the information contained in or referenced by this manual, even if ZKDIGIMAX has been advised of the possibility of such damages.

This manual and the information contained therein may include technical, other inaccuracies or typographical errors. ZKDIGIMAX periodically changes the information herein which will be incorporated into new additions/amendments to the manual. ZKDIGIMAX reserves the right to add, delete, amend or modify the information contained in the manual from time to time in the form of circulars, letters, notes, etc. for better operation and safety of the device/unit/equipment. The said additions or amendments are meant for improvement /better operations of the device/unit/equipment and such amendments shall not give any right to claim any compensation or damages under any circumstances.

ZKDIGIMAX shall in no way be responsible (i) in case the device/unit/equipment malfunctions due to any non-compliance of the instructions contained in this manual (ii) in case of operation of the device/unit/equipment beyond the rate limits (iii) in case of operation of the device and equipment in conditions different from the prescribed conditions of the manual.

The product will be updated from time to time without prior notice. The latest operation procedures and relevant documents are available on http://www.zkdigimax.com

If there is any issue related to the product, please contact us.

# **About the Company**

ZKDIGIMAX is a new digital transformation platform company that comes from a joint venture company between PT Digital Mediatama Maxima Tbk ("DMMX") - an Indonesian public listed company focused on digital cloud advertising, and ZKTeco CO. LTD, a Chinese public listed company focused on biometric verification in security and time management solutions. ZKDIGIMAX strives to provide businesses end-to-end solutions, not only in digital cloud advertising, all biometric, computer vision hardware and SaaS software solutions but also in introducing a unique business model to transform retail, quick-service restaurants, offices, and buildings into a digitalized environment.

Our solution will help business owners focus more on their core business to achieve their growth potential, as all their digital needs are handled by us, not only for hardware and software but also managed service and maintenance solutions. ZKDIGIMAX provides a comprehensive total solution for the retail and quick service restaurant industries, from digital signage to AI business analysis, entrance control, time management, hardware leasing, software hosting, and more.

## **About the Manual**

This manual introduces the LCD Shelf Display.

All figures displayed are for illustration purposes only. Figures in this manual may not be exactly consistent with the actual products.

# **Table of Contents**

CAUTI	ON	5
	NINGS AND PRECAUTIONS	
	TY INSTRUCTION	
PACKI	NG LIST	6
1 PF	RODUCT INSTRUCTIONS	7
1.1	PRODUCT DIAGRAM COMPONENT AND INTERFACE DIAGRAM (UNIT: MM)	
1.2	Installation Instruction	10
1.3	OPERATION INSTRUCTION	1
2 E/	ALII T ANAI VCIC AND ELIMINATION	13

# **Caution**

Thank you for purchasing our display products. Please read and save this manual carefully before use.

# **Warnings and Precautions**



Please insert the socket accurately to prevent the power plug from falling off.

- If not connected properly, the screen may turn off or may cause fire.
- Make sure to hold the plug while disconnecting from the socket.



Do not use damaged power cords, plugs, or loose sockets as they may cause electric shock and fire. Make sure hands are not wet while removing the plug or power cable from the socket, as it may cause electric shock.



Pulling the wires can cause breakage and leakage in wires, causing fires and disasters. Do not connect more than one plug to a socket, overload fire and disaster may occur.



If you bend the power plug too much, there may be broken wires and leakage. Fire and disaster caused by power leakage may occur if the cable is broken. Please note that the power cable should not be unplugged when using the monitor.



If the product is not used for a long time, please detach the power cable. Otherwise, it may cause heat, fire and insulation leading to electric shock and leakage fire.



When placing the monitor, be careful not to impact the monitor, which may cause failure and damage to the monitor.



Do not install or use in damp and dusty places, which may cause leakage and electric shock to cause fire and other disaster.

## Warning:

This is an A grade product. In the domestic environment, the product may cause radio interference. In such cases, it may be necessary for the user to take practical measures against interference.

# **Safety Instruction**

 If you need to clean the monitor with a damp wipe, remove the plug first. Wipe the screen with a dry cloth only after the power is turned off, but do not use alcohol, solvents or ammonia-containing liquids.

- 2. If you have followed the instructions in this manual and the display still does not work properly, please contact a service technician.
- 3. Open the cover only by qualified maintenance personnel.
- 4. Keep the display away from direct sunlight, furnaces or other heat sources.
- 5. Remove anything that could fall into the vent or prevent the display electronics from dissipating heat.
- 6. Do not block the ventilation holes in the cabinet.
- 7. Keep the monitor dry. To avoid electric shock, do not place this product in an excessively humid environment or be exposed to rain.
- 8. In order to avoid electric shock and prevent permanent damage to the product, do not place the product in an excessively humid environment or be exposed to rain.
- 9. When placing the monitor, ensure that electrical plugs and sockets are safe to use.

# **Packing List**

Name	Quantity	Picture	Note
Main Device	1		See <u>Product Diagram</u> .
Fixed Plate	1	•	Use to fix the main device, and screws supplied.
Power Supply	1		Input: AC 100V-240V, 50/60Hz. Output: 12V/2A.


# 1 Product Instructions

# 1.1 Product Diagram Component and Interface Diagram (Unit: mm)

## Model: DG03-S1W23



**Front View** 




**Rear View** 

## Model: DG03-S1W24




**Front View** 




**Rear View** 

## Model: DG03-S1W28




**Front View** 




**Rear View** 

## Model: DG03-S1W29




## **Front View**



**Rear View** 

## Model: DG03-S1W35



# **Front View**




**Rear View** 

## Model: DG03-S1W37




## **Front View**




# **Rear View**






# **Side View**




**Fixed Plate** 

# 1.2 Installation Instruction

1. Install the wall hanging board on the customer's corresponding shelf with screws.




2. Plug the Type-C power plug into the rear of the device.



3. Align the device with the screw hole on the front of the wall mount, and lock the screw on the back of the wall mount (see the following diagram, installation is completed).

**Note:** The TF card slot and USB interface face down.




# **Attached: Disassembly Instructions**

Remove the screws fixed on the rear of the fixed plate and lift the device.



# 1.3 Operation Instruction


1. Power on the device; the standby screen will appear within a few seconds, as shown in the picture below:





**Boot Screen** 

2. Insert the TF card and connect it to the mouse using the transfer cable. The right mouse button serves as the return button.



## **Wi-Fi Connection:**

Manual Connection: Left click the mouse to enter the setting interface. Click Network and Internet
 Settings, turn on the switch, select Wi-Fi, and enter the password.

• **Automatic Connection:** After entering the correct Wi-Fi password, it will automatically connect next time.

## **Brightness Settings:**

Click on "Settings" to access the settings interface, then click on • and slide the progress bar to adjust the brightness to your preference.

# **Installing and Uninstalling the APK:**

- Manual Installation: Find the target APK through file management and click Install.
- Manual Uninstallation: Drag and drop the APK onto the uninstallation icon on the left.

# **2** Fault Analysis and Elimination

## Problem 1: No Image Displayed on LCD.

#### **Possible Causes:**

- The LVDS cable is disconnected.
- The device power is disconnection or powered off.
- The device has no signal input and is in standby state.

#### **Solution:**

- Please check that the LVDS cable is connected correctly, the network cable is connected correctly, and the plug is secure.
- Check whether the device is powered on.
- Please check whether the station command is normally sent and the device is in standby state.

## Problem 2: The Remote Control of the Device cannot Operate Normally.

#### **Possible Causes:**

- The remote control is too far away or the angle is too large.
- The battery is dead.

#### **Solution:**

- Please ensure that the remote control is within the effective control range.
- Please replace the battery.

## **Problem 3: Cannot enter the Screen Properly.**

## **Possible Causes:**

- The network connection is incorrect.
- The device information is incorrectly configured.

#### **Solution:**

- Check whether the network connection is correct.
- Reset basic information.

## Problem 4: Abnormal Image Display (Jitter, Flicker, Shadow).

#### **Possible Causes:**

- The abnormal image display may be caused by the poor quality of the signal cable.
- The abnormal image display may be due to the non-standard video file encoding format.

## **Solution:**

- Replace a signal cable with a good quality one.
- Replace the video file with a correct encoding format.

# Problem 5: The Startup Interface not Displayed.

#### **Possible Causes:**

The startup animation file is damaged.

#### **Solution:**

- Upgrading a known logo software package.
- To remake, select all the images, place them in a folder and compress them, and rename the file Bootanimation.zip.
- The file format can be png, jpg, or bmp. The file formats that are not supported are gif or tiff.

If you cannot resolve the issue using the above methods or encounter a different problem, please contact ZKDIGIMAX technical support.

Teletech Park #03/32, 20 Science Park Road, 117674, Singapore. www.zkdigimax.com

