

Access Standalone

User's Manual



V1.0.1






Foreword

General

This manual introduces the functions and operations of the Access Standalone (hereinafter referred to as the Device). Read carefully before using the device, and keep the manual safe for future reference.

Safety Instructions

The following signal words might appear in the manual.

Signal Words	Meaning
 DANGER	Indicates a high potential hazard which, if not avoided, will result in death or serious injury.
 WARNING	Indicates a medium or low potential hazard which, if not avoided, could result in slight or moderate injury.
 CAUTION	Indicates a potential risk which, if not avoided, could result in property damage, data loss, reductions in performance, or unpredictable results.
 TIPS	Provides methods to help you solve a problem or save time.
 NOTE	Provides additional information as a supplement to the text.

Revision History

Version	Revision Content	Release Time
V1.0.1	Added initialization description.	December 2024
V1.0.0	First release.	August 2024

Privacy Protection Notice

As the device user or data controller, you might collect the personal data of others such as their face, audio, fingerprints, and license plate number. You need to be in compliance with your local privacy protection laws and regulations to protect the legitimate rights and interests of other people by implementing measures which include but are not limited: Providing clear and visible identification to inform people of the existence of the surveillance area and provide required contact information.

About the Manual

- The manual is for reference only. Slight differences might be found between the manual and the product.
- We are not liable for losses incurred due to operating the product in ways that are not in compliance with the manual.

- The manual will be updated according to the latest laws and regulations of related jurisdictions. For detailed information, see the paper user's manual, use our CD-ROM, scan the QR code or visit our official website. The manual is for reference only. Slight differences might be found between the electronic version and the paper version.
- All designs and software are subject to change without prior written notice. Product updates might result in some differences appearing between the actual product and the manual. Please contact customer service for the latest program and supplementary documentation.
- There might be errors in the print or deviations in the description of the functions, operations and technical data. If there is any doubt or dispute, we reserve the right of final explanation.
- Upgrade the reader software or try other mainstream reader software if the manual (in PDF format) cannot be opened.
- All trademarks, registered trademarks and company names in the manual are properties of their respective owners.
- Please visit our website, contact the supplier or customer service if any problems occur while using the device.
- If there is any uncertainty or controversy, we reserve the right of final explanation.

Table of Contents

Foreword.....	I
1 Overview.....	1
2 Local Operations.....	2
2.1 Initialization.....	2
2.2 Main Menu.....	3
2.3 User Management.....	4
2.3.1 Adding User.....	4
2.3.2 Deleting User.....	5
2.4 Configuring Door Unlock Mode.....	5
2.5 Configuring Unlock Duration.....	6
2.6 Configuring Door Sensor.....	6
2.7 Password Management.....	6
2.7.1 Changing the Administrator Password.....	6
2.7.2 Adding Public Password.....	7
2.7.3 Deleting Public Password.....	7
2.8 Main Card Management.....	7
2.8.1 Adding Main Card.....	7
2.8.2 Deleting Main Card.....	8
2.8.3 Managing User Cards through Main Card.....	8
2.9 Configuring Door Timeout Period.....	8
2.10 Restoring to Factory Settings.....	9
3 Webpage Operations.....	10
3.1 Initialization.....	10
3.2 Resetting the Password.....	11
3.3 Home Page.....	12
3.4 Person Management.....	13
3.5 Configuring Access Control.....	17
3.5.1 Configuring Access Control Parameters.....	17
3.5.2 Configuring Alarms.....	20
3.5.3 Configuring Alarm Linkages (Optional).....	22
3.5.4 Configuring Alarm Event Linkage.....	24
3.5.5 Configuring Card Settings.....	25
3.5.6 Configuring Periods.....	28
3.5.7 Configuring Port Functions.....	30
3.5.8 Configuring the Password Unlock.....	31
3.5.9 Configuring First-Person Unlock.....	31
3.5.10 Configuring Anti-Passback.....	32

3.6	Access Monitoring.....	34
3.7	Communication Settings.....	35
3.7.1	Network Settings.....	35
3.7.2	Configuring RS-485.....	46
3.7.3	Configuring Wiegand.....	47
3.8	Configuring the System.....	49
3.8.1	User Management.....	49
3.8.2	Viewing Online Users.....	51
3.8.3	Configuring Time.....	51
3.9	Maintenance Center.....	53
3.9.1	One-click Diagnosis.....	53
3.9.2	System Information.....	53
3.9.3	Data Capacity.....	54
3.9.4	Viewing Logs.....	54
3.9.5	Maintenance Management.....	55
3.9.6	Updating the System.....	57
3.9.7	Advanced Maintenance.....	57
3.10	Security Settings(Optional)	58
3.10.1	Security Status.....	58
3.10.2	Configuring System Service.....	59
3.10.3	Attack Defense.....	60
3.10.4	Installing Device Certificate.....	63
3.10.5	Installing the Trusted CA Certificate.....	66
3.10.6	Security Warning.....	67
3.10.7	Security Authentication.....	68
4	Phone Operations.....	69
4.1	Initialization.....	69
4.2	Logging in to the Webpage.....	70
4.3	Home Page.....	71
4.4	Person Management.....	73
4.5	Configuring the System.....	76
4.5.1	Viewing Version Information.....	76
4.5.2	Maintenance.....	76
4.5.3	Configuring Time.....	77
4.5.4	Data Capacity.....	79
4.6	Configuring Access Control.....	79
4.6.1	Configuring Unlock Methods.....	79
4.6.2	Configuring Access Control Parameters.....	79
4.6.3	Configuring Alarms.....	81
4.6.4	Configuring Alarm Event Linkage.....	84

4.6.5	Configuring Card Settings.....	85
4.7	Communication Settings.....	87
4.7.1	Configuring TCP/IP.....	87
4.7.2	Configuring Wi-Fi.....	88
4.7.3	Configuring Wi-Fi AP.....	89
4.7.4	Configuring Cloud Service.....	90
4.7.5	Configuring Auto Registration.....	90
4.7.6	Configuring Wiegand.....	91
4.7.7	Configuring RS-485.....	92
4.8	Viewing Logs.....	94
4.8.1	System Logs.....	94
4.8.2	Unlock Records.....	95
4.8.3	Alarm Logs.....	95
5	Smart PSS Lite Configuration.....	96
5.1	Installation.....	96
5.2	Initialization.....	96
5.3	Adding Devices.....	99
5.3.1	Adding Device by Searching.....	100
5.3.2	Adding Device One by One.....	101
5.3.3	Importing Device in Batches.....	102
5.4	User Management.....	103
5.4.1	Setting Card Type.....	103
5.4.2	Configuring Card Type.....	103
5.4.3	Adding Users.....	104
5.4.4	Assigning Access Permissions.....	108
5.4.5	Assigning Attendance Permissions.....	110
5.5	Access Control Monitoring.....	113
Appendix 1	Important Points of Fingerprint Registration Instructions.....	116
Appendix 2	Security Recommendation.....	118

1 Overview

This product is an access control equipment integrating card reading, configuration and execution. The appearance of the product is simple and fashionable, and it is suitable for office buildings, schools, parks, communities, factories, public venues, business centers, government buildings and other application scenarios.

2 Local Operations

2.1 Initialization

After the Device is powered on for the first time, you need to set the administrator password. The administrator password is used to enter the main menu of the Device.

Procedure

Step 1 Power on the Device, and the indicator light will flash red slowly.

Step 2 Press # , enter the administrator password, and then press #.

The password must be 1 to 8 characters in length.

If the indicator light is solid blue, it means the Device is initialized.



After initialization, you can only use the functions on the Device. If you want to login to the webpage of the Device, initialize the Device on its webpage or through the ConfigTool.

Related Operations

- You can only set numbers as the admin account password when you initialize it through the Device.
- You can set numbers, letters and other characters as the admin account password when you initialize it through the platform of the ConfigTool.

After you complete the initialization on the Device, you can only perform operations on the Device itself. If you need to connect the Device to the network, use ConfigTool or the platform to initialize the Device.

When you use ConfigTool or the platform to initialize the Device, after configuring the network account and password, the device will automatically complete initialization and enter the standby status. The local admin password is converted from the network password. If the password exceeds 8 characters, only the first 8 characters are kept. The letters are converted into digits according to the E.161 standard. The password conversion is case-insensitive, and all other symbols are converted to 0.



- After the initialization, if you modify the network password, the local admin password will not be affected.
- If you initialize through the Device first, then initialize through the ConfigTool or the platform, the local admin password will not be affected.

Figure 2-1 E.161 (T9 keypad)




Table 2-1 Conversion example

Network Password	Local Admin Password
ABC12345	22212345
admin123	23646123
admin12!	23646120
admin123456	23646123

2.2 Main Menu

Entering Main Menu

Press # , enter the administrator password, and then press #.

- The indicator flashes blue, and it means you have entered the main menu.
- The indicator flashes red once, the buzzer beeps 3 times, and then the indicator turns solid blue, which means the password is wrong.

Related Prompts

- The indicator flashes green once, and the buzzer beeps once, which means that the operation or access control verification is successful.
- The indicator flashes red once, and the buzzer beeps 3 times, which means that the operation or access control verification failed.
- If the indicator flashes red slowly, it means the Device is not uninitialized.

- If the indicator is solid blue, it means the Device is in the standby status.
- The indicator flashes blue, it means the Device enters the main menu.
- The keypad is white when you operate the device. If there is no operation within 10 seconds, the light turns off and the Device exits the current screen.

2.3 User Management

2.3.1 Adding User



- You can add only one card, one password or one fingerprint for one user. At least one method of card, password, and fingerprint must be added.
- Fingerprint function is available on select models.

Procedure

Step 1 Press # , enter the administrator password, and then press #.

Enter the main menu, and the indicator flashes blue.

Step 2 Press 1 and # to add users.

Step 3 Enter the user ID, and then press #.

- If the indicator does not light up and the Device beeps, the user ID is added successfully.
- If the indicator flashes red and the Device beeps, you fail to add the user ID. The possible reason is the ID already exists. Please try the other ID.



You can only enter numbers for the ID on the Device.

Step 4 After swiping the card, press # to add the card.

If you do not need to add the card, press # to skip it.

Step 5 Enter the user password, and then press #.

If you do not need to set the user password, press # to skip it.



The password can be 1 to 8 characters in length.

Step 6 Add the fingerprint, and then press #.

If you do not need to set the fingerprint, press # to skip it.



This function is available on select models.

Step 7 Repeat Step 2 to Step 6 to add more users.

After adding the user, press * to return to the main menu, and then press * to return to the standby status.

2.3.2 Deleting User

Procedure

Step 1 Press # , enter the administrator password, and then press #.

Enter the main menu, and the indicator flashes blue.

Step 2 Press 2 and #.

Step 3 Delete a user.

- Swipe the card, and then press #.



If you swipe a card that has not been added, the deletion fails.

- Enter the user ID, and then press #.



If you enter the ID that has not been added, the deletion fails.

- Enter 0000, and then press # to delete all users.

After deletion, press * to return to the main menu, and then press * to exit the main menu.

2.4 Configuring Door Unlock Mode

Background Information



The fingerprint function is available on select models.

Procedure

Step 1 Press # , enter the administrator password, and then press #.

Enter the main menu and the indicator flashes blue.

Step 2 Press 3 and #.

Step 3 Select the unlock mode.

- Press 0 and # to set unlocking by card, password or fingerprint.

Swipe the card, enter the password, or use the fingerprint to open the door. The password consists of the following methods.

- ◇ On the standby screen, enter the user ID, press # , and the Device beeps once. Enter the password, and then press # to verify the identity.
- ◇ On the standby screen, enter the public password, and then press # to verify the identity.
- ◇ When the **PIN Code Authentication** is enabled on the webpage of the Device, people can verify the identity by simply entering the password.
- ◇ When the Device is used with the DMSS app, the temporary password is supported and can be configured on the app.

- Press 1 and # to set unlocking by card and user password.

Swipe the card first. After the Device beeps once, enter the password, and then press # to verify the identity.

- Press 2 and # to set unlocking by card and user password.

Swipe the card first. After the Device beeps once, press the fingerprint to verify the identity.

- Press **3** and **#** to set unlocking by card, password and fingerprint.

Swipe the card first. After the Device beeps once, press the fingerprint. The Device beeps again. Enter the password, and then press **#** to verify the identity.

Step 4 Press ***** to exit the main menu.

2.5 Configuring Unlock Duration

The door remains open after a defined time after it unlocks, which allows people to pass through.

Procedure

Step 1 Press **#**, enter the administrator password, and then press **#**.

Enter the main menu and the indicator flashes blue.

Step 2 Press **4** and **#**.

Step 3 Enter the time, and then press **#**.

The value ranges from 1 second to 600 seconds. The default value is 3 seconds.

Step 4 Press ***** to exit the main menu.

2.6 Configuring Door Sensor

After the door sensor is enabled, the door timeout alarm is enabled at the same time by default. If the door stays open after the set door timeout period, the buzzer of the Device generates alarms.

Procedure

Step 1 Press **#**, enter the administrator password, and then press **#**.

Enter the main menu and the indicator flashes blue.

Step 2 Press **5** and **#**.

Step 3 Turn on or turn off the door sensor.

The door sensor is turned off by default.

- Press **0** and **#** to turn off the door sensor.
- Press **1** and **#** to turn on the door sensor.

Step 4 Press ***** to exit the main menu.

2.7 Password Management

- Administrator password: Used to enter the main menu of the Device.
- Public password: Used to verify the authentication to unlock the door.

2.7.1 Changing the Administrator Password

To ensure device security, we recommend that you change the administrator password from time to time.

Procedure

Step 1 Press **#**, enter the administrator password, and then press **#**.

Enter the main menu and the indicator flashes blue.

- Step 2 Press **0** and #.
- Step 3 Enter the new password, and then press #.
- Step 4 Enter the new password again, and then press #.
- Flashing green means the password is modified successfully.
 - Flashing red means that you fail to modify the password.
 - After modification, the Device automatically exits the main menu, and the indicator turns solid blue. Enter the main menu using the new password if you modify the password successfully. Enter the main menu using the original password if you fail to modify the password.

2.7.2 Adding Public Password

Procedure

- Step 1 Press # , enter the administrator password, and then press #.

Enter the main menu and the indicator flashes blue.

- Step 2 Press **6** and #.

- Step 3 Enter the public password, and then press #.

The password can be 1 to 8 characters in length.



You can add only one public password. If you repeat the operations, the new password will replace the original one.

- Step 4 Press * to exit the main menu.

2.7.3 Deleting Public Password

Procedure

- Step 1 Press # , enter the administrator password, and then press #.

Enter the main menu and the indicator flashes blue.

- Step 2 Press **7** and #.

- Step 3 Enter the public password and press #.

- Step 4 Press * to exit the main menu.

2.8 Main Card Management

2.8.1 Adding Main Card

After adding the main card, you can quickly add and delete other user cards through the main card.

Background Information



The main card cannot be used to unlock the door.

Procedure

Step 1 Press # , enter the administrator password, and then press #.

Enter the main menu and the indicator flashes blue.

Step 2 Press 8 and #.

Step 3 Swipe the card, and then press #.

- If the indicator flashes green, and the Device beeps, it means the card is added as the main card.
- If the indicator flashes red, and the Device beeps, it means you fail to add the card as the main card.



- User cards that have been added can also be set as main card.
- If a user card is set to main card, it will not be able to unlock the door.
- Only supports one main card. If a new main card is added, the old main card will be overwritten.

Step 4 Press * to exit the main menu.

2.8.2 Deleting Main Card

Procedure

Step 1 Press # , enter the administrator password, and then press #.

Enter the main menu, and the indicator flashes blue.

Step 2 Press 9 and #.

Step 3 Swipe the card, and then press #.

Step 4 Press * to exit the main menu.

2.8.3 Managing User Cards through Main Card

If no operation is performed in 3 seconds after you swipe the main card, the Device enters the main card mode, and the Device will determine the corresponding function according to the swipe times of the main card. In the main card mode, the indicator flashes red and blue alternately, and if there is no operation for 10 seconds or you swipe the main card again for one time, it returns to the standby status.

- Add user card: Swipe the main card once, and then swipe the user card to add it. User cards can be added continuously.
- Delete the user card: Swipe the main card twice, and then swipe the user card to delete it. User cards can be deleted continuously.
- Clear all user cards: Swipe the main card 5 times in a row.

2.9 Configuring Door Timeout Period

After the door sensor is enabled, if the door stays open after the set time, the buzzer of the Device will give an alarm.

Procedure

Step 1 Press # , enter the administrator password, and then press #.

- Enter the main menu and the indicator flashes blue.
- Step 2 Press **10** and #.
- Step 3 Enter the door timeout period, and then press #.
- The value range is from 1 second to 9999 seconds. The default value is 60 seconds.
- Step 4 Press * to exit the main menu.

2.10 Restoring to Factory Settings

Procedure

- Step 1 Press # , enter the administrator password, and then press #.
- Enter the main menu, and the indicator flashes blue.
- Step 2 Press **11** and #.
- Step 3 Restore the Device to factory settings.
- Press **00** and # to restore factory settings (retain user information).
 - Press **000** and # to restore factory settings (restore all information).

Related Operations

You can use the reset button to restore the Device to factory settings.

3 Webpage Operations

On the webpage, you can also configure and update the Device.



Web configurations differ depending on models of the Device.

3.1 Initialization

Initialize the Device when you log in to the webpage for the first time or after the Device is restored to the factory defaults.

Prerequisites

Make sure that the computer used to log in to the webpage is on the same LAN as the Device.

Procedure

Step 1 Open a browser, go to the IP address (the default address is 192.168.1.108) of the Device.



We recommend you use the latest version of Chrome or Firefox.

Step 2 Select a language for the Device.

Step 3 Set the password and email address according to the screen instructions.



- The password must consist of 8 to 32 non-blank characters and contain at least two types of the following characters: upper case, lower case, numbers, and special characters (excluding ' " ; : &). Set a high-security password by following the password strength prompt.
- Keep the password safe after initialization and change the password regularly to improve security.

Related Operations

- You can only set numbers as the admin account password when you initialize it through the Device.
- You can set numbers, letters and other characters as the admin account password when you initialize it through the platform of the ConfigTool.

After you complete the initialization on the Device, you can only perform operations on the Device itself. If you need to connect the Device to the network, use ConfigTool or the platform to initialize the Device.

When you use ConfigTool or the platform to initialize the Device, after configuring the network account and password, the device will automatically complete initialization and enter the standby status. The local admin password is converted from the network password. If the password exceeds 8 characters, only the first 8 characters are kept. The letters are converted into digits according to the E.161 standard. The password conversion is case-insensitive, and all other symbols are converted to 0.



- After the initialization, if you modify the network password, the local admin password will not be affected.
- If you initialize through the Device first, then initialize through the ConfigTool or the platform, the local admin password will not be affected.

Figure 3-1 E.161 (T9 keypad)




Table 3-1 Conversion example

Network Password	Local Admin Password
ABC12345	22212345
admin123	23646123
admin12!	23646120
admin123456	23646123


3.2 Resetting the Password

Reset the password through the linked e-mail when you forget the admin password.

Procedure

- Step 1 On the login page, click **Forgot password**.
- Step 2 Read the on-screen prompt carefully, and then click **OK**.
- Step 3 Scan the QR code, and you will receive a security code.

Figure 3-2 Reset password



Please scan QR code.

Note (for admin only):

Please use an app that can scan and identify QR codes to scan the QR code on the left. Please send the results of the scan to support_rpwd@global.damtech.com.

Email Address: 1***@damtech.com

Security code:

Next



- Up to two security codes will be generated when the same QR code is scanned. If the security code becomes invalid, refresh the QR code and scan again.
- After you scan the QR code, you will receive a security code in your linked e-mail address. Use the security code within 24 hours after you receive it. Otherwise, it will become invalid.
- If the wrong security code is entered 5 times in a row, the administrator account will be frozen for 5 minutes.

Step 4 Enter the security code.

Step 5 Click **Next**.

Step 6 Reset and confirm the password.



The password should consist of 8 to 32 non-blank characters and contain at least two of the following types of characters: upper case, lower case, number, and special character (excluding ' " ; : &).

Step 7 Click **OK**.

3.3 Home Page

The home page is displayed after you successfully log in.

Figure 3-3 Home page




Table 3-2 Home page description

No.	Description
1	<ul style="list-style-type: none"> • : Enter the home page. • : Select a language on the device. • : Log out or restart the device. • : Enter the Security page. • Product Material : Scan the QR code to view the product material. <div> <p>This function is available on select models.</p> </div> <ul style="list-style-type: none"> • : Display in the full screen.
2	Main menu.

3.4 Person Management

Procedure

- Step 1 On the home page, select **Person Management** , and then click **Add**.
- Step 2 Configure user information.

Figure 3-4 Add users

Add
X

Basic Info

* No.

Name

* User Type
General User
v

* Times Used
Unlimited


* General Plan
255-Default x

* Holiday Plan
255-Default x

Validity Period
2037-12-31 23:59:59

Verification Mode

v Password
Not Added


Add



> Card
Not Added





> Fingerprint
Not Added

Add
Add More
Cancel

Table 3-3 Parameters description

Parameter	Description
No.	The No. is like employee ID, which can be numbers, letters, and their combinations, and the maximum length of the number is 30 characters.
Name	The name can have up to 32 characters (including numbers, symbols, and letters).

Parameter	Description
User Type	<ul style="list-style-type: none"> ● General User : General users can unlock the door. ● Blocklist User : When users in the blocklist unlock the door, service personnel will receive a notification. ● Guest User : Guests can unlock the door within a defined period or for certain amount of times. After the defined period expires or the unlocking times runs out, they cannot unlock the door. ● Patrol User : Patrol users can take attendance on the Device, but they do not have door permissions. ● VIP User : When VIP unlock the door, service personnel will receive a notice. ● Other User : When they unlock the door, the door will stay unlocked for 5 more seconds. ● Custom User 1/Custom User 2: Same as general users.
Times Used	Set an unlock limit for guest users. After the unlock times run out, they cannot unlock the door.
General Plan	<p>People can unlock the door or take attendance during the defined period.</p>  <p>You can select more than one plan.</p>
Holiday Plan	<p>People can unlock the door or take attendance during the defined holiday.</p>  <p>You can select more than one holiday.</p>
Validity Period	Set a date on which the door access and attendance permissions of the person will be expired.
Password	Enter the user password. The maximum length of the password is 8 digits. The duress password is the unlock password + 1. For example, if the user password is 12345, the duress password will be 12346. A duress alarm will be triggered when a duress password is used to unlock the door.

Parameter	Description
Card	<ul style="list-style-type: none"> Enter the card number manually. <ol style="list-style-type: none"> Click Add. Enter the card number, and then click Add. Read the number automatically through the enrollment reader or the Device. <ol style="list-style-type: none"> Click Add, and then click Modify to select an enrollment reader or the Device. Click Read Card, and then swipe cards on the card reader. <p>A 60-second countdown is displayed to remind you to swipe cards, and the system will read the card number automatically. If the 60-second countdown expires, click Read Card again to start a new countdown.</p> <ol style="list-style-type: none"> Click Add. <p>A user can register up to 5 cards at most. Enter your card number or swipe your card, and then the card information will be read by the Device.</p> <p>You can enable the Duress Card function. An alarm will be triggered if a duress card is used to unlock the door.</p> <ul style="list-style-type: none"> : Set duress card. : Change card number. <p></p> <p>One user can only set one duress card.</p>
Fingerprint	<p>Register fingerprints. A user can register up to 3 fingerprints, and you can set a fingerprint to the duress fingerprint. An alarm will be triggered when the duress fingerprint is used to unlock the door.</p> <p>Enroll fingerprints through an enrollment reader or the Device.</p> <ol style="list-style-type: none"> Click Add, and then click Modify to select an enrollment reader or the Device. Press finger on the scanner according to the on-screen instructions. Click Add. <p></p> <ul style="list-style-type: none"> Fingerprint function is only available on select models. We do not recommend you set the first fingerprint as the duress fingerprint. One user can only set one duress fingerprint. Fingerprint function is available if the Device supports connecting a fingerprint module.


Step 3 Click **OK**.

Related Operations

- Import user information: Click **Export** , download the template and enter user information in it. Click **Import** to import the folder.



Up to 10,000 users can be imported at a time.

- Clear: Clear all users.
- Refresh: Refresh the user list.
- Click  to edit the person information.
- Select people, and then click **Delete** to delete users.
- Search: Search by user name or user ID.

3.5 Configuring Access Control

3.5.1 Configuring Access Control Parameters


3.5.1.1 Configuring Basic Parameters

Procedure

Step 1 Select **Access Control** > **Access Control Parameters**.

Step 2 In **Basic Settings**, configure basic parameters for the access control.

Figure 3-5 Basic parameters



Basic Settings

Name: Door1

Door Status: ☒ Normal ☐ Always Closed ☐ Always Open

Normally Open Period: General Plan Disabled Holiday Plan Disabled


Normally Closed Period: General Plan Disabled Holiday Plan Disabled

Verification Interval: 0 s (0-180)

Admin Unlock Password: ☒

Table 3-4 Basic parameters description

Parameter	Description
Name	The name of the door.
Door Status	<p>Set the door status.</p> <ul style="list-style-type: none">• Normal: The door will be unlocked and locked according to your settings.• Always Open: The door remains unlocked all the time.• Always Closed: The door remains locked all the time.

Parameter	Description
Normally Open Period	When you select Normal , you can select a time template from the drop-down list. The door remains open or closed during the defined time.
Normally Closed Period	 <ul style="list-style-type: none"> • When normally open period conflicts with normally closed period, normally open period takes priority over normally closed period. • When period conflicts with holiday plan, holiday plans take priority over periods.
Verification Interval	If you verify your identity multiple times within a set period, only the earliest verification will be considered valid, and the door will not open after the second or later verifications. From the moment the door fails to open, you must wait for the configured verification time interval before attempting to verify your identity again.
Admin Unlock Password	You can configure one administrator password for opening the door. The password must contain 1 to 8 numbers.

Step 3 Click **Apply**.

3.5.1.2 Configuring Unlock Methods

You can use multiple unlock methods to unlock the door, such as fingerprint, card, and password. You can also combine them to create your own personal unlock method.

Procedure

Step 1 Select **Access Control** > **Access Control Parameters**.

Step 2 In **Unlock Settings**, select an unlock method.

- Combination unlock
 1. Select **Combination Unlock** from the **Unlock Method** list.
 2. Select **Or** or **And**.
 - ◇ Or: Use one of the selected unlock methods to open the door.
 - ◇ And: Use all the selected unlock methods to open the door.
 3. Select unlock methods, and then configure other parameters.

Figure 3-6 Unlock settings

Unlock Settings

Unlock Method

Combination Unlock

Combination Method

☒ Or
 ☐ And

Unlock Method (Multi-select)

☒ Card
 ☒ Fingerprint
 ☒ Password

Door Unlocked Duration

3.0

s (0.2-600)

Remote Verification

☐

Table 3-5 Unlock settings description

Parameter	Description
Unlock Method (Multi-select)	Unlock methods might differ depending on the models of product.
Door Unlock Duration	After a person is granted access, the door will remain unlocked for a defined time for the person to pass through. It ranges from 0.2 to 600 seconds.
Remote Verification	If this function is enabled, you can control the door on the corresponding platform.

- Unlock by period

1. In the **Unlock Method** list, select **Unlock by Period**.
2. Drag the slider to adjust time period for each day.



You can also click **Copy** to apply the configured time period to other days.

3. Select an unlock method for the time period, and then configure other parameters.

Figure 3-7 Unlock by period

Unlock Method: Unlock by Period

	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
Sun	Card/Fingerprint/Password																								Copy
Mon	Card/Fingerprint/Password																								Copy
Tue	Card/Fingerprint/Password																								Copy
Wed	Card/Fingerprint/Password																								Copy
Thu	Card/Fingerprint/Password																								Copy
Fri	Card/Fingerprint/Password																								Copy
Sat	Card/Fingerprint/Password																								Copy

Door Unlocked Duration: s (0.2-600)

Remote Verification: ☐

- Unlock by multiple users.
 1. In the **Unlock Method** list, select **Unlock by multiple users**.
 2. Click **Add** to add groups.
 3. Select unlock method, valid number and users.



- ◇ The valid number indicates the number of people who need to verify their identities on the Device before the door unlocks.

Step 3 Click **Apply**.

3.5.2 Configuring Alarms

An alarm will be triggered when an abnormal access event occurs.

Procedure

- Step 1 Select **Access Control** > **Alarm** > **Alarm**.
- Step 2 Configure alarm parameters.

Figure 3-8 Alarm

Duress Alarm

☒

Anti-passback

☐

Door Detector

☒

☐ NC ☒ NO

Intrusion Alarm

☐

Unlock Timeout Alarm

☐

Unlock Timeout

60

s (1-9999)

Excessive Use Alarm


☒



Apply

Refresh

Default

Table 3-6 Description of alarm parameters

Parameter	Description
Duress Alarm	An alarm will be triggered when a duress card, duress password or duress fingerprint is used to unlock the door.
Anti-passback	<p>Users need to verify their identities both for entry and exit; otherwise an alarm will be triggered. It helps prevent a card holder from passing an access card back to another person to gain entry. When anti-passback is enabled, the card holder must leave the secured area through an exit reader before system will grant another entry.</p> <ul style="list-style-type: none"> • If a person enters after authorization and exits without authorization, an alarm will be triggered when the person attempt to enter again, and access is denied at the same time. • If a person enters without authorization and exits after authorization, an alarm will be triggered when the person attempt to enter again, and access is denied at the same time. <p></p> <p>If the Device can only connect one lock, verifying on the Device means entry direction, and verifying on the external card reader means exit direction by default. You can modify the setting on the management platform.</p>

Parameter	Description
Door Detector	<p>With the door detector wired to your device, alarm can be triggered when doors are opened or closed abnormally. The door detector includes 2 types, including NC detector and NO detector.</p> <ul style="list-style-type: none"> ● NC: The sensor is in a shorted position when the door or window is closed. ● NO: An open circuit is created when the window or door is actually closed.
Intrusion Alarm	<p>If the door is opened abnormally, an intrusion alarm will be triggered and last for a defined time.</p>  <p>The door detector and intrusion need to be enabled at the same time.</p>
Unlock Timeout Alarm	<p>When the door remains unlocked for longer than the defined timeout duration, the door timeout alarm will be triggered and last for the defined time.</p>
Unlock Timeout	 <p>The door detector and door timed out function need to be enabled at the same time.</p>
Excessive Use Alarm	<p>If the wrong password or card is used 5 times in a row within 60 seconds, the alarm for excessive use of illegal card will be triggered and last for a defined time.</p>

Step 3 Click **Apply**.

3.5.3 Configuring Alarm Linkages (Optional)

You can configure alarm linkages.

Procedure

Step 1 Select **Access Control** > **Alarm** > **Alarm Linkage Setting**.



- If the Device is added to a management platform, the alarm settings will be synchronized to the platform.
- This function is only available on models that have alarm input and alarm output ports.
- The number of alarm input and output ports differs depending on models of the product.


Step 2 Click  to configure alarm.

Figure 3-9 Alarm linkage

Alarm-in Port	<input type="text" value="1"/>	Name	<input type="text" value="Zone1"/>
Alarm Input Type	<input type="text" value="NO"/>	Link Fire Safety Control	<input checked="" type="checkbox"/>
<hr/>			
Alarm-out Port	<input type="checkbox"/>		
Duration	<input type="text" value="30"/>	s (1-300)	
Alarm Output Channel	<input checked="" type="checkbox"/> 1		
<hr/>			
Access Control Linkage	<input type="checkbox"/>		
<div style="border: 1px solid #add8e6; padding: 5px;"> <i>When the heat alarm signal disappears, the door will automatically return to the normal authentication mode.</i> </div>			
Linkage Mode	<input type="text" value="Weak Execution"/>		
Channel Type	<input type="text" value="NO"/>		
<input type="button" value="OK"/> <input type="button" value="Cancel"/>			

Step 3 Create a name for the alarm zone.

Step 4 Enable **Link Fire Safety Control**, and select a type for the alarm input device.

- Normally Closed: The alarm input is in a normally closed (NC) circuit state when the alarm has not been tripped. Opening a normally closed circuit sets off the alarm.
- Normally Open: The alarm input device is in a normally open (NO) circuit state when the alarm has not been tripped. Closing the circuit sets off the alarm.

Step 5 If you want to link access control when the fire alarm is triggered, enable **Access Control Linkage**.



This function takes effect only after **Link Fire Safety Control** is enabled.

Step 6 Select a linkage mode.

- Strong Execution: When the fire alarm signal disappears, the door remains the current status. Please manually change to its previous door status settings if you want to.
- Weak Execution: When the fire alarm signal disappears, the door automatically returns to its previous door status.

Step 7 Select a channel type.

- NO: The door automatically opens when fire alarm is triggered.
- NC: The door automatically closes when fire alarm is triggered.

Step 8 Click **OK**.

3.5.4 Configuring Alarm Event Linkage

Procedure

Step 1 On the **Main Menu**, select **Access Control > Alarm > Alarm Event Linkage**.

Step 2 Configure alarm event linkages.

Figure 3-10 Alarm event linkage

Intrusion Alarm Linkage

☒ Enable

Duration

s (1-1800)

☒ Enable

Link Alarm Ou...

s (1-1800)

Unlock Timeout Alarm Lin...

☒ Enable

Duration

Custom Time ▾

s (1-1800)

☒ Enable

Link Alarm Ou...

s (1-1800)

Max Use Alarm Link

☒ Enable

Duration

s (1-1800)

☒ Enable

Link Alarm Ou...

s (1-1800)

Tamper Alarm Linkage

☒ Enable

Duration

s (1-1800)

☐ Enable

Link Alarm Ou...

s (1-1800)

Apply

Refresh

Default

Please enable Intrusion Alarm.

Please enable Unlock Timeout Alarm.

Please enable Excessive Use Alarm.

Table 3-7 Alarm event linkage

Parameter	Description
Intrusion Alarm Linkage	<p>If the door is opened abnormally, an intrusion alarm will be triggered.</p> <ul style="list-style-type: none">• Buzzer: The buzzer sounds when an intrusion alarm is triggered. You can configure the alarm duration.• Link Alarm Output: The external alarm device generates alarms when the intrusion alarm is triggered. You can configure the alarm duration.

Parameter	Description
Unlock Timeout Alarm Linkage	<p>When the door remains unlocked for longer than the defined timeout duration, the door timeout alarm will be triggered and last for the defined time.</p> <ul style="list-style-type: none"> ● Buzzer: The buzzer sounds when the unlock timeout alarm is triggered. You can configure the alarm duration. ● Local Alarm Output: The external alarm device generates alarms when the unlock timeout alarm is triggered. You can configure the alarm duration.
Max Use Alarm Link	<p>If the wrong password or card is used 5 times in a row within 60 seconds, the alarm for excessive use of illegal card will be triggered and lasts for a defined time.</p> <ul style="list-style-type: none"> ● Buzzer: The buzzer sounds when the excessive use alarm is triggered. You can configure the alarm duration. ● Local Alarm Output: The external alarm device generates alarms when the unlock timeout alarm is triggered. You can configure the alarm duration.
Tamper Alarm Linkage	<p>The tamper alarm is triggered when someone has tried to physically damage the Device.</p> <ul style="list-style-type: none"> ● Buzzer: The buzzer sounds when the tamper alarm is triggered. You can configure the alarm duration. ● Local Alarm Output: The external alarm device generates alarms when the tamper alarm is triggered. You can configure the alarm duration.

Step 3 Click **Apply**.

3.5.5 Configuring Card Settings

Background Information



This function is only available on select models.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **Access Control** > **Card Settings**.
- Step 3 Configure the card parameters.

Figure 3-11 Card parameters

Card Settings

IC Card

IC Card Encryption & Verification

Block NFC Cards

Enable DESFire Card

DESFire Card Decryption

Apply

Refresh

Default

Card No. System

After the number system is changed, the card numbers will become invalid.

Card No. System

☒ Hexadecimal
 ☐ Decimal

Apply

Refresh

Default

DESFire Card Write






Please place the card on the swiping area and enable DESFire card and DESFire Card Decryption.

Card Number

Write

Table 3-8 Card parameters description

Item	Parameter	Description
Card Settings	IC Card	The IC card can be read when this function is enabled.
		<div></div> This function is only available on select models.

Item	Parameter	Description
	IC Card Encryption & Verification	<p>The encrypted card can be read when this function is enabled.</p>  <p>Make sure IC Card is enabled.</p>
	Block NFC Cards	<p>Prevent unlocking through duplicated NFC card after this function is enabled.</p>  <ul style="list-style-type: none"> • This function is only available on models that support IC cards. • Make sure IC Card is enabled. • NFC function is only available on select models of phones.
	Enable Desfire Card	<p>The Device can read the card number of Desfire card when this function and IC Card are enabled at the same time.</p>  <ul style="list-style-type: none"> • This function is only available on models that support IC cards. • Only supports hexadecimal format.
	Desfire Card Decryption	<p>Information in the Desfire card can be read when IC Card, Enable Desfire Card and Desfire Card Decryption are enabled at the same time.</p>  <ul style="list-style-type: none"> • This function is only available on models that support IC cards. • Make sure that Desfire card is enabled.
Card No. System	Card No. System	<p>Select decimal format or hexadecimal format for the card number when Wiegand card reader is connected. The card No. system is the same for both card number input and output.</p>
DESFire Card Write	Card Number	<p>Place the card on the reader, enter the card number, and then click Write to write card number to the card.</p>  <ul style="list-style-type: none"> • Desfire card function must be enabled. • Only supports hexadecimal format. • Supports up to 8 characters.

Step 4 Click **Apply**.

3.5.6 Configuring Periods

Configure general plans and holiday plans, and then you can define when a user has the permissions to unlock doors.

3.5.6.1 Configuring General Plan

You can configure up to 128 periods (from No.0 through No.127) of general plans. In each period, you need to configure door access schedules for a whole week. People can only unlock the door during the scheduled time.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **Access Control** > **Period Config** > **General Plan**.
- Step 3 Click **Add**.
1. Configure the plan number and the plan name.
 2. Drag the time slider to configure time for each day.
 3. (Optional) Click **Copy** to copy the configuration to the rest of days.

Figure 3-12 Configure general plan

The screenshot shows a web interface for adding a general plan. The dialog is titled 'Add' and has a close button (X) in the top right corner. It contains the following elements:

- No.:** A dropdown menu with the value '0' selected.
- General Plan Name:** A text input field containing 'Plan 1'.
- Time Plan:** A grid for configuring access times for each day of the week. The grid has columns for hours (0 to 11) and rows for days (Sun, Mon, Tue, Wed, Thu, Fri, Sat). A time range of 12:30:00 to 23:59:59 is selected, and the 'Copy' button is visible for each day.
- Buttons:** 'OK' and 'Cancel' buttons are located at the bottom right of the dialog.

- Step 4 Click **OK**.

3.5.6.2 Configuring Holiday Plan

You can configure up to 128 holiday groups (from No.0 through No.127), and for each holiday group, you can add up to 16 holidays in it. After that, you can assign the configured holiday groups to the holiday plan. Users can only unlock the door during the defined time of the holiday plan.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **Access Control** > **Period Config** > **Holiday Plan**.
- Step 3 Click **Holiday Management**, and then click **Add**.
1. Select a number for the holiday group, and then enter a name for the group.

Figure 3-13 Add a holiday group

The 'Add' dialog box contains the following fields and elements:

- No.:** A dropdown menu with the value '2' selected.
- Holiday Group Name:** A text input field containing 'Holiday Group for 2023'.
- Holiday Group Config:** A section containing an 'Add' button and a table.
- Table:** A table with 5 columns: No., Holiday Name, Start Time, End Time, and Operation. It contains one row with the following data:

No.	Holiday Name	Start Time	End Time	Operation
1	National Day	2023-10-01	2023-10-07	
- Buttons:** 'OK' and 'Cancel' buttons at the bottom right.

2. Click **Add**, add a holiday to a holiday group, and then click **OK**.

Figure 3-14 Add a holiday to a holiday group

The 'Edit' dialog box contains the following fields and elements:

- Holiday Name:** A text input field containing 'National Day'.
- * Period:** A date range selector showing '2023-10-01' to '2023-10-07' with a calendar icon.
- Buttons:** 'OK' and 'Cancel' buttons at the bottom right.

- Step 4 Click **OK**.
- Step 5 Click **Plan Management**, and then click **Add**.
1. Select a number for the holiday plan, and then enter a name for it.
 2. Select a holiday group, and then drag the slider to configure time for each day.
Supports adding up to 4 time sections on a day.

Figure 3-15 Add holiday plan

Step 6 Click **OK**.

3.5.7 Configuring Port Functions

Some ports can function as different ports, you can set them to different ports based on the actual needs.

Background Information



- This function is only available on select models.
- Ports might differ depending on the models of the product.

Procedure

Step 1 On the webpage, select **Access Control** > **Port Config**.

Step 2 Select the type of the port.

It is **Doorbell** by default.

Step 3 Click **Apply**.

Figure 3-16 Configure ports

3.5.8 Configuring the Password Unlock

When the **PIN Code Authentication** is enabled, people can unlock the door by simply entering the password.

Background Information



- If PIN code authentication is not enabled, you can unlock the door by entering the unlock password in the format of **user ID#password#** . For example, if the user ID is 123, and the password you set is 12345, and then you must enter **123#12345#** to unlock the door.
- If PIN code authentication is enabled, you can unlock the door by entering the unlock password in the format of **password#** . For example, if the user ID is 123, and the password you set is 12345, and then you must enter **12345#** to unlock the door.

Procedure

Step 1 On the home page, select **Access Control** > **Unlock Method Config**.

Step 2 Turn on **PIN Code Authentication** , and then click **Apply**.



There are some safety risks in enabling PIN code authentication. When it is turned on, the user types and roles become ineffective, and the following situations occur.

- First-card holders and users in multi-person unlock groups need to verify their identities through the defined unlock methods, except password. If they verify through password, the first-card unlock or multi-person unlock function will become ineffective.
- Users need to verify their through defined unlock methods except password. If they gain access through password, the anti-passback function will become ineffective.
- Patrol users and block-listed users can simply enter their password to unlock the door.
- Frozen and expired accounts can still unlock doors by simply entering their password.
- When the password unlock method is turned off at the same time, all types of users cannot unlock the door using their password.

3.5.9 Configuring First-Person Unlock

Any person can only access doors only after the persons you specify pass through. When you specify multiple persons, other persons can access doors after any one of specified persons pass through.

Prerequisites

Persons can only be set as first persons when they have permissions to access doors.

Procedure

Step 1 On the home page, select **Access Control** > **First-Person Unlock**.

Step 2 Select the door channel, and then enable the function.

Figure 3-17 First-person unlock

Step 3 Configure the parameters.

Table 3-9 Parameter description

Parameter	Description
Time Templates	Select when this rule is effective.
Door Status after First-Card Unlock	<ul style="list-style-type: none"> ● Normal : Other persons must verify their identifications to pass. ● Always Open : All people can pass without verifying their identifications.
Person List	Click + to select one or more persons, and they will have permissions to access the doors.

Step 4 Click **Apply**.

3.5.10 Configuring Anti-Passback

Users need to verify their identities both for entry and exit; otherwise an anti-passback alarm will be triggered. It prevents a card holder from passing an access card back to another person so they gain entry. When anti-passback is enabled, the card holder must leave the secure area before system will grant another entry.

- If a person enters after being authorized and exits without being authorized, an alarm will be triggered when they attempt to enter again, and access is denied at the same time.
- If a person without being authorized and exits after being authorized, an alarm will be triggered when they attempt to enter again, and access is denied at the same time.



- When you have configured anti-passback for sub controllers through the main controller, and you plan on restoring the main controller to its factory defaults, we recommend you also restore the sub controller to its factory defaults at the same time.
- If the anti-passback rule is used when the network is not stable, the door might open after an identity is verified, but a time-out alarm might be triggered on the card reader. Please make sure your network is stable.

Procedure

- Step 1 On the home page, select **Access Control** > **Anti-passback Group Config**.
- Step 2 Turn on this function, and then configure a reset time.
Specify a time when the anti-passback status of all personnel will be reset.
- Step 3 Select the general plan and the holiday plan.
Anti-passback is effective during the defined time.
- Step 4 In entry group, click **Add**, and then select the card reader.
- Step 5 In exit group, click **Add**, and then select the card reader.

Figure 3-18 Anti-passback

Enable ☒

Reset Time min (5-300)

Time Templates

General Plan Holiday Plan

Anti-passback Group Config?

Entry Group

+ Add

Clear

/Reader 1

Remove

Exit Group

+ Add

Clear

/Reader 2


Remove

- Step 6 Click **Apply**.

Results

The group number indicates the sequence of swiping cards. Card must be used following the specific sequence of groups. For example, you must swipe card at a reader in entry group, and then at a reader for exit group. As long as you swipe card following the established sequence, the system works fine.

Figure 3-19 Anti-passback function



3.6 Access Monitoring


Log in to the webpage, select **Access Monitoring**, and all the connected doors are displayed.

Operations to control the door

- Click **Open** or **Close** to remotely control the door.
- Click **Always Open** or **Always Closed** to remotely control the door.

The door will remain open or closed all the time. You can click **Normal** to restore access control to its normal status, and the door will be open or closed based on the configured verification methods.

Figure 3-20 Operations to control the door



Event information



In the **Event Info** area, select the event type to view the events. Click  to clear all the events.

Figure 3-21 Event information

Event Info ☒ Select All ☒ Alarm ☒ Abnormal ☒ Normal 

Time	Camera Name	Event Info	Description
2024-07-30 00:32:00	Door1	Alarm	Unlock Timeout Alarm
2024-07-30 00:32:00	Door1	Alarm	Unlock Timeout Alarm

Details

The details of the Device are displayed. You can view the IP address, device type and the device model here.

3.7 Communication Settings

3.7.1 Network Settings

3.7.1.1 Configuring TCP/IP

You need to configure IP address of Device to make sure that it can communicate with other devices.

Procedure


- Step 1 Select **Communication Settings** > **Network Setting** > **TCP/IP**.
- Step 2 Configure the parameters.

Figure 3-22 TCP/IP

The image shows a TCP/IP configuration window. At the top, there's a 'NIC' dropdown menu set to 'NIC 1'. Below it, the 'Mode' is set to 'Static' (indicated by a blue dot next to the 'Static' radio button). The 'MAC Address' field is a text box with a light gray background. The 'IP Version' dropdown is set to 'IPv4'. Below this are four text boxes for 'IP Address', 'Subnet Mask', 'Default Gateway', and 'Preferred DNS', each with a light gray background. Below these is another text box for 'Alternate DNS' with a light gray background. At the bottom, there's an 'MTU' field with the value '1500'. At the very bottom, there are three buttons: 'Apply' (blue), 'Refresh' (light gray), and 'Default' (light gray).

Table 3-10 Description of TCP/IP

Parameter	Description
Mode	<ul style="list-style-type: none"> • Static: Manually enter IP address, subnet mask, and gateway. • DHCP: It stands for Dynamic Host Configuration Protocol. When DHCP is turned on, the Device will automatically be assigned with IP address, subnet mask, and gateway.
MAC Address	MAC address of the Device.
IP Version	IPv4 or IPv6.

Parameter	Description
IP Address	If you set the mode to Static , configure the IP address, subnet mask and gateway.
Subnet Mask	
Default Gateway	
	 <ul style="list-style-type: none"> • IPv6 address is represented in hexadecimal. • IPv6 version do not require setting subnet masks. • The IP address and default gateway must be in the same network segment.
Preferred DNS	Set IP address of the preferred DNS server.
Alternate DNS	Set IP address of the alternate DNS server.
MTU	<p>MTU (Maximum Transmission Unit) refers to the maximum size of data that can be transmitted in a single network packet in computer networks. A larger MTU value can improve network transmission efficiency by reducing the number of packets and associated network overhead. If a device along the network path is unable to handle packets of a specific size, it can result in packet fragmentation or transmission errors. In Ethernet networks, the common MTU value is 1500 bytes. However, in certain cases such as using PPPoE or VPN, smaller MTU values may be required to accommodate the requirements of specific network protocols or services. The following are recommended MTU values for reference:</p> <ul style="list-style-type: none"> • 1500: Maximum value for Ethernet packets, also the default value. This is a typical setting for network connections without PPPoE and VPN, some routers, network adapters, and switches. • 1492: Optimal value for PPPoE • 1468: Optimal value for DHCP. • 1450: Optimal value for VPN.

Step 3 Click **OK**.

3.7.1.2 Configuring Wi-Fi



- The Wi-Fi function is available on select models.
- The Wi-Fi and Wi-Fi AP cannot be enabled at the same time.


Procedure

Step 1 Select **Communication Settings** > **Network Setting** > **Wi-Fi**.

Step 2 Turn on Wi-Fi.

All available Wi-Fi are displayed.

Figure 3-23 Wi-Fi



The image shows a Wi-Fi configuration interface. At the top, there is a toggle switch for 'Wi-Fi' which is currently turned off. Below it, the 'Mode' is set to 'Static' (selected with a radio button) over 'DHCP'. There are input fields for 'IP Address', 'Subnet Mask', and 'Default Gateway', each with a small grid icon for selection. Below these fields are 'Apply' and 'Refresh' buttons. At the bottom, there is a table with four columns: 'Name', 'Signal Strength', 'Status', and 'Connect'. The table is currently empty, showing a 'No Data' message in the center.



- Wi-Fi and Wi-Fi AP cannot be enabled at the same time.
- Wi-Fi function is only available on select models.

Step 3 Click +, and then enter the password of the Wi-Fi.

The Wi-Fi is connected.

Related Operations

- DHCP: Enabled this function and click **Apply**, the Device will automatically be assigned a Wi-Fi address.
- Static: Enable this function, manually enter a Wi-Fi address, and then click **Apply**, the Device will connect to the Wi-Fi.

3.7.1.3 Configuring Wi-Fi AP




- The Wi-Fi function is available on select models.
- The Wi-Fi and Wi-Fi AP cannot be enabled at the same time.

Procedure

Step 1 Select **Communication Settings** > **Network Setting** > **Wi-Fi AP**.

Step 2 Enable the function, and then click **Apply**.

Figure 3-24 Wi-Fi AP

The image shows a web-based configuration interface for a Wi-Fi Access Point (AP). It features a toggle switch for 'Enable', which is currently turned off. Below this are input fields for 'SSID' (containing a masked string), 'Security' (a dropdown menu set to 'None'), and 'IP Address' (containing a masked IP address). A large QR code is displayed in the center of the interface. At the bottom, there are three buttons: 'Apply' (highlighted in blue), 'Refresh', and 'Default'.

Results

After enabled, you can connect to the Device Wi-Fi through your phone, and log in to the webpage of the Device on your phone.

3.7.1.4 Configuring Port

You can limit access to the Device at the same time through webpage, desktop client and mobile client.

Procedure

- Step 1 Select **Communication Settings** > **Network Setting** > **Port**.
- Step 2 Configure the ports.

Figure 3-25 Configure ports

Max Connection	<input type="text" value="50"/>	(1-50)
TCP Port	<input type="text" value="37777"/>	(1025-65535)
HTTP Port	<input type="text" value="80"/>	
HTTPS Port	<input type="text" value="443"/>	
<input type="button" value="Apply"/> <input type="button" value="Refresh"/> <input type="button" value="Default"/>		



You need to restart the Device to make the configurations effective after you configure parameters.

Table 3-11 Description of ports

Parameter	Description
Max Connection	You can set the maximum number of clients (such as webpage, desktop client and mobile client) that can access the Device at the same time.
TCP Port	Default value is 37777.
HTTP Port	Default value is 80. If you have changed the port number, add the port number after the IP address when access the webpage.
HTTPS Port	Default value is 443.

Step 3 Click **Apply**.

3.7.1.5 Configuring Basic Service


When you want to connect the Device to a third-party platform, turn on the CGI and ONVIF functions.

Procedure

Step 1 Select **Communication Settings** > **Network Settings** > **Basic Services**.

Step 2 Configure the basic service.

Figure 3-26 Basic service



SSH ☒

Multicast/Broadcast Search ☒

CGI ☒

ONVIF ☒

Emergency Maintenance ☐

i For easy access to our after-sales service, enable this function. If the device has any trouble performing functions, such as updating, the system will automatically enable this function.

Private Protocol Authentication Mode Security Mode (Recommended) ▾

Private Protocol ☒

*Before enabling private protocol TLS, make sure that the corresponding device or software supports this function.


TLSv1.1 ☐

LLDP ☐

Apply Refresh Default

Table 3-12 Basic service parameter description

Parameter	Description
SSH	SSH, or Secure Shell Protocol, is a remote administration protocol that allows users to access, control, and modify their remote servers over the internet.
Mutlicast/Broadcast Search	Search for devices through multicast or broadcast protocol.
CGI	The Common Gateway Interface (CGI) is an intersection between web servers through which the standardized data exchange between external applications and servers is possible.
ONVIF	ONVIF stands for Open Network Video Interface Forum. Its aim is to provide a standard for the interface between different IP-based security devices. These standardized ONVIF specifications are like a common language that all devices can use to communicate.
Emergency Maintenance	It is turned on by default.
Private Protocol Authentication Mode	<p>Set the authentication mode, including safe mode and compatibility mode. It is recommended to choose Security Mode.</p> <ul style="list-style-type: none"> Security Mode (recommended): Does not support accessing the device through Digest, DES, and plaintext authentication methods, improving device security. Compatible Mode: Supports accessing the device through Digest, DES, and plaintext authentication methods, with reduced security.
Private Protocol	The platform adds devices through private protocol.

Parameter	Description
TLSv1.1	<p>TLSv1.1 refers to Transport Layer Security version 1.1. TLS is a cryptographic protocol designed to provide secure and authenticated communication over a computer network.</p>  <p>Security risks might present when TLSv1.1 is enabled. Please be advised.</p>
LLDP	<p>LLDP is the abbreviation for Link Layer Discovery Protocol, which is a data link layer protocol. It allows network devices, such as switches, routers, or servers, to exchange information about their identities and capabilities with each other. The LLDP protocol helps network administrators gain a better understanding of network topology and provides a standardized way to automate the discovery and mapping of connections between network devices. This makes it easier to perform network configuration, troubleshoot issues, and optimize performance.</p>

Step 3 Click **Apply**.

3.7.1.6 Configuring Cloud Service

The cloud service provides a NAT penetration service. Users can manage multiple devices through DMSS. You do not have to apply for dynamic domain name, configure port mapping or deploy server.

Procedure

Step 1 On the home page, select **Communication Settings > Network Setting > Cloud Service**.

Step 2 Turn on the cloud service function.

The cloud service goes online if the P2P and PaaS are online.

Figure 3-27 Cloud service


Enable ☒

After the function is enabled and the device connects to the network, we will collect device information such as the IP address, MAC address, device name and serial number. The collected information will only be used to remotely access the device. If you do not want to enable this function, please clear the selection from the check box.

P2P Status ● Offline

PaaS Status ● Offline

SN 8[REDACTED]759



Apply

Refresh

Step 3 Click **Apply**.

Step 4 Scan the QR code with DMSS to add the device.

3.7.1.7 Configuring Auto Registration

The auto registration enables the devices to be added to the management platform without manual input of device information such as IP address and port.

Background Information

The auto registration only supports SDK.

Procedure

Step 1 On the home page, select **Network Setting** > **Auto Registration**.

Step 2 Enable the auto registration function and configure the parameters.

43

Figure 3-28 Auto Registration

Table 3-13 Automatic registration description

Parameter	Description
Status	Displays the connection status of auto registration.
Server Address	The IP address or the domain name of the server.
Port	The port of the server that is used for automatic registration.
Registration ID	The registration ID (user defined) of the device. Adding the device to the management by entering the registration ID on the platform.

Step 3 Click **Apply**.

3.7.1.8 Configuring CGI Auto Registration

Connect to a third-party platform through CGI protocol.

Background Information



Only supports IPv4.

Procedure

Step 1 On the home page, select **Communication Settings** > **Network Settings** > **CGI Auto Registration**.


Step 2 Enable this function, and then click  to configure the parameters.

Table 3-14 Automatic registration description

Parameter	Description
Device ID	Supports up to 32 bytes, including Chinese, numbers, letters, and special characters.
Address Type	Supports 2 methods to register. <ul style="list-style-type: none"> Host IP: Enter the IP address of the third-party platform. Domain Name: Enter the domain name of the third-party platform.
Host IP	
Domain Name	
HTTPS	Access the third-party platform through HTTPS. HTTPS secures communication over a computer network.

Step 3 Click **OK**.

3.7.1.9 Configuring Auto Upload

Send user information and unlock records through to the management platform.

Procedure

Step 1 On the home page, select **Communication Settings** > **Network Settings** > **Auto Upload**.

Step 2 (Optional) Enable **Push Person Info**.

When the user information is updated or new users are added, the Device will automatically push user information to the management platform.


Step 3 Enable HTTP upload mode.

Step 4 Click **Add**, and then configure parameters.

Figure 3-29 Automatic upload

Table 3-15 Parameters description

Parameter	Description
IP/Domain Name	The IP or domain name of the management platform.
Port	The port of the management platform.
HTTPS	Access the management platform through HTTPS. HTTPS secures communication over a computer network.
Authentication	Enable account authentication when you access the management platform. Login username and password are required.

Parameter	Description
Event Type	<p>Select the type of event that will be pushed to the management platform.</p> <p></p> <ul style="list-style-type: none"> • Before you use this function, enable Push Person Info. • Person information can only be pushed to one management platform and unlock records can be pushed to multiple management platforms.

Step 5 Click **Apply**.

3.7.2 Configuring RS-485


Configure the RS-485 parameters if you connect an external device to the RS-485 port.

Procedure

Step 1 Select **Communication Settings** > **RS-485 Settings**.

Step 2 Configure the parameters.

Figure 3-30 Configure parameters



External Device	Access Controller	<input checked="" type="radio"/> Authentication by Local Device <input type="radio"/> Authentication by Controller
Baud Rate	9600	
Data Bit	8	
Stop Bit	1	
Parity Code	None	
Output Data Type	Card Number	

Table 3-16 Description of RS-485 parameters

Parameter	Description
External Device	<ul style="list-style-type: none"> ● Access Controller Select Access Controller when the Device functions as a card reader, and sends data to other external access controllers to control access. <ul style="list-style-type: none"> ◇ Authentication by Local Device : The identity is verified on both the Device and the controller. ◇ Authentication by Controller : The identity is verified only on the controller. ● Card Reader: The Device functions as an access controller, and connects to an external card reader. ● Reader (OSDP): The Device is connected to a card reader based on OSDP protocol. ● Door Control Security: The door exit button, lock and fire linkage is not effective after the security module is enabled.
Baud Rate	Select the baud rate. It is 9600 by default.
Data Bit	The number of bits used to transmit the actual data in a serial communication. It represents the binary digits that carry the information being transmitted.
Stop Bit	A bit sent after the data and optional parity bits to indicate the end of a data transmission. It allows the receiver to prepare for the next byte of data and provides synchronization in the communication protocol.
Parity Code	An additional bit sent after the data bits to detect transmission errors. It helps verify the integrity of the transmitted data by ensuring a specific number of logical high or low bits.
Output Data Type	<p>When you configure the external device as Access Controller.</p> <ul style="list-style-type: none"> ● Card Number: Outputs data based on card number when users swipe card to unlock door; outputs data based on user's first card number when they use other unlock methods. ● No.: Outputs data based on the user ID.

Step 3 Click **Apply**.

3.7.3 Configuring Wiegand

Supports access Wiegand devices. Configure the mode and the transmission mode according to your actual devices.

Procedure

Step 1 Select **Communication Settings** > **Wiegand**.

Step 2 Select a Wiegand type, and then configure parameters.

- Select **Wiegand Input** when you connect an external card reader to the Device.



When the Device connects to a third-party device through the Wiegand input port, and the card number read by the Device is in the reverse order from the actual card number. In this case, you can turn on **Card No. Inversion** function.

- Select **Wiegand Output** when the Device functions as a card reader, and you need to connect it to another access controller.

Figure 3-31 Wiegand output

Wiegand

☐ Wiegand Input ☒ Wiegand Output

Wiegand Output Type

Wiegand34

Pulse Width (μs)

200

(20-200)

Pulse Interval (μs)

1000

(200-5000)

The pulse width is a multiple of 10 and has a multiple relationship with the pulse interval.

Output Data Type

☒ Card Number ☐ No.

Apply

Refresh

Default

Table 3-17 Description of Wiegand output

Parameter	Description
Wiegand Output Type	Select a Wiegand format to read card numbers or ID numbers. <ul style="list-style-type: none">• Wiegand26 : Reads 3 bytes or 6 digits.• Wiegand34 : Reads 4 bytes or 8 digits.• Wiegand66 : Reads 8 bytes or 16 digits.
Pulse Width	Enter the pulse width and pulse interval of Wiegand output.
Pulse Interval	
Output Data Type	Select the type of output data. <ul style="list-style-type: none">• No. : Outputs data based on user ID. The data format is hexadecimal or decimal.• Card Number : Outputs data based on user's first card number.

Step 3 Click **Apply**.

3.8 Configuring the System

3.8.1 User Management

You can add or delete users, change user passwords, and enter an email address for resetting the password when you forget your password.

3.8.1.1 Adding Administrators

You can add new administrator accounts, and then they can log in to the webpage of the Device.

Procedure

Step 1 On the home page, select **System** > **Account** > **Account**.

Step 2 Click **Add**, and enter the user information.



- The username cannot be the same with existing account. The username consists of up to 31 characters and only allows for numbers, letters, underscores, midlines, dots, or @.
- The password must consist of 8 to 32 non-blank characters and contain at least two types of the following characters: Upper case, lower case, numbers, and special characters (excluding ' " ; : &).

Set a high-security password by following the password strength prompt.

Figure 3-32 Add administrators

The screenshot shows a web-based 'Add' dialog box. It has a title bar with the text 'Add' and a close button (X). The main area contains four input fields: 'Username' (with a red asterisk), 'Password' (with a red asterisk), 'Confirm Password' (with a red asterisk), and 'Remarks'. Below the 'Password' field is a blue progress bar indicating password strength. At the bottom right are 'OK' and 'Cancel' buttons.

Step 3 Click **OK**.



Only admin account can change password and admin account cannot be deleted.

3.8.1.2 Adding ONVIF Users

Background Information

Open Network Video Interface Forum (ONVIF), a global and open industry forum that is established for the development of a global open standard for the interface of physical IP-based security products, which allows the compatibility from different manufactures. ONVIF users have their identities verified through ONVIF protocol. The default ONVIF user is admin.

Procedure

Step 1 On the home page, select **System** > **Account** > **ONVIF User**.

Step 2 Click **Add**, and then configure parameters.

Figure 3-33 Add ONVIF user

The screenshot shows a web-based 'Add' dialog box. It has a title bar with the word 'Add' and a close button (X). The main area contains four labeled input fields, each with a red asterisk indicating it is required: 'Username', 'Password', 'Confirm Password', and 'Group'. The 'Group' field is a dropdown menu. At the bottom right of the dialog are two buttons: 'OK' (blue) and 'Cancel' (white with a grey border).

Table 3-18 ONVIF user description

Parameter	Description
Username	The username cannot be the same with existing account. The username consists of up to 31 characters and only allows for numbers, letters, underscores, midlines, dots, or @.
Password	The password must consist of 8 to 32 non-blank characters and contain at least two types of the following characters: Upper case, lower case, numbers, and special characters (excluding ' " ; : &).

Parameter	Description
Group	<p>There three permission groups which represents different permission levels.</p> <ul style="list-style-type: none"> • admin: You can view and manage other user accounts on the ONVIF Device Manager. • Operator: You cannot view or manage other user accounts on the ONVIF Device Manager. • User: You cannot view or manage other user accounts and system logs on the ONVIF Device Manager.

Step 3 Click **OK**.

3.8.1.3 Resetting the Password

Reset the password through the linked e-mail when you forget your password.

Procedure

Step 1 Select **System** > **Account** > **Account**.

Step 2 Enter the email address, and set the password expiration time.

Step 3 Turn on the password reset function.

Figure 3-34 Reset Password



If you forgot the password, you can receive security codes through the linked email address to reset the password.

Step 4 Click **Apply**.

3.8.2 Viewing Online Users

You can view online users who currently log in to the webpage. On the home page, select **System** > **Online User**.

3.8.3 Configuring Time

Procedure


Step 1 Log in to the webpage.

Step 2 Select **System** > **Time**.

Step 3 Configure the time of the Platform.

Figure 3-35 Time settings

Time and Time Zone



Date :

2024-08-05 Monday

Time :

18:50:31


Time

☒ Manually Set

☐ NTP

System Time


2024-08-05 18:50:31




Sync PC

Time Format

YYYY-MM-DD




24-Hour



Time Zone

(UTC+09:30)



DST

Enable

☐

Type

☒ Date

☐ Week

Start Time

Jan



1



00:00



End Time

Jan



2



00:00



Apply

Refresh

Default

Table 3-19 Time settings description

Parameter	Description
Time	<ul style="list-style-type: none">Manual Set: Manually enter the time or you can click Sync PC to sync time with computer.NTP: The Device will automatically sync the time with the NTP server.<ul style="list-style-type: none">Server : Enter the domain of the NTP server.Port : Enter the port of the NTP server.Interval : Enter its time with the synchronization interval.
Time Format	Select the time format.
Time Zone	Select the time zone.

Parameter	Description
DST	<ol style="list-style-type: none"> 1. (Optional) Enable DST. 2. Select Date or Week from the Type. 3. Configure the start time and end time of the DST.

Step 4 Click **Apply**.

3.9 Maintenance Center

3.9.1 One-click Diagnosis

The system automatically diagnoses the configurations and the status of the device to improve its performance.

Procedure

Step 1 On the home page, select **Maintenance Center** > **One-click Diagnosis**.


Step 2 Click **Diagnose**.

The system automatically diagnoses the configurations and the status of the device and display diagnosis results after it completes.

Step 3 (Optional) Click **Details** to view details of abnormal items.

You can ignore the abnormality or optimize it. You can also click **Diagnose Again** to perform automatic diagnosis again.

Figure 3-36 One-click diagnosis



3.9.2 System Information

3.9.2.1 Viewing Version Information

On the webpage, select **Maintenance Center** > **System Info** > **Version**, and you can view version information of the Device.

3.9.2.2 Viewing Legal Information

On the home page, select **Maintenance Center** > **System Info** > **Legal Info**, and you can view the software license agreement, privacy policy and open source software notice.

3.9.3 Data Capacity

You can see how many users, and cards that the Device can store.

Log in to the webpage and select **Maintenance Center** > **Data Capacity**.

3.9.4 Viewing Logs

View logs such as system logs, admin logs, and unlock records.


3.9.4.1 System Logs

View and search for system logs.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **Maintenance Center** > **Log** > **Log**.
- Step 3 Select the time range and the log type, and then click **Search**.

Related Operations

- click **Export** to export the searched logs to your local computer.
- Click **Encrypt Log Backup**, and then enter a password. The exported file can be opened only after entering the password.
- Click  to view details of a log.

3.9.4.2 Unlock Records

Search for unlock records and export them.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **Maintenance Center** > **Log** > **Unlock Records**.
- Step 3 Select the time range and the type, and then click **Search**.

You can click **Export** to download the log.

3.9.4.3 Alarm Logs

View alarm logs.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **Maintenance Center** > **Log** > **Alarm Logs**.
- Step 3 Select the type and the time range.
- Step 4 Enter the admin ID, and then click **Search**.

3.9.4.4 Admin Logs

Search for admin logs by using admin ID.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **Maintenance Center > Log > Admin Logs**.
- Step 3 Enter the admin ID, and then click **Search**.
Click **Export** to export admin logs.

3.9.5 Maintenance Management

When more than one Device need the same configurations, you can configure parameters for them by importing or exporting configuration files.

3.9.5.1 Exporting and Importing Configuration Files

You can import and export the configuration file for the Device. When you want to apply the same configurations to multiple devices, you can import the configuration file to them.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **Maintenance Center > Maintenance Management > Config**.

Figure 3-37 Configuration management

- Step 3 Export or import configuration files.

- Export the configuration file.
Click **Export Configuration File** to download the file to the local computer.



The IP will not be exported.

- Import the configuration file.
 1. Click **Browse** to select the configuration file.
 2. Click **Import configuration**.



Configuration files can only be imported to devices that have the same model.

3.9.5.2 Configuring the Fingerprint Similarity Threshold

Configure the fingerprint similarity threshold. The higher the value is, the higher accuracy is, and the lower the pass rate.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **Maintenance Center > Maintenance Management > Config.**
- Step 3 Enter the similarity threshold, and then click **Apply**.



- The parameter is available on the modular access controller with the fingerprint module.
- The parameter is available on the access controller with fingerprint function.

Figure 3-38 Fingerprint similarity threshold

3.9.5.3 Restoring the Factory Default Settings

Procedure

- Step 1 Select **Maintenance Center > Maintenance Management > Config.**



Restoring the **Device** to its default configurations will result in data loss. Please be advised.

- Step 2 Restore to the factory default settings if necessary.
- **Factory Defaults** : Resets all the configurations of the Device and delete all the data.
 - **Restore to Default (Except for User Info and Logs)** : Resets the configurations of the Device and deletes all the data except for user information and logs.

3.9.5.4 Maintenance

Regularly restart the Device during its idle time to improve its performance.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **Maintenance Center > Maintenance Management > Maintenance.**
- Step 3 Set the time, and then click **Apply**.

The Device will restart at the scheduled time, or you can click **Restart** to restart it immediately.

3.9.6 Updating the System



- Use the correct update file. Make sure that you get the correct update file from technical support.
- Do not disconnect the power supply or network, and do not restart or shutdown the Device during the update.
- Update to a lower version may cause potential risks. Please be advised.
- If you start the Device for the first time or restore the Device to factory default settings, the Device automatically backups the system files within the first 10 minutes. Please do not update in this period.

3.9.6.1 File Update

Procedure

- Step 1 On the home page, select **Maintenance Center** > **Update**.
- Step 2 In **File Update**, click **Browse**, and then upload the update file.



The update file should be a .bin file.

- Step 3 Click **Update**.
- The Device will restart after the update finishes.

3.9.6.2 Online Update

Procedure

- Step 1 On the home page, select **Maintenance Center** > **Update**.
- Step 2 In the **Online Update** area, select an update method.
- Select **Auto Check for Updates**, and the Device will automatically check for the latest version update.
 - Select **Manual Check**, and you can immediately check whether the latest version is available.
- Step 3 (Optional) Click **Update Now** to update the Device immediately.

3.9.7 Advanced Maintenance

Acquire device information and capture packet to make easier for maintenance personnel to perform troubleshooting.

3.9.7.1 Exporting

Procedure

- Step 1 On the home page, select **Maintenance Center** > **Advanced Maintenance** > **Export**.
- Step 2 Click **Export** to export the serial number, firmware version, device operation logs and configuration information.





3.9.7.2 Packet Capture

Procedure

- Step 1** On the home page, select **Maintenance Center > Advanced Maintenance > Packet Capture**.

Figure 3-39 Packet Capture

Packet Capture							
NIC	Device Address	IP 1: Port 1		IP 2: Port 2		Packet Sniffer Size	Packet Sniffer Backup
eth0	1 166	Optional	Optional	Optional	Optional	0.00MB	▶
eth2	1 101	Optional	Optional	Optional	Optional	0.00MB	▶

- Step 2** Enter the IP address, click .
-  changes to .
- Step 3** After you acquired enough data, click .
- Captured packets are automatically downloaded to your local computer.

3.10 Security Settings(Optional)


3.10.1 Security Status

Scan the users, service, and security modules to check the security status of the Device.

Background Information

- User and service detection: Check whether the current configuration conforms to recommendation.
- Security modules scanning: Scan the running status of security modules, such as audio and video transmission, trusted protection, securing warning and attack defense, not detect whether they are enabled.


Procedure

- Step 1** Select  > **Security Status**.
- Step 2** Click **Rescan** to perform a security scan of the Device.



Hover over the icons of the security modules to see their running status.

Figure 3-40 Security Status



Related Operations

After you perform the scan, the results will be displayed in different colors. Yellow indicates that the security modules are abnormal, and green indicates that the security modules are normal.

- Click **Details** to view the details on the results of the scan.
- Click **Ignore** to ignore the abnormality, and it will not be scanned. The abnormality that was ignored will be highlighted in grey.
- Click **Optimize** to troubleshoot the abnormality.

3.10.2 Configuring System Service

Create a certificate or upload an authenticated certificate, and then you can log in to the webpage through HTTPS on your computer. HTTPS secures communication over a computer network.

Procedure

Step 1 Select  > **System Service** > **System Service**.

Step 2 Turn on the HTTPS service.



If you turn on the compatible with TLS v1.1 and earlier versions, security risks might occur. Please be advised.

Step 3 Select the certificate.



If there are no certificates in the list, click **Certificate Management** to upload a certificate.

Figure 3-41 System service

Step 4 Click **Apply**.

Enter "https://IP address: httpsport" in a web browser. If the certificate is installed, you can log in to the webpage successfully. If not, the webpage will display the certificate as wrong or untrusted.

3.10.3 Attack Defense

3.10.3.1 Configuring Firewall

Configure firewall to limit access to the Device.

Procedure

Step 1 Select > **Attack Defense** > **Firewall**.

Step 2 Click to enable the firewall function.


Figure 3-42 Firewall

Step 3 Select the mode: **Allowlist** and **Blocklist**.

- **Allowlist** : Only IP/MAC addresses on the allowlist can access the Device.
- **Blocklist** : The IP/MAC addresses on the blocklist cannot access the Device.

Step 4 Click **Add** to enter the IP information.

Figure 3-43 Add IP information

A dialog box titled "Add" with a close button (X) in the top right corner. It contains four fields: "Add Mode" with a dropdown menu showing "IP", "IP Version" with a dropdown menu showing "IPv4", "IP Address" with a text input field containing three dots, and "All Device Ports" with a blue toggle switch. At the bottom right, there are "OK" and "Cancel" buttons.

Add

Add Mode IP

IP Version IPv4



IP Address . . .

All Device Ports ☒

OK Cancel

Step 5 Click **OK**.

Related Operations

- Click  to edit the IP information.
- Click  to delete the IP address.

3.10.3.2 Configuring Account Lockout

If the incorrect password is entered for a defined number of times, the account will be locked.

Procedure

Step 1 Select  > **Attack Defense** > **Account Lockout**.

Step 2 Enter the number of login attempts and the time the administrator account and ONVIF user will be locked for.

Figure 3-44 Account lockout

Firewall **Account Lockout** Anti-DoS Attack

Device Account

Login Attempt 5time(s) ▼

Lock Time 5 min

Apply Refresh Default

- Login Attempt: The limit of login attempts. If the incorrect password is entered for a defined number of times, the account will be locked.
- Lock Time: The duration during which you cannot log in after the account is locked.

Step 3 Click **Apply**.

3.10.3.3 Configuring Anti-DoS Attack

You can enable **SYN Flood Attack Defense** and **ICMP Flood Attack Defense** to defend the Device against Dos attacks.

Procedure



- Step 1 Select  > **Attack Defense** > **Anti-DoS Attack**.
- Step 2 Turn on **SYN Flood Attack Defense** or **ICMP Flood Attack Defense** to protect the Device against Dos attack.

Figure 3-45 Anti-DoS attack



Firewall Account Lockout **Anti-DoS Attack**

SYN Flood Attack D... ☒

An attacker might send out repeated SYN messages to the device, leaving many half-open TCP connections on the device, which will make the device crash. When hit by an SYN flood attack, the device will defend itself by discarding the first message.

ICMP Flood Attack ... ☒

An attacker might send out an abnormally large number of ICMP packets to the device, which will use up all computing resources and thus make the device crash. When hit by an ICMP flood attack, the device will defend itself by using the ICMP message filtering tactic.

Apply Refresh Default

Step 3 Click **Apply**.

3.10.4 Installing Device Certificate

Create a certificate or upload an authenticated certificate, and then you can log in through HTTPS on your computer.

3.10.4.1 Creating Certificate

Create a certificate for the Device.

Procedure



- Step 1 Select  > **CA Certificate** > **Device Certificate**.
- Step 2 Select **Install Device Certificate**.
- Step 3 Select **Create Certificate**, and click **Next**.
- Step 4 Enter the certificate information.

Figure 3-46 Certificate information



The name of region cannot exceed 2 characters. We recommend entering the abbreviation of the name of the region.

Step 5 Click **Create and install certificate**.

The newly installed certificate is displayed on the **Device Certificate** page after the certificate is successfully installed.


Related Operations

- Click **Enter Edit Mode** on the **Device Certificate** page to edit the name of the certificate.
- Click  to download the certificate.
- Click  to delete the certificate.

3.10.4.2 Applying for and Importing CA Certificate

Import the third-party CA certificate to the Device.

Procedure

- Step 1** Select  > **CA Certificate** > **Device Certificate**.
- Step 2** Click **Install Device Certificate**.
- Step 3** Select **Apply for CA Certificate and Import (Recommended)**, and click **Next**.
- Step 4** Enter the certificate information.
 - IP/Domain name: the IP address or domain name of the Device.

- **Region:** The name of region must not exceed 3 characters. We recommend you enter the abbreviation of region name.

Figure 3-47 Certificate information (2)

Step 2: Fill in certificate information.

* IP/Domain Name: 172.16.0.03

Organization Unit:

Organization:

* Region:

Province:

City Name:

Back Create and Download Cancel

Step 5 Click **Create and Download**.

Save the request file to your computer.

Step 6 Apply to a third-party CA authority for the certificate by using the request file.

Step 7 Import the signed CA certificate.

1. Save the CA certificate to your computer.
2. Click **Installing Device Certificate**.
3. Click **Browse** to select the CA certificate.
4. Click **Import and Install**.

The newly installed certificate is displayed on the **Device Certificate** page after the certificate is successfully installed.

- Click **Recreate** to create the request file again.
- Click **Import Later** to import the certificate at another time.

Related Operations

- Click **Enter Edit Mode** on the **Device Certificate** page to edit the name of the certificate.
- Click  to download the certificate.
- Click  to delete the certificate.

3.10.4.3 Installing Existing Certificate

If you already have a certificate and private key file, import the certificate and private key file.

Procedure

Step 1 Select **Security** > **CA Certificate** > **Device Certificate**.

- Step 2 Click **Install Device Certificate**.
- Step 3 Select **Install Existing Certificate**, and click **Next**.
- Step 4 Click **Browse** to select the certificate and private key file, and enter the private key password.

Figure 3-48 Certificate and private key

- Step 5 Click **Import and Install**.

The newly installed certificate is displayed on the **Device Certificate** page after the certificate is successfully installed.

Related Operations

- Click **Enter Edit Mode** on the **Device Certificate** page to edit the name of the certificate.
- Click  to download the certificate.
- Click  to delete the certificate.

3.10.5 Installing the Trusted CA Certificate

A trusted CA certificate is a digital certificate that is used for validating the identities of websites and servers. For example, when 802.1x protocol is used, the CA certificate for switches is required to authenticate its identity.

Background Information

802.1X is a network authentication protocol that opens ports for network access when an organization authenticates a user's identity and authorizes them access to the network.

Procedure



- Step 1 Select  > **CA Certificate** > **Trusted CA Certificates**.
- Step 2 Select **Install Trusted Certificate**.
- Step 3 Click **Browse** to select the trusted certificate.

Figure 3-49 Install the trusted certificate

A dialog box titled "Install Trusted Certificate" with a close button (X) in the top right corner. It contains two input fields: "Custom Name" and "Certificate Path". Below the "Certificate Path" field is a "Browse" button. At the bottom right are "OK" and "Cancel" buttons.

Install Trusted Certificate

Custom Name

Certificate Path

Step 4 Click **OK**.


The newly installed certificate is displayed on the **Trusted CA Certificates** page after the certificate is successfully installed.

Related Operations

- Click **Enter Edit Mode** on the **Device Certificate** page to edit the name of the certificate.
- Click  to download the certificate.
- Click  to delete the certificate.

3.10.6 Security Warning


Procedure

Step 1 Select  > **Security Warning**.

Step 2 Enable the security warning function.

Step 3 Select the monitoring items.

Figure 3-50 Security warning

A configuration page for "Security Warning". At the top, there is an "Enable" toggle switch which is turned on. Below this is a section titled "Event Monitoring" containing a list of six items, each with a checked checkbox: "Invalid executable programs attempting to run", "Web directory bruteforcing", "Number of session connections exceeds limit", "Session ID bruteforcing", "Login not in the specified time range.", and "Brute force attack of the account.". A light blue informational box at the bottom states: "Security warning can detect device security status in real time, and keep you informed of the security exception events immediately, so that you can deal with them timely and avoid security risks." At the very bottom are three buttons: "Apply", "Refresh", and "Default".

Enable ☒

Event Monitoring

<input checked="" type="checkbox"/> Invalid executable programs attempting to run	<input checked="" type="checkbox"/> Session ID bruteforcing
<input checked="" type="checkbox"/> Web directory bruteforcing	<input checked="" type="checkbox"/> Login not in the specified time range.
<input checked="" type="checkbox"/> Number of session connections exceeds limit	<input checked="" type="checkbox"/> Brute force attack of the account.

Security warning can detect device security status in real time, and keep you informed of the security exception events immediately, so that you can deal with them timely and avoid security risks.


Step 4 Click **Apply**.

3.10.7 Security Authentication

Procedure

- Step 1 Select **Security** > **Security Authentication**.
- Step 2 Select a message digest algorithm.
- Step 3 Click **Apply**.

Figure 3-51 Security authentication



Digest Algorithm for Authentication

Digest Algorithm for User Authentication ☒ MD5 ☐ SHA256

Digest Algorithm for ONVIF User Authentication ☒ MD5 ☐ SHA256

Apply Refresh Default

4 Phone Operations

Before logging in to the webpage of the Device on your phone, make sure that you have initialized the Device through the webpage on the computer.

We recommend you use your phone in portrait mode and day mode. You can log in to the webpage of the Device on your phone through the following methods.

- Connect the Device to the network through the network cable. Make sure the phone and the Device are in the same network. Open the browser on the phone, and then enter the IP address of the Device.
- Connect the Device and the phone to the network through the same Wi-Fi. Open the browser on the phone, and then enter the IP address according to the connected Wi-Fi.
- Connect the phone to the network through the Device Wi-Fi. Open the browser on the phone, and then enter the IP address according to the Wi-Fi AP on the Device (it is 192.168.3.1 by default).



The Device Wi-Fi name is displayed in the **Device serial number + Device model** mode.



- The Wi-Fi and Wi-Fi AP are available on select models.
- Only English is supported when you log in to the webpage on the phone.

4.1 Initialization

When the phone is on the same LAN as the Access Controller, you can initialize the Access Controller for the first time or after the Device is restored to the factory defaults on the webpage of the phone.

Prerequisites

Make sure that the Access Controller is not connected to Wi-Fi or 4G network.

There are mainly 3 ways to connect the Device and the phone to the same network. This section introduces initialization on the phone through Wi-Fi AP.

- Connect the Device to the network through the network cable. Make sure the phone and the Device are on the same network. Open the browser on the phone, and then enter the IP address of the Device.
- Connect the Device and the phone to the network through the same Wi-Fi. Open the browser on the phone, and then enter the IP address according to the connected Wi-Fi.
- Connect the phone to the network through the Device Wi-Fi. Open the browser on the phone, and then enter the IP address according to the Wi-Fi AP on the Device (it is 192.168.3.1 by default).



The Wi-Fi and Wi-Fi AP are available on select models.

Procedure

Step 1 Power on the Access Controller.

Step 2 Connect to the Wi-Fi hotspot on your phone. The hotspot name is **product serial number + device model**.

If you have not connected to the Wi-Fi hotspot within 30 minutes, the hotspot is off.

Step 3 Open a browser on your phone, and go to the IP address (the default address is 192.168.3.1) of the hotspot.

Step 4 Tap **Starting initialization**.

Step 5 Enter and confirm the password, enter an email address.



- The password must consist of 8 to 32 non-blank characters and contain at least two types of the following characters: upper case, lower case, numbers, and special characters (excluding ' " ; &). Set a high-security password by following the password strength prompt.
- Keep the password safe after initialization and change the password regularly to improve security.

Step 6 (Optional) Enable the e-mail address, and then configure the address.



If you want to reset the administrator password by scanning the QR code, you need to enable the e-mail function and configure the e-mail address to receive the security code.

Step 7 (Optional) Select **I have read and agree Software License Agreement Privacy Policy**.

Step 8 Tap **Next**.

Step 9 Enable **Auto Check for Updates** as needed, and then tap **Completed**.

The login page is displayed.

4.2 Logging in to the Webpage

Prerequisites

Make sure that the phone used to log in to the webpage is on the same LAN as the Device.

Procedure


Step 1 Open a browser, and then enter to the IP address of the Device.

Step 2 Enter the user name and password.



- The default administrator name is admin, and the password is the one you set up during initialization. We recommend you change the administrator password regularly to increase security.
- If you forget the administrator login password, you can reset the password through the webpage on the computer.

Figure 4-1 Login page

The login page features a light gray background with a subtle geometric pattern of overlapping planes. At the top center is a blue circular icon containing a white door symbol. Below this icon are two input fields: the first is labeled 'admin' with a user icon, and the second is labeled 'Password' with a lock icon. At the bottom center is a prominent blue 'Login' button with white text.


Step 3 Click **Login**.

4.3 Home Page

The home page is displayed after you successfully log in.


- The **Door Status** area displays the status of the door. You can remotely open or close the door. You can also configure the door status as **Always Open** or **Always Closed**.

Figure 4-2 Door status




- The **Common Function** area displays the configuration menu of the Device. Click **More** to view all the configuration menus.

Figure 4-3 Common functions



- View the serial number and the version information on the **Version** area. Click > to view the version details.

Figure 4-4 Version



4.4 Person Management

Add the person and configure the permissions.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Click **Person Management**, and then click +.
- Step 3 Configure user information.

Figure 4-5 Add the person (1)

Basic Info

* User ID

Name

Verification Mode

PasswordNot Added >

Card0 >

Fingerprint0 >

Figure 4-6 Add the person (2)

Validity Period
2037-12-31 23:59:59

General Plan255-Default



Holiday Plan255-Default



User TypeGeneral User

Times UsedUnlimited

Table 4-1 Parameters description

Parameter	Description
User ID	The User ID is like employee ID, which can be numbers, letters, and their combinations, and the maximum length of the number is 30 characters.
Name	The name can have up to 32 characters (including numbers, symbols, and letters).
Password	Configure the user password. The maximum length of the password is 8 digits. The duress password is the unlock password + 1. For example, if the user password is 12345, the duress password will be 12346. A duress alarm will be triggered when a duress password is used to unlock the door.

Parameter	Description
Card	<ul style="list-style-type: none"> Enter the card number manually. <ol style="list-style-type: none"> Click Add. Enter the card number, and then click Add. Read the number automatically through the Device. <ol style="list-style-type: none"> Click Add. Swipe cards on the card reader. <p>A 60-second countdown is displayed to remind you to swipe cards, and the system will read the card number automatically. If the 60-second countdown expires, click Read Card again to start a new countdown.</p> <ol style="list-style-type: none"> Click OK. <p>A user can register up to 5 cards at most. Enter your card number or swipe your card, and then the card information will be read by the Device.</p> <p>You can enable the Duress Card function. An alarm will be triggered if a duress card is used to unlock the door.</p> <ul style="list-style-type: none"> Duress Card : Click to set duress card. Change Card No. : Click to change the card number.  <p>One user can only set one duress card.</p>
Fingerprint	<p>Register fingerprints. A user can register up to 3 fingerprints, and you can set a fingerprint to the duress fingerprint. An alarm will be triggered when the duress fingerprint is used to unlock the door.</p> <p>Enroll fingerprints through an enrollment reader or the Device.</p> <ol style="list-style-type: none"> Click Add. Press finger on the scanner according to the on-screen instructions. Click OK.  <ul style="list-style-type: none"> Fingerprint function is only available on select models. We do not recommend you set the first fingerprint as the duress fingerprint. One user can only sets one duress fingerprint.
Permission	<ul style="list-style-type: none"> User : Users only have door access or time attendance permissions. Admin : Administrators can configure the Device besides door access and attendance permissions.
Validity Period	<p>Set a date on which the door access and attendance permissions of the person will be expired.</p>

Parameter	Description
General Plan	<p>People can unlock the door or take attendance during the defined period.</p>  <p>You can select more than one plan.</p>
Holiday Plan	<p>People can unlock the door or take attendance during the defined holiday.</p>  <p>You can select more than one holiday.</p>
User Type	<ul style="list-style-type: none"> ● General User : General users can unlock the door. ● Blocklist User : When users in the blocklist unlock the door, service personnel will receive a notification. ● Guest User : Guests can unlock the door within a defined period or for certain amount of times. After the defined period expires or the unlocking times runs out, they cannot unlock the door. ● Patrol User : Patrol users can take attendance on the Device, but they do not have door permissions. ● VIP User : When VIP unlock the door, service personnel will receive a notice. ● Other User : When they unlock the door, the door will stay unlocked for 5 more seconds. ● Custom User 1/Custom User 2: Same with general users.
Time Used	Set an unlock limit for guest users. After the unlock times run out, they cannot unlock the door.

Step 4 Click **Add**.

4.5 Configuring the System

4.5.1 Viewing Version Information

On the webpage, select **More > System > Version**, and you can view version information on the Device.

4.5.2 Maintenance


Regularly restart the Device during its idle time to improve its performance.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **More > System > Maintenance**.
- Step 3 Set the time, and then click **Apply**.

The Device will restart at the scheduled time, or you can click **Restart** to restart it immediately.

Figure 4-7 Maintenance



< Maintenance

Period Tue >

Time 02:00 >

Apply

Restart

4.5.3 Configuring Time

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **More** > **System** > **Time**.
- Step 3 Configure the time.

Figure 4-8 Configure the time parameters

<

Time

Time

Manually Set >

System Time

2024-06-25 11:13:03 >

Sync Time

Sync Phone

Date Format

YYYY-MM-DD >

Time Format

24-Hour >

Time Zone

(UTC+08:00) Beijing, >

DST

☐

Type

Date >

Start Time

01-01 00:00 >

End Time

01-02 00:00 >

Table 4-2 Time settings description

Parameter	Description
Time	<ul style="list-style-type: none">Manual Set: Manually enter the time or you can click Sync Phone to sync time with the phone.NTP: The Device will automatically sync the time with the NTP server.<ul style="list-style-type: none">Server : Enter the domain of the NTP server.Port : Enter the port of the NTP server.Interval : Enter its time with the synchronization interval.
Date Format	Select the date format and the time format.
Time Format	
Time Zone	Select the time zone.
DST	<ol style="list-style-type: none">(Optional) Enable DST.Select Date or Week as the Type.Configure the start time and end time of the DST.

Step 4 Click **Apply**.

4.5.4 Data Capacity

You can see how many users, cards, fingerprints, logs, unlock records, and other information that the Device can store.

Log in to the webpage and select **More > System > Data Capacity**.

4.6 Configuring Access Control

4.6.1 Configuring Unlock Methods

You can use multiple unlock methods to unlock the door, such as fingerprint, card, and password. You can also combine them to create your own personal unlock method.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Click **Unlock Method** on the main menu, or select **More > Access Control > Unlock Method**.
- Step 3 (Optional) Configure the combination method and the unlock method, and then click **Apply**.

- Combination method
 - ◇ Or: Use one of the selected unlock methods to open the door.
 - ◇ And: Use all the selected unlock methods to open the door.
- Unlock method

Select the unlock method according to the supported capabilities of the Device.

Figure 4-9 Unlock method

< Unlock Method

Unlock Method	Combination Unlock
Combination Method	Or >
Unlock Method	Card, Fingerprint, Password >

Apply

4.6.2 Configuring Access Control Parameters

Procedure

- Step 1 Log in to the webpage.

- Step 2 Click **Access Control Parameters** on the main menu, or select **More > Access Control > Access Control Parameters**.
- Step 3 Configure basic parameters for the access control, and then click **Apply**.

Figure 4-10 Access control parameters (1)

Access Control Parameters

Basic Settings

Name

Door1

Door Status

Normal >

Verification Interval

0 s

Normally Open Period

Period

Disabled >

Holiday Plan

Disabled >

Normally Closed Period

Period

Disabled >

Holiday Plan

Disabled >

Figure 4-11 Access control parameters (2)

Unlock Settings

Unlock Method

Combination Unlock

Combination Method

Or >

Unlock Method


Card, Fingerprint, Password >

Door Unlocked Duration

3 s

Table 4-3 Description of access control parameters

Parameter		Description
Basic Settings	Name	The name of the door.

Parameter		Description
	Door Status	<p>Set the door status.</p> <ul style="list-style-type: none"> ● Normal: The door will be unlocked and locked according to your settings. ● Always Open: The door remains unlocked all the time. ● Always Closed: The door remains locked all the time.
	Verification Interval	<p>If you verify your identity multiple times within a set period, only the earliest verification will be considered valid, and the door will not open after the second or later verifications. From the moment the door fails to open, you must wait for the configured verification time interval before attempting to verify your identity again.</p>
Normally Open Period	Period/Holiday Plan	<p>When you select Normal, you can select a time template from the drop-down list. The door remains open or closed during the defined time.</p>  <ul style="list-style-type: none"> ● When normally open period conflicts with normally closed period, normally open period takes priority over normally closed period. ● When period conflict with holiday plan, holiday plans takes priority over periods.
Normally Closed Period	Period/Holiday Plan	
Unlock Settings	Unlock Method	Combination Unlock by default.
	Combination Method	<ul style="list-style-type: none"> ● Or: Use one of the selected unlock methods to open the door. ● And: Use all the selected unlock methods to open the door.
	Unlock Method	Select the unlock method according to the supported capabilities of the Device.
	Door Unlocked Duration	Configure the time in which the door keeps the open status. It is 3 seconds by default. When the door opens for more than the configured time, the door closes.

Step 4 Click **Apply**.

4.6.3 Configuring Alarms

An alarm will be triggered when an abnormal access event occurs.

Procedure




- Step 1 Log in to the webpage.
- Step 2 Select **More** > **Access Control** > **Alarm**.
- Step 3 Configure alarm parameters, and then click **Apply**.

Figure 4-12 Alarm settings

The screenshot shows a mobile application interface for 'Alarm' settings. At the top, there is a navigation bar with a back arrow on the left and the title 'Alarm' in the center. Below the navigation bar is a list of settings, each with a label on the left and a control on the right. The settings are: 'Duress Alarm' with a blue toggle switch turned on; 'Anti-passback' with a grey toggle switch turned off; 'Door Detector' with a blue toggle switch turned on; 'Door Detector Status' with the text 'NO' and a right-pointing chevron; 'Intrusion Alarm' with a grey toggle switch turned off; 'Unlock Timeout Alarm' with a grey toggle switch turned off; 'Unlock Timeout' with the text '60 s'; and 'Excessive Use Alarm' with a blue toggle switch turned on. At the bottom of the settings list is a solid blue button with the word 'Apply' in white text.

Table 4-4 Description of alarm parameters

Parameter	Description
Duress Alarm	An alarm will be triggered when a duress card, duress password or duress fingerprint is used to unlock the door.


Parameter	Description
Anti-passback	<p>Users need to verify their identities both for entry and exit; otherwise an alarm will be triggered. It helps prevent a card holder from passing an access card back to another person to gain entry. When anti-passback is enabled, the card holder must leave the secured area through an exit reader before system will grant another entry.</p> <ul style="list-style-type: none"> ● If a person enters after authorization and exits without authorization, an alarm will be triggered when the person attempt to enter again, and access is denied at the same time. ● If a person enters without authorization and exits after authorization, an alarm will be triggered when the person attempt to enter again, and access is denied at the same time.  <p>If the Device can only connect one lock, verifying on the Device means entry direction, and verifying on the external card reader means exit direction by default. You can modify the setting on the management platform.</p>
Door Detector	<p>With the door detector wired to your device, alarm can be triggered when doors are opened or closed abnormally. The door detector includes 2 types, including NC detector and NO detector.</p> <ul style="list-style-type: none"> ● NC: The sensor is in a shorted position when the door or window is closed. ● NO: An open circuit is created when the window or door is actually closed.
Intrusion Alarm	<p>If the door is opened abnormally, an intrusion alarm will be triggered and last for a defined time.</p>  <p>The door detector and intrusion need to be enabled at the same time.</p>
Unlock Timeout Alarm	<p>When the door remains unlocked for longer than the defined timeout duration, the door timeout alarm will be triggered and last for the defined time.</p>
Unlock Timeout	 <p>The door detector and door timed out function need to be enabled at the same time.</p>
Excessive Use Alarm	<p>If the wrong password or card is used 5 times in a row within 60 seconds, the alarm for excessive use of illegal card will be triggered and last for a defined time.</p>

4.6.4 Configuring Alarm Event Linkage

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **More** > **Access Control** > **Alarm Event Linkage**.

Figure 4-13 Alarm event linkage



- Step 3 Click the linkage to configure the alarm linkage, and then click **OK**.

Table 4-5 Alarm event linkage

Parameter	Description
Intrusion Alarm Linkage	If the door is opened abnormally, an intrusion alarm will be triggered. Buzzer: The buzzer sounds when an intrusion alarm is triggered. You can configure the alarm duration.
Unlock Timeout Alarm Linkage	When the door remains unlocked for longer than the defined timeout duration, the door timeout alarm will be triggered and last for the defined time. Buzzer: The buzzer sounds when the unlock timeout alarm is triggered. You can configure the alarm duration.

Parameter	Description
Max Use Alarm Link	<p>If the wrong password or card is used 5 times in a row within 60 seconds, the alarm for excessive use of illegal card will be triggered and lasts for a defined time.</p> <p>Buzzer: The buzzer sounds when the excessive use alarm is triggered. You can configure the alarm duration.</p>
Tamper Alarm Linkage	<p>The tamper alarm is triggered when someone has tried to physically damage the Device.</p> <ul style="list-style-type: none"> • Buzzer: The buzzer sounds when the tamper alarm is triggered. You can configure the alarm duration. • Local Alarm Output: The external alarm device generates alarms when the tamper alarm is triggered. You can configure the alarm duration.

4.6.5 Configuring Card Settings

Background Information

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **More** > **Access Control** > **Card Settings**.
- Step 3 Configure the card parameters, and then click **Apply**.

Figure 4-14 Card settings










Table 4-6 Card parameters description

Item	Parameter	Description
Card Settings	IC Card	The IC card can be read when this function is enabled.
		 This function is only available on select models.

Item	Parameter	Description
	IC Card Encryption & Verification	<p>The encrypted card can be read when this function is enabled.</p>  <p>Make sure IC Card is enabled.</p>
	Block NFC Cards	<p>Prevent unlocking through duplicated NFC card after this function is enabled.</p>  <ul style="list-style-type: none"> • This function is only available on models that support IC cards. • Make sure IC Card is enabled. • NFC function is only available on select models of phones.
	Enable Desfire Card	<p>The Device can read the card number of Desfire card when this function and IC Card are enabled at the same time.</p>  <ul style="list-style-type: none"> • This function is only available on models that support IC cards. • Only supports hexadecimal format.
	Desfire Card Decryption	<p>Information in the Desfire card can be read when IC Card, Enable Desfire Card and Desfire Card Decryption are enabled at the same time.</p>  <ul style="list-style-type: none"> • This function is only available on models that support IC cards. • Make sure that Desfire card is enabled.
Card No. System	Card No. System	<p>Select decimal format or hexadecimal format for the card number when Wiegand card reader is connected. The card No. system is the same for both card number input and output.</p>
DESFire Card Write	Card Number	<p>Place the card on the reader, enter the card number, and then click Write to write card number to the card.</p>  <ul style="list-style-type: none"> • Desfire card function must be enabled. • Only supports hexadecimal format. • Supports up to 8 characters.

Step 4 Click **Apply**.

4.7 Communication Settings

4.7.1 Configuring TCP/IP

You need to configure IP address of Device to make sure that it can communicate with other devices.


Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **More** > **Communication Settings** > **TCP/IP**.
- Step 3 Configure the parameters, and then click **Apply**.

Figure 4-15 TCP/IP

The screenshot displays the 'TCP/IP' configuration page. At the top, there is a back arrow and the title 'TCP/IP'. Below this, the configuration is organized into several sections. The first section contains 'NIC' set to 'NIC 1' and 'Mode' set to 'Static'. The second section shows the 'MAC Address' field. The third section shows 'IP Version' set to 'IPv4'. The fourth section contains five fields marked with a red asterisk: 'IP Address', 'Subnet Mask', 'Default Gateway', 'Preferred DNS', and 'Alternate DNS', each followed by a greyed-out input field. The fifth section shows 'MTU' set to '1500'. At the bottom, there is a large blue 'Apply' button.

Table 4-7 Description of TCP/IP

Parameter	Description
Mode	<ul style="list-style-type: none"> • Static: Manually enter IP address, subnet mask, and gateway. • DHCP: It stands for Dynamic Host Configuration Protocol. When DHCP is turned on, the Device will automatically be assigned with IP address, subnet mask, and gateway.
MAC Address	MAC address of the Device.
IP Version	IPv4 or IPv6.
IP Address	If you set the mode to Static , configure the IP address, subnet mask and gateway.
Subnet Mask	
Default Gateway	
	 <ul style="list-style-type: none"> • IPv6 address is represented in hexadecimal. • IPv6 version do not require setting subnet masks. • The IP address and default gateway must be in the same network segment.
Preferred DNS	Set IP address of the preferred DNS server.
Alternate DNS	Set IP address of the alternate DNS server.
MTU	<p>MTU (Maximum Transmission Unit) refers to the maximum size of data that can be transmitted in a single network packet in computer networks. A larger MTU value can improve network transmission efficiency by reducing the number of packets and associated network overhead. If a device along the network path is unable to handle packets of a specific size, it can result in packet fragmentation or transmission errors. In Ethernet networks, the common MTU value is 1500 bytes. However, in certain cases such as using PPPoE or VPN, smaller MTU values may be required to accommodate the requirements of specific network protocols or services. The following are recommended MTU values for reference:</p> <ul style="list-style-type: none"> • 1500: Maximum value for Ethernet packets, also the default value. This is a typical setting for network connections without PPPoE and VPN, some routers, network adapters, and switches. • 1492: Optimal value for PPPoE • 1468: Optimal value for DHCP. • 1450: Optimal value for VPN.

4.7.2 Configuring Wi-Fi

Procedure

- Step 1** Log in to the webpage.
- Step 2** Select **More > Communication Settings > Wi-Fi**.
- Step 3** Turn on Wi-Fi.
- All available Wi-Fi are displayed.



- The Wi-Fi function is available on select models.
- The Wi-Fi and Wi-Fi AP cannot be enabled at the same time.

Step 4 Click the Wi-Fi, and then enter the password.

The Wi-Fi is connected.

Related Operations

- DHCP: Select the **DHCP** mode and click **Apply**, the Device will automatically be assigned a Wi-Fi address.
- Static: Select the **Static** mode, manually enter a Wi-Fi address, and then click **Apply**, the Device will connect to the Wi-Fi.

4.7.3 Configuring Wi-Fi AP



- The Wi-Fi function is available on select models.
- The Wi-Fi and Wi-Fi AP cannot be enabled at the same time.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **More** > **Communication Settings** > **Wi-Fi AP**.
- Step 3 Enable the function, and then click **Apply**.

Figure 4-16 Wi-Fi AP

Wi-Fi AP

Enable ☒

SSID 2024-03-03 10:00:00

Security None >

IP Address 192.168.1.1

Apply

4.7.4 Configuring Cloud Service

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **More** > **Communication Settings** > **Cloud Service**.
- Step 3 Turn on the cloud service function.
The cloud service goes online if the P2P and PaaS are online.
- Step 4 Click **Apply**.

4.7.5 Configuring Auto Registration

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **More** > **Network Setting** > **Auto Registration**.
- Step 3 Enable the auto registration function, configure the parameters, and then click **Apply**.

Figure 4-17 Auto registration

The screenshot shows a mobile application interface for 'Auto Registration'. At the top, there is a back arrow and the title 'Auto Registration'. Below this is a light gray box containing the configuration options. The 'Enable' option is a toggle switch currently turned off. The 'Status' is indicated by a red dot and the text 'Offline'. The 'Server Address' is a text input field. The 'Port' is set to '7000'. The 'Registration ID' is set to 'none'. At the bottom of the form is a blue button labeled 'Apply'.

Table 4-8 Automatic registration description

Parameter	Description
Status	Displays the connection status of auto registration.
Server Address	The IP address or the domain name of the server.
Port	The port of the server that is used for automatic registration.
Registration ID	The registration ID (user defined) of the device. Adding the device to the management by entering the registration ID on the platform.

4.7.6 Configuring Wiegand


Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **More** > **Communication Settings** > **Wiegand**.
- Step 3 Select a Wiegand type, configure the parameters, and then click **Apply**.
 - Select **Wiegand Input** when you connect an external card reader to the Device.



When the Device connects to a third-party device through the Wiegand input port, and the card number read by the Device is in the reverse order from the actual card number. In this case, you can turn on **Card No. Inversion** function.

Figure 4-18 Wiegand input



- Select **Wiegand Output** when the Device functions as a card reader, and you need to connect it to another access controller.

Figure 4-19 Wiegand output

Table 4-9 Description of Wiegand output

Parameter	Description
Wiegand Output Type	Select a Wiegand format to read card numbers or ID numbers. <ul style="list-style-type: none"> ◇ Wiegand26 : Reads 3 bytes or 6 digits. ◇ Wiegand34 : Reads 4 bytes or 8 digits. ◇ Wiegand66 : Reads 8 bytes or 16 digits.
Pulse Width	Enter the pulse width and pulse interval of Wiegand output.
Pulse Interval	
Output Data Type	Select the type of output data. <ul style="list-style-type: none"> ◇ No. : Outputs data based on user ID. The data format is hexadecimal or decimal. ◇ Card Number : Outputs data based on user's first card number.

4.7.7 Configuring RS-485

Configure the RS-485 parameters if you connect an external device to the RS-485 port.

Procedure

Step 1 Log in to the webpage.

Step 2 Select **More** > **Communication Settings** > **RS-485 Settings**.

Step 3 Configure the parameters, and then click **Apply**.

Figure 4-20 RS-485 settings

The screenshot shows a mobile application interface for configuring RS-485 settings. The title bar at the top is labeled 'RS-485 Settings' with a back arrow on the left. Below the title bar is a list of settings, each with a label on the left and a value on the right, followed by a right-pointing arrow. The settings are: 'External Device' (Access Controller), 'Baud Rate' (9600), 'Data Bit' (8), 'Stop Bit' (1), 'Parity Code' (None), and 'Output Data Type' (No.). At the bottom of the interface is a large blue button labeled 'Apply'.

Table 4-10 Description of RS-485 parameters

Parameter	Description
External Device	<ul style="list-style-type: none"> ● Access Controller Select Access Controller when the Device functions as a card reader, and sends data to other external access controllers to control access. <ul style="list-style-type: none"> ◇ Authentication by Local Device : The identity is verified on both the Device and the controller. ◇ Authentication by Controller : The identity is verified only on the controller. ● Card Reader: The Device functions as an access controller, and connects to an external card reader. ● Reader (OSDP): The Device is connected to a card reader based on OSDP protocol. ● Door Control Security: The door exit button, lock and fire linkage is not effective after the security module is enabled.
Baud Rate	Select the baud rate. It is 9600 by default.
Data Bit	The number of bits used to transmit the actual data in a serial communication. It represents the binary digits that carry the information being transmitted.

Parameter	Description
Stop Bit	A bit sent after the data and optional parity bits to indicate the end of a data transmission. It allows the receiver to prepare for the next byte of data and provides synchronization in the communication protocol.
Parity Code	An additional bit sent after the data bits to detect transmission errors. It helps verify the integrity of the transmitted data by ensuring a specific number of logical high or low bits.
Output Data Type	<p>When you configure the external device as Access Controller.</p> <ul style="list-style-type: none"> ● Card Number: Outputs data based on card number when users swipe card to unlock door; outputs data based on user's first card number when they use other unlock methods. ● No.: Outputs data based on the user ID.

4.8 Viewing Logs

View logs such as system logs, unlock records, and alarm logs.

4.8.1 System Logs


View and search for system logs.

Procedure

Step 1 Log in to the webpage.

Step 2 Select **More** > **Log** > **Log**.

Figure 4-21 Logs



4.8.2 Unlock Records

Search for unlock records.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **More** > **Log** > **Unlock Records**.
- Step 3 Click the record to view the details.

4.8.3 Alarm Logs

View alarm logs.

Procedure

- Step 1 Log in to the webpage.
- Step 2 Select **More** > **Log** > **Alarm Log**.

5 Smart PSS Lite Configuration

This section introduces how to manage and configure the device through Smart PSS Lite. For details, see the user's manual of Smart PSS Lite.

5.1 Installation

Contact technical support or go to the official website to get the SmartPSS Lite. If you get the software package of the SmartPSS Lite, install and run the software according to page instructions.

5.2 Initialization

Initialize SmartPSS Lite when you log in for the first time, including setting a password for login and security questions for resetting password.

Procedure


- Step 1 Double-click SmartPSSLite.exe.
- Step 2 Select the language from the drop-down list, select **I have read and agree the software agreement**, and then click **Next**.

Figure 5-1 Select language



- Step 3 Click **Browse** to select installation path, and then click **Install**.

Figure 5-2 Select installation path




Step 4 Click **Finish** to complete the installation.




Select **Run SmartPSSLite** to start SmartPSS Lite.

Figure 5-3 Install complete



Step 5 Select the application scenes you want to add, and then click **OK**.

Figure 5-4 Select application scenes



Step 6 Click **Agree and Continue** to agree **Software License Agreement** and **Product Privacy Policy**.

Step 7 Set password on the **Initialization** page, and then click **Next**.

Figure 5-5 Set password




Table 5-1 Initialization parameters

Parameter	Description
Password	The password must consist of 8 to 32 non-blank characters and contain at least two types of characters among uppercase, lowercase, number, and special character (excluding ' " ; &).
Password Strength	Displays the effectiveness of a password against guessing or brute-force attacks. Green means the password is strong enough, and red means less strong. Set a password of high security level according to the password strength prompt.
Confirm Password	Enter the password again to confirm the password.
Auto Login after Registration	Enable Auto Login after Registration so that the SmartPSS Lite will log in automatically after initialization; otherwise the login page is displayed.

Step 8 Set security questions, and then click **Finish**.

Figure 5-6 Set security questions

The screenshot shows a window titled 'Initialization' with a close button (X) in the top right corner. Inside the window, there are two tabs: '1.Password Setting' and '2.Password Protection'. The '2.Password Protection' tab is active. Below the tabs, there is a yellow warning icon and the text 'Please set security questions!'. There are three sets of questions, each with a dropdown menu for the question and a text box for the answer. The questions are: 'Question 1: What is your favorite children's book?', 'Question 2: What was the first name of your first boss?', and 'Question 3: What is the name of your favorite fruit?'. At the bottom right of the window, there is a blue button labeled 'Finish'.

5.3 Adding Devices

There are several methods available to add devices.

- Automatically search
- Manually adding
- Import in batches

5.3.1 Adding Device by Searching

You can add multiple devices by searching for them on the current network segment or other network segments.

Background Information



We recommend you add devices through searching when want to add multiple devices that are on the same network segment, or when you want to add devices with a known network segment but you do not know the exact IP address of the devices.

Procedure

Step 1 On the home page, click **Devices**.

Step 2 Select a search method.

- **Auto Search:** Enter the username and the password of the device. The system will automatically search for devices that are on the same network to your computer.
- **Device Network Segment:** Enter the username and the password of the device, and then define the start IP and the end IP. The system will automatically search for devices in this IP range.

Step 3 Click **Auto Search**.

Step 4 Enter a IP range, and then click **Search**.

The system automatically searches for devices in this IP range. You can also click **Auto Search** to automatically search for devices on the same network your computer is connected to.

Figure 5-7 Search for devices

No.	IP	Device Type	MAC Address	Port	Initialization Status
-----	----	-------------	-------------	------	-----------------------











Step 5 Select devices, and then click **Add**.







Step 6 Enter the login username and password of the selected devices, and then click **OK**.

Step 7 Enter the login user name and password, and then click **OK**.

The devices will be added to the platform.

Figure 5-8 Added devices

Total Devices										
<input type="checkbox"/>	No.	Name	IP	Device Type	Device Model	Port	Number of Chann	Online Status	SN	Operation
<input type="checkbox"/>	1	AC		Door Station		37777	2/0/10/2	● Online		    
<input type="checkbox"/>	2	AC2		Access Controller		37777	2/0/0/0	● Offline		    

-  : Change the information of the device.
-  : Goes to the **Device Config** module in the platform.
-  : Goes to the webpage of the device.
-  : Log out of the device, and the status of the device will become **Offline**.
-  : Log in to the device, and the status of the device will become **Online**.
-  : Delete the device.

Related Operations

- Change IP one by one: Select a device, and then click **Change IP** to change the IP of the device.
- Change IP in batches: Select multiple devices, and then click **Change** to change their IP.



Enter the start IP, and the system will automatically assign IP to devices through increasing the IP by one based on the start IP. For example, if the start IP is 10.XX.XXX.52, and the following IP of devices will be 10.XX.XXX.53, 10.XX.XXX.54, and more.

- Initialize devices: Click **Initialize** to initialize devices.



Only support activating devices which are on the same network segment to your computer.

5.3.2 Adding Device One by One

If you already know the IP address of a device, you can manually add it to the platform.

Procedure

- Step 1 On the home page, click **Devices**.
- Step 2 Click **Add**, and then enter the device information.

Figure 5-9 Add devices

The 'Add Device' dialog box is shown with the following fields and controls:

- Device Name:** A text input field with a red asterisk indicating it is required.
- Add Mode:** A dropdown menu currently set to 'IP/Domain Name'.
- IP/Domain Name:** A text input field with a red asterisk indicating it is required.
- Port No.:** A text input field containing the value '37777' and a red asterisk indicating it is required.
- Username:** A text input field with a red asterisk indicating it is required.
- Password:** A text input field with a red asterisk indicating it is required.
- Buttons:** 'Add and Continue' (blue), 'Add' (blue), and 'Cancel' (grey).

Table 5-2 Parameters of IP adding

Parameter	Description
Device Name	The name of the device.
Add Mode	<ul style="list-style-type: none"> IP/Domain Name: Add devices through IP Address. SN (Available on devices that support P2P): Add devices through their serial number.
IP/Domain Name	Enter the IP address or domain name of the device.
Port No.	Enter the port number (80 by default).
Username	Enter the username and the password of the device.
Password	

Step 3 Click **Add**.

You can also click **Add and Continue** to add more devices.

5.3.3 Importing Device in Batches

You can export the device information, and then import it to another platform to add them in batches. We recommend you add devices by importing them when the devices are not on the same network segment.

Prerequisites

A .xml file of device information was exported. For details, see the corresponding user's manual.

Procedure

- Step 1 On the home page, click **Devices**.
- Step 2 Click **Import** to import the file the platform.



Devices will be logged in automatically after adding.

5.4 User Management

Add users, assign cards to them, and configure their access permissions.

5.4.1 Setting Card Type

Select **Person** > **Person Management**, and then **Card Type**.

Before issuing card, set card type first. For example, if the issued card is ID card, select type as ID card.





The system uses hexadecimal card number by default. Click  to change it to decimal card number.

Figure 5-10 Set card type



5.4.2 Configuring Card Type

Set the card type before you assign cards to users. For example, if the assigned card is an ID card, set card type to ID card.

Procedure

- Step 1 Log in to Smart PSS Lite.
- Step 2 Click **Access Solution** > **Personnel Manager** > **User**.
- Step 3 On the **Card Issuing Type** and then select a card type.



Make sure that the card type is same to the actually assigned card; otherwise, the card number cannot be read.

Step 4 Click **OK**.

5.4.3 Adding Users

5.4.3.1 Adding Personnel One by One

Procedure

Step 1 Select **Person** > **Person Management**, and then click **Add**.



Step 2 Enter basic information of person.

1. Select **Basic Info**.
2. Add basic information of personnel.
3. Take snapshot or upload picture, and then click **Finish**.
4. Configure identity verification methods.

- Set password

Click **Add** to add the password. For second-generation access controllers, set person passwords; for other devices, set card passwords. New passwords must consist of 6-8 digits.

- Configure card

- a. Click  to select **Device** or **Card issuer** as card reader.
- b. Add card.
- c. After adding, you can select the card as main card or duress card, or replace the card with a new one, or delete the card.
- d. Click  to display the QR code of the card.



Only 8-digit card number in hexadecimal mode can display the QR code of the card.

- Configure fingerprint

- a. Click  to select **Device** or **Fingerprint Scanner** as the fingerprint collector.
- b. Add fingerprint. Select **Add** > **Add Fingerprint**, and then press finger on the scanner for three times continuously.

- Configure feature codes


- a. Click , and then select a device.
- b. Click **Extract**, and then the device will extract the features of the face.

Figure 5-11 Add basic information

Add User

Basic Info

More Info

Person ID: *

Name: *

Department:

ult Company\HumanResource

Person Type:

Normal User

Effective Time:

2023/12/29 0:00:00

2023/12/29 23:59:59

3654 Day

Times Used:

Unlimited

Profile Picture

Take Snapshot

Upload Picture

Image size: 0-100 KB

Face1

Take Snapshot

Upload Picture

Image size: 0-100 KB

Face2

Take Snapshot

Upload Picture

Image size: 0-100 KB

Password

Add

For the second-generation access control device, it is the person password. Otherwise it is the card password.

Card

Add

The card number must be added if non-2nd generation access controller is used.

Fingerprint

+ Add

Delete

	Fingerprint Name	Operation
<input type="checkbox"/>		

Add More

Complete

Cancel

Step 3 Click **More Info** tab to add extended information of the staff, and then click **Complete**.

Figure 5-12 Add more information


The 'Add User' dialog box has a title bar with a close button. It contains two tabs: 'Basic Info' and 'More Info'. The 'More Info' tab is active, showing a 'Details' section. The fields in this section are:

- Gender: Radio buttons for 'Male' (selected) and 'Female'.
- Credential Type: A dropdown menu showing 'ID Card'.
- Title: A dropdown menu showing 'Mr.'.
- Credential No.: A text input field.
- Date of Birth: A date picker showing '1985/3/15'.
- Organization: A text input field.
- Phone No.: A text input field.
- Occupation: A text input field.
- Email: A text input field.
- Employment Date: A date-time picker showing '2023/12/28 11:11:18'.
- Communication A...: A text input field.
- Termination Date: A date-time picker showing '2033/12/29 11:11:18'.
- Admin: A toggle switch.
- Remarks: A large text area.




At the bottom right, there are three buttons: 'Add More' (blue), 'Complete' (blue), and 'Cancel' (grey).

Step 4 Click **Complete**.



After completing adding, you can click  to modify information or add details in the list of person.

Related Operations

- Click  to modify information or add details in the list of staff.
- Click  to delete all information of the person.
- Click  to freeze the card, and then the card cannot be used normally.

5.4.3.2 Adding Personnel in Batches

Procedure

- Step 1 Select **Person** > **Person Management**, and then click **Batch Add**.
- Step 2 Select the device type, set the start number, number of card.
- Step 3 Set the department, and the effective time and expiration time of card.
- Step 4 Click **Read Card No.**.
- Step 5 Place cards on the card issuer or the card reader.
The card number will be read automatically or filled in automatically.
- Step 6 Click **OK**.

Figure 5-13 Add personnel in batches

Batch Add

Device: Card Issuer

Start No.: 5

Quantity: 10

Department: Dropdown list

Validity Time: 2022/11/24 0:00:00

Expiration Time: 2032/11/24 23:59:59

Read C...

Issue Card

ID	Card No.
----	----------

OK Cancel

5.4.4 Assigning Access Permissions

The method to configure permission for department and for personnel is similar, and here uses department as an example.

Procedure

Step 1 Select **Access Control Config > Permission Settings**.



Step 2 Click  to add a permission rule.

Figure 5-14 Assign permissions rules



Step 3 Enter the name of the permission rule, select the time plan and unlock methods.

Step 4 In the **Person Info** area, click **Add** to select personnel, and then click **OK**.


You can select personnel on the department or individual users.

- Dept: All personnel in the department will be assigned with access permissions.
- User: Only selected users will be assigned with access permissions.



When you want to assign permission to a new person or change access permissions for an existing person, you can simply add the user in a existing department or link them with a existing role, they will be automatically assigned access permissions set for the department or role.

Figure 5-15 Add users



You can click **+** to create new permission areas. For details on creating permission areas, see the corresponding user's manual.

Step 5 In the **Area Info**, click **Add** to select an area, and then click **OK**.

Figure 5-16 Add area





The 'Add Area' dialog box features a title bar with a close button (X). Below the title bar is a table with two columns: a checkbox column and an 'Area List' column. The first row in the list contains a checked checkbox and the text 'Area1'. Below the table is a large empty rectangular area. At the bottom right of the dialog are two buttons: 'OK' (blue) and 'Cancel' (gray).

Step 6 Click **OK**.

Step 7 If authorization failed, click  in the list to view the possible reason.

Figure 5-17 Authorization progress

Permission Group	Device Name	Progress	Status	Result of Issuing	Operation
Permission Group3		<div><div></div>1/1</div>	Finished issuing	Successful: 1, Failed: 0	

5.4.5 Assigning Attendance Permissions

The method to configure permission for department and for personnel is similar, and here uses department as an example.

Procedure

Step 1 Select **Access Control Config > Permission Settings**.


Step 2 Click  to add a permission rule.

Figure 5-18 Assign permissions rules

The screenshot shows the 'Add Permission Rule' dialog box. On the left, a sidebar contains a '+', a trash icon, a search bar, and a message: 'You can only create up to 128 permission rules.' Below this is a table with columns 'Rule List' and 'Operation'. The main area is titled 'Add Permission Rule' and contains the following elements:

- Callout 1:** Points to the '+' icon in the sidebar.
- Callout 2:** Points to the 'Name' and 'Remarks' input fields. The 'Name' field contains 'Permission Rule1'.
- Callout 3:** Points to the 'Add' button in the 'Person Info' section.
- Callout 4:** Points to the 'Add' button in the 'Area Info' section.
- Callout 5:** Points to the 'OK' button at the bottom right.

The main area also includes:

- Weekly Plan:** A dropdown menu set to 'Full-day Time Template'.
- Holiday Plan:** A dropdown menu set to 'Disabled'.
- Select Data to be Sent:** Checkboxes for 'Card', 'Fingerprint', 'Password', and 'Face', all of which are checked.
- Person Info:** A section with a search bar and a list area showing 'No data' with an 'Add' button.
- Area Info:** A section with a search bar and a list area showing 'No data' with an 'Add' button.

Step 3 Enter the name of the permission rule, select the time plan and unlock methods.

Step 4 In the **Person Info** area, click **Add** to select personnel, and then click **OK**.


You can select personnel on the department or individual users.

- Dept: All personnel in the department will be assigned with access permissions.
- User: Only selected users will be assigned with access permissions.



When you want to assign permission to a new person or change access permissions for an existing person, you can simply add the user in a existing department or link them with a existing role, they will be automatically assigned access permissions set for the department or role.


Figure 5-19 Add users



You can click **+** to create new permission areas. For details on creating permission areas, see the corresponding user's manual.

Step 5 In the **Area Info**, click **Add** to select an area, and then click **OK**.

Figure 5-20 Add area





The 'Add Area' dialog box features a title bar with a close button (X). Below the title bar is a table with two columns: a checkbox column and an 'Area List' column. The first row contains a checked checkbox and the text 'Area1'. Below this table is a large empty rectangular area. At the bottom right of the dialog are two buttons: 'OK' (blue) and 'Cancel' (gray).

<input checked="" type="checkbox"/>	Area List
<input checked="" type="checkbox"/>	Area1

Step 6 Click **OK**.

Step 7 If authorization failed, click  in the list to view the possible reason.

Figure 5-21 Authorization progress

Permission Group	Device Name	Progress	Status	Result of Issuing	Operation
Permission Group3		<div><div></div>1/1</div>	Finished issuing	Successful: 1, Failed: 0	

5.5 Access Control Monitoring

Procedure

Step 1 Click **Access Control Monitoring** on the home page.

Step 2 Manage the door.

Figure 5-22 Monitor the door









Table 5-3 Parameters description

Function	Description
Remotely control the door	<p>Remotely control the door.</p> <ul style="list-style-type: none"> Method 1: Right-click a door, and then select Open or Close. Method 2: Click  or  to open or close the door.
	<p>View the video captured by the camera of the access controller or the linked external camera.</p> <p></p> <p>If you cannot view real-time video, it means that the access control device has no camera and is not connected to an external camera. Please configure an external camera for access controller. For details, see the corresponding user's manual..</p> <p>If you want to view multiple live videos at the same time, click  View, and then drag the access control device in the organization tree to windows, or double-click the access control device in the organization tree.</p>
Always Open	<p>After setting always open or always closed, the door is open or closed all the time and cannot be controlled manually. If you want to manually control the door again, click Normal to reset the door status.</p>
Always Closed	
Restore	
Access Point Settings	<p>Set devices (NVR, IPC, IVSS and more) that support target recognition as the access control point. After setting, the door unlock records will be uploaded to the platform.</p>

Step 3 Right-click a access control device to manage the device.

Figure 5-23 Manage the device





Table 5-4 Parameters description

Parameter	Description
Enable Real-time Monitoring	Start real-time event monitoring.
Show all Doors	Show all doors connected to the access control device.
Restart Device	Restart the access control device.
Details	View the device information, such as version, and more.

Step 4 View door status on **Event Info** list. For details, see the corresponding user's manual.

Related Operations

Click  to open the **Event Info** list.






- View access control information: You can view real-time access information in the **Event Info** list. The information will be cleared after the platform restarts.
- Filter events: Select the event type in the **Event Info** , and the event list displays events of the selected types. For example, select **Alarm**, and the event list only displays alarm events.
- Lock or unlock the event list: Click  on the right side of **Event Info** to lock or unlock the event list, and then the real-time events cannot be viewed.
- Delete events: Click  on the right side of **Event Info** to clear all events in the event list.
- Click **Event History** to jump to the **Access Control Record** page, and click **Event Config** to jump to the **Event Config** page.

Figure 5-24 Event information



Appendix 1 Important Points of Fingerprint Registration Instructions


When you register the fingerprint, pay attention to the following points:

- Make sure that your fingers and the scanner surface are clean and dry.
- Press your finger on the center of the fingerprint scanner.
- Do not put the fingerprint sensor in a place with intense light, high temperature, and high humidity.
- If your fingerprints are unclear, use other unlocking methods.

Fingers Recommended


Forefingers, middle fingers, and ring fingers are recommended. Thumbs and little fingers cannot be put at the recording center easily.

Appendix Figure 1-1 Recommended fingers




How to Press Your Fingerprint on the Scanner

Appendix Figure 1-2 Correct placement



Appendix Figure 1-3 Wrong placement



Appendix 2 Security Recommendation

Account Management

1. Use complex passwords

Please refer to the following suggestions to set passwords:

- The length should not be less than 8 characters;
- Include at least two types of characters: upper and lower case letters, numbers and symbols;
- Do not contain the account name or the account name in reverse order;
- Do not use continuous characters, such as 123, abc, etc.;
- Do not use repeating characters, such as 111, aaa, etc.

2. Change passwords periodically

It is recommended to periodically change the device password to reduce the risk of being guessed or cracked.

3. Allocate accounts and permissions appropriately

Appropriately add users based on service and management requirements and assign minimum permission sets to users.

4. Enable account logout function

The account logout function is enabled by default. You are advised to keep it enabled to protect account security. After multiple failed password attempts, the corresponding account and source IP address will be locked.

5. Set and update password reset information in a timely manner

The device supports password reset function. To reduce the risk of this function being used by threat actors, if there is any change in the information, please modify it in time. When setting security questions, it is recommended not to use easily guessed answers.

Service Configuration

1. Enable HTTPS

It is recommended that you enable HTTPS to access web services through secure channels.

2. Encrypted transmission of audio and video

If your audio and video data contents are very important or sensitive, it is recommended to use encrypted transmission function in order to reduce the risk of your audio and video data being eavesdropped during transmission.

3. Turn off non-essential services and use safe mode

If not needed, it is recommended to turn off some services such as SSH, SNMP, SMTP, UPnP, AP hotspot etc., to reduce the attack surfaces.

If necessary, it is highly recommended to choose safe modes, including but not limited to the following services:

- SNMP: Choose SNMP v3, and set up strong encryption and authentication passwords.
- SMTP: Choose TLS to access mailbox server.
- FTP: Choose SFTP, and set up complex passwords.
- AP hotspot: Choose WPA2-PSK encryption mode, and set up complex passwords.

4. Change HTTP and other default service ports

It is recommended that you change the default port of HTTP and other services to any port between 1024 and 65535 to reduce the risk of being guessed by threat actors.

Network Configuration

1. **Enable Allow list**

It is recommended that you turn on the allow list function, and only allow IP in the allow list to access the device. Therefore, please be sure to add your computer IP address and supporting device IP address to the allow list.

2. **MAC address binding**

It is recommended that you bind the IP address of the gateway to the MAC address on the device to reduce the risk of ARP spoofing.

3. **Build a secure network environment**

In order to better ensure the security of devices and reduce potential cyber risks, the following are recommended:

- Disable the port mapping function of the router to avoid direct access to the intranet devices from external network;
- According to the actual network needs, partition the network: if there is no communication demand between the two subnets, it is recommended to use VLAN, gateway and other methods to partition the network to achieve network isolation;
- Establish 802.1x access authentication system to reduce the risk of illegal terminal access to the private network.

Security Auditing

1. **Check online users**

It is recommended to check online users regularly to identify illegal users.

2. **Check device log**

By viewing logs, you can learn about the IP addresses that attempt to log in to the device and key operations of the logged users.

3. **Configure network log**

Due to the limited storage capacity of devices, the stored log is limited. If you need to save the log for a long time, it is recommended to enable the network log function to ensure that the critical logs are synchronized to the network log server for tracing.

Software Security

1. **Update firmware in time**

According to the industry standard operating specifications, the firmware of devices needs to be updated to the latest version in time in order to ensure that the device has the latest functions and security. If the device is connected to the public network, it is recommended to enable the online upgrade automatic detection function, so as to obtain the firmware update information released by the manufacturer in a timely manner.

2. **Update client software in time**

It is recommended to download and use the latest client software.

Physical Protection

It is recommended that you carry out physical protection for devices (especially storage devices), such as placing the device in a dedicated machine room and cabinet, and having access control

and key management in place to prevent unauthorized personnel from damaging hardware and other peripheral equipment (e.g. USB flash disk, serial port).