

AMC2 Extensions

AMC2-16IOE / -8IOE / -16IE



BOSCH

en Installation Manual

Table of contents

1	Safety Instructions	5
1.1	Important Safety Notes	5
1.2	Safety Precautions	7
1.3	Unpacking	9
2	Important Information	10
2.1	Explanation of symbols in this document	10
2.2	Internet	11
3	Introduction	12
3.1	Description	12
3.1.1	Extension AMC2-16IOE	12
3.1.2	Extension AMC2-8IOE	13
3.1.3	Extension AMC2-16IE	14
3.2	Equipment Configuration	15
3.3	Performance Characteristics	16
3.4	System Overview	17
4	Installing	19
4.1	Mounting	19
4.2	Unmounting	20
4.3	Opening the Case	21
4.4	Closing the Case	22
4.5	Cabling	23
4.5.1	Conductor data	23
4.6	Grounding and Shielding	25
4.6.1	Grounding for Extension Interface	26
4.7	Connecting Power Supply	27
4.7.1	Direct Power Supply	27
4.7.2	Power Supply via RS-485 Interface	28
4.7.3	Overview - Power supply/consumption	29
4.8	RS-485 for extension modules	32
4.8.1	Addressing	33
4.9	Connecting Relay Outputs	33
4.10	Connecting Analog Input Devices	38
4.11	Tamper Protection	41

5	Operating	42
5.1	Status Display of the AMC2	42
6	Technical Data	44
7	Appendices	48
7.1	Connecting Diagrams	48
	Index	52

1 Safety Instructions

1.1 Important Safety Notes

1. **Read, follow, and retain instructions** - All safety and operating instructions must be read and followed properly before putting the unit into operation. Retain instructions for future reference.
2. **Do not ignore warnings** - Adhere to all warnings on the unit and in the operating instructions.
3. **Accessories** - Use only accessories recommended by the manufacturer or those sold with the product. Accessories not recommended by the manufacturer must not be used, as they may cause hazards.
4. **Installation precautions** - Do not place this unit on an unstable stand, tripod, bracket, or mount. The unit may fall, causing serious injury to persons and damage to the unit. Mount the unit according to the manufacturer's instructions.
5. **Service** - Do not attempt to service this unit by yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Refer all servicing to qualified service personnel.
6. **Damage which requires service** - Disconnect the unit from the main AC or DC power source and refer servicing to qualified service personnel under the following conditions:
 - If the power supply cord or plug is damaged.
 - If liquid has been spilled or an object has fallen into the unit.
 - If the unit has been exposed to water and/or inclement weather (rain, snow, etc.).
 - If the unit does not operate normally when following the operating instructions. Adjust only those controls specified in the operating instructions. Improper

adjustment of other controls may result in damage, and require extensive work by a qualified technician to restore the unit to normal operation.

- If the unit has been dropped or the cabinet damaged.
 - If the unit exhibits a distinct change in performance.
7. **Replacement parts** - If replacement parts are required, the service technician must use only replacement parts that are specified by the manufacturer. Unauthorized replacements may result in fire, electrical shock or other hazards.
 8. **Safety check** - Upon completion of service or repair work on the unit, ask the service technician to perform safety checks to ensure that the unit operates properly
 9. **Power sources** - Operate the unit only from the type of power source indicated on the label. If unsure of the type of power supply to use, contact your dealer
 10. **Lightning** - For added protection during electrical storms external lightning conductors can be installed. This prevents power surges from damaging the unit.
 11. The units should be installed in **locations with restricted access**.

1.2 Safety Precautions

Read instructions!

Before working with the AMC2 device, read these instructions carefully. Make sure you have understood all information described in this document.

Warning!

Risk of electric shock



External power supplies must be installed and put into service by qualified personnel.

Ensure compliance with the relevant regulations.

Ground the controller.

Disconnect both AC and battery power supply before working on the controller.

Warning!

Risk of fire



Installation of the AMC2 device must comply with any local fire, health, and safety regulations. A secured door that may be part of an escape route from an area must be installed with:

Install a fail-safe lock (A), so that the door will be released if power fails. Ideally, use a magnetic lock.

Install a normally-closed break glass or a manual pull (B) in the lock supply wiring, so that in an emergency the fail-safe lock can be immediately powered down.

Warning!**Risk of explosion of Lithium battery**

The battery can explode if it is replaced incorrectly.

Replace only with the same type as recommended by the manufacturer.

Dispose used batteries according to the battery manufacturer's instructions.

Notice!**Risk of damage to equipment**

Protect the hardware from electrostatic discharge by observing ESD instructions before unpacking or touching connectors of electronics.

Always switch off power of the AMC2 device before modifying the installation.

Do not connect or disconnect plug connectors, data cables, or screw connectors while power is on.

Rules and Conditions

There are no specific requirements as for selling and delivery. As for storage and safe operation, the environmental temperature should not exceed the range of 0°C to 50°C.

Disposal

Your Bosch product is designed and manufactured with high-quality materials and components which can be recycled and reused.



This symbol means that electrical and electronic equipment, at their end-of-life, should be disposed of separately from your household waste.

In the European Union, there are separate collection systems for used electrical and electronic products. Please dispose of this equipment at your local community waste collection/recycling center.

1.3 Unpacking

Check the packaging for visible damage. If anything has been damaged during transport, please inform the transport agency. Unpack the unit carefully. This is an electronic device that must be handled with care to avoid damage. Do not attempt to put the unit into operation if components are damaged.

If any parts are missing, inform your customer service representative or a Bosch Security Systems salesperson. The shipping carton is the safest transport container for the unit. Store it and the other packaging material for future use. If the unit has to be sent back, use the original packaging.

2 Important Information

Remarks

This hardware is part of a security system. Access should be limited to authorized persons only.

Some states do not allow the exclusion or limitation of implied warranties, or limitation of liability for incidental or consequential damages, hence the above limitation or exclusion might not apply to you.

Bosch Security Systems retains all rights not expressly granted. Nothing in this license constitutes a waiver of Bosch's rights under the U.S. Copyright laws or any other federal or state law. If you have any questions concerning this license, please, write to:

Bosch Sicherheitssysteme GmbH
Robert-Bosch-Ring 5
85630 Grasbrunn
Germany.

2.1 Explanation of symbols in this document

Throughout this document, warning messages, important notes, and helpful tips are presented for the reader. These appear as follows:



Danger!

Cause of Hazard

Indicates a hazardous situation, which, if not avoided, will result in death or serious injury.



Warning!

Cause of Hazard

Indicates a hazardous situation, which, if not avoided, could result in death or serious injury.

**Caution!**

Cause of Hazard

Indicates a hazardous situation, which, if not avoided, could result in minor or moderate injury.

**Notice!**

Cause of Hazard

Important Notes that must be followed to avoid damage to the equipment or environment, and to ensure successful operation and programming.

Tips and shortcuts may also be included in such notes.

2.2 Internet

If you are interested in further information on this product or information on other products, please consult our website at <http://www.boschsecurity.com>.

3 Introduction

3.1 Description

3.1.1 Extension AMC2-16IOE

The extension board AMC2-16IOE can be used with an AMC2 controller. It serves additional inputs and outputs.




Figure 3.1: The extension board AMC2-16IOE

The AMC2 has eight analog input devices and eight relay outputs. With its analog input devices, the AMC2 verifies, for example, if a lock is closed or open. The relay outputs can be used to activate lock mechanisms if access is granted, or activate an external alarm system if an intrusion or system alert is detected.

The AMC2-16IOE electronics are completely covered by a plastic housing.



Notice!

The AMC2-16IOE has no display. The information about the input and outputs will be shown on special pages of the AMC2 display.

**Notice!**

An AMC2-16IOE provides signals only to the AMC2 to which it is connected. Signal transfer to another AMC2 is not possible.

**Notice!**

Depending on the software system up to 3 extension modules can be connected at random.

3.1.2 Extension AMC2-8IOE

To optimize the utilization of the available signals the extension module can be delivered in a reduced version, too. The AMC2-8IOE has eight inputs and eight outputs. The places of the pluggable screw connectors are on one side of the module - the other side will be closed by the housing.



Figure 3.2: Extension module AMC2 8IOE

Notice!

The AMC2-8IOE is identical in all respects to the AMC2-16IOE except in the number of inputs and outputs. Information in this manual refers to all three extensions described here, unless explicitly stated otherwise.

3.1.3 Extension AMC2-16IE

Another variant of the extension modul AMC2-16IOE is the AMC2-16IE which offers connectors for input signals only. The inputs are located at the same positions as on the AMC2-16IOE. The output connections in the AMC2-16IE are not usable. Within a system configuration the AMC2-16IE is treated as a normal extension module:

It can be connected at any AMC2. Up to three extensions (for BIS three, for Access PE only one) can be connected to an AMC2. Extension variants can be used in any combination.




Figure 3.3: Extension module AMC2-16IE

Notice!

The AMC2-16IE is identical in all respects to the AMC2-16IOE except in missing outputs. Information in this manual refers to all three extensions described here, unless explicitly stated otherwise.

3.2 Equipment Configuration




Figure 3.4: Overview - Interfaces

1	RS-485 extension module bus
2	External tamper contact
3	N.A.
4	Connector for power supply
5	Connectors for 16 analog inputs
6	Connectors for 16 relay outputs



Notice!

All connectors are pluggable screw clamp terminals.




Figure 3.5: Jumpers at the bottom side

7	Jumper for setting either voltage free relay output (“dry” mode) or looped-in voltage from the AMC2 internal power supply (“wet” mode).
8	DIL switch for setting the board address.
9	Jumper: Equalization of potential between different systems and earth ground (shield) for the extension interface.

3.3 Performance Characteristics

- Controlled by an AMC2 via RS-485
- 16 relay outputs
 - voltage free, power is supplied externally (dry mode)
 - powered by internal power supply (wet mode)
- 16 analog inputs with internal power supply
- Transfer rate to the extension interface: 9,6 kBit/s

- Self regulating transmit/receive switching
- Power supply:
 - 10V - 30Vdc - max. 5 A
 - or over the RS-485 host connector
- Information about the inputs and outputs on the display of the AMC2 controller
- Tamper contact for external covers

**Notice!**

If an external power supply is used, this should also guarantee an uninterruptable power supply (UPS). Example: Bosch power supply APS-PSU-60 (F.01U.282.970).

3.4 System Overview

The extension module AMC2-16IOE is connected to the Access controller AMC2. By default it is connected via RS-485.




Figure 3.6: System overview

1 =	Host
2 =	AMC2-Controller
3 =	Card reader
4 =	Communication and Power supply
5 =	AMC2-Extension
6 =	Ethernet

System configurations for Access Control applications.

- The minimum configuration consists of:
 - one PC with system software,
 - one AMC2 controller,
 - one AMC power supply,
 - one AMC enclosure.
- The maximum configuration depends on the system software,

4 Installing

4.1 Mounting

The AMC2-16IOE can be attached on a standard 35 mm (1.377 in.) mounting rail using a snap-in mechanism. Attach the AMC2-16IOE into the upper edge of the mounting rail [1], then push down the device and snap it onto the rail by pushing it towards the back [2].




Figure 4.1: Mounting the AMC2 device on a mounting rail

4.2 Unmounting

**Notice!**

To remove the AMC2-16IOE from a mounting rail, first remove all pluggable connectors.

Push down the AMC2-16IOE until the lower edge snaps out of the mounting rail [1]. Pull the lower end of the AMC2-16IOE from the mounting rail [2].




Figure 4.2: Unmounting the AMC2 device from a mounting rail

4.3 Opening the Case

**Notice!**

To open the AMC2-16IOE, first remove all pluggable connectors.

The AMC2-16IOE case consists of a top cover mounted with a two-point snap-in closure on a chassis. To open the case, push down the two snap-ins with a screwdriver, then swing the cover down.




Figure 4.3: Opening the AMC2-16IOE case

4.4 Closing the Case

Before aligning the covers, unplug any pluggable screw connectors. Insert the hooks on the lower edge of the front cover into the lugs on lower edge of the plastic back cover [1]. Please ensure that the BOSCH logo is not upside-down. The upper edge of the front cover now aligns with the two-point snap-in closures on the upper edge of the back cover [2], and may thus be clicked gently into place. Hence the closing process is the reverse of the opening process.




Figure 4.4: Closing the extension case

Notice!

Risk of damage to equipment

If excessive force is required to close the front cover then it is probably incorrectly hooked into the back cover. In such cases the display 'Dialog' button in the front cover will be misaligned and will not function correctly.

4.5 Cabling

Notice!

Risk of malfunction

The cables used in the AMC2-16IOE access control system are not prone to electrical interference. However, you should avoid routing cables close to heavy load switching cables and equipment. If this is unavoidable, cross the cable at right angles every 1 to 2 m (3 to 6 ft) to reduce interference.

4.5.1 Conductor data

With the calculation below you can find out which cable type must be used. If you connect the power supply and the AMC-device with the delivered cable set from the enclosure the calculation is not necessary.

For distances below 25 m (75 ft) use AWG18 conductors (1mm²). For longer distances, install an additional power supply close to the AMC2 controller.

Please, calculate the voltage drop by checking the conductor specifications for characteristic resistance values. The voltage drop shall not exceed 2 V.

Example:

Length = 100 m/328 ft

$U = 12V$, $I = 1A$, maximum $U_{Drop} = 2V$

i.e. RAWG18 (acc. specs) = $6.385 \frac{\Omega}{1000 \text{ ft}}$ or $20,948 \frac{\Omega}{\text{km}}$

$$U_{\text{Drop}} = 20,948 \frac{\Omega}{\text{km}} \times 0.1 \text{ km} \times 1\text{A} = 2.1\text{V}$$

$$U_{\text{Drop}} = 6.385 \frac{\Omega}{1000 \text{ ft}} \times 328 \text{ ft} \times 1\text{A} = 2.1\text{V}$$

Critical condition! Install the power supply closer to the controller.

Notice!



These specifications apply to power supply, readers, relay outputs, and extension interface.

Regarding inputs, specific voltage-drop values need to be taken into account. Refer to *Connecting Analog Input Devices*, page 38.

4.6 Grounding and Shielding

The AMC2 controller allows you to create a central ground or shielding point, simply by setting certain jumpers. Set these jumpers only if grounding or shielding is not achieved by other means.

1. If the AMC2-16IOE has its own power - as in the third example in *Overview - Power supply/consumption, page 29* - the shield will be connected to pin 2 of the power supply connector - see *Connecting Diagrams, page 48*.
2. If the extension module is powered from the AMC2 controller - as in the second example in *Overview - Power supply/consumption, page 29* - the connection should be made as in the *RS-485 for extension modules, page 32* diagram.
3. If more than one extension module is to be connected to an AMC2 controller, and all of them to receive power from it as well, then use the RS-485 extension interface for the connection.

Notice!



In the second and third case the jumper B on the bottom side of the AMC2-controller must to be set - see the installation manual of the AMC2-4W.

The jumper A of the extension boards will not be set.

Notice!



Risk of malfunction

Ensure that no ground loops are formed.

Notice!

In general the following apply:



If the devices have their own power supplies, the shielding is applied to one side only. The free end should be insulated to avoid inadvertent connections.

If one device is fed power by another, the cable shielding should be applied to both sides.

4.6.1 Grounding for Extension Interface




Figure 4.5: Location of ground jumper bottom side

The jumper setting A1 shows the factory settings.

Jumper connects the internal ground of the AMC2-16IOE to the ground of the RS-485 slave interface. Set Jumper A2 only at the first AMC2-16IOE of a party line - like example four in *Overview - Power supply/consumption*, page 29.

4.7 Connecting Power Supply

4.7.1 Direct Power Supply

Connect the power supply to the POWER 7-pin pluggable screw connector. Refer to *Connecting Diagrams*, page 48 for a complete diagram.




Figure 4.6: Location of the power supply connector

Connect an external power supply (10 - 30 Vdc) for AMC2-16IOE at pin 1 (positive) and pin 3 (0 V) of the pluggable screw connector.

If an uninterruptible power supply (UPS) is used, the relay output for power good signals from the UPS is connected to the following pins:

- pin 4 and 7 for power good AC
- pin 5 and 7 for power good Battery
- pin 6 and 7 for power good DC

Otherwise these pins must be short-circuited.

4.7.2 Power Supply via RS-485 Interface

The power can also be supplied by the AMC2-4W. In this case power pins 1 and 2 should be connected, as well as data lines on pins 3 - 6.




Figure 4.7: Interface for internal power supply

4.7.3 Overview - Power supply/consumption




Figure 4.8: Example configurations

Examp le	Used components	Output power	Own Usage	availabl e	Constan t load
1	PS + AMC2	60VA	5VA	55VA	25VA
2	PS + AMC2 + Extension	60VA	2 x 5VA	50VA	20VA
	using further Extensions the values decrease				
	PS + AMC2 + 2 x Extension	60VA	3 x 5VA	45VA	15VA
	PS + AMC2 + 3 x Extension	60VA	4 x 5VA	40VA	10VA
3	PS + AMC2 and PS + Extension	60VA + 60VA	5VA + 5VA	55VA + 55VA	25VA + 25VA
	using further Extensions the values decrease				
	PS + AMC2 and PS + 2 x Extension	60VA + 60VA	5VA + 2 x 5VA	55VA + 50VA	25VA + 20VA
	PS + AMC2 and PS + 3 x Extension	60VA + 60VA	5VA + 3 x 5VA	55VA + 45VA	25VA + 15VA

Example	Used components	Output power	Own Usage	available	Constant load
using more than two Extensions this combination is recommended					
4	PS + AMC2 + Extension and PS + Extension + Extension	60VA + 60VA	2 x 5VA + 2 x 5VA	50VA + 50VA	20VA + 20VA

Table 4.1: Overview - power supply and power consumption

Explanations for the table columns:

- Output power**Power provided by the power supply.
- Own usage**Power used by AMC2 device
- Available**Power remaining for external devices
- Constant load**Amount of the available power that can be drawn constantly.

Hence **Example 1** can be read as follows:
Of the total incoming power (60VA) 5VA will be drawn by the AMC2 itself . This leaves 55VA to support external devices. 25VA of these 55VA can be used for constant load (e.g. a card reader) leaving 30VA for occasional peak usage (e.g. a door opener).

4.8 RS-485 for extension modules

The AMC2-16IOE is connected to the AMC2 controller using the RS-485 extension interface. This interface will also be used to connect further extension modules.




Figure 4.9: Location of the RS-485 extension module bus





Figure 4.10: Connection of an extension module to an AMC2

4.8.1 Addressing

The address of the board is set using a switch on the board's underside (see *Equipment Configuration, page 15*).
Up to three extension boards (BIS) can be connected to one AMC2 - depending on that the addresses 1 to 3 can be assigned, only.



Notice!

When configuring the system, ensure that the order of boards in the access control software corresponds to the addresses you set using this switch.

This order of addressing determines the numbering of the boards' signals - see *Connecting Diagrams, page 48*.

Address	Signal-No.:	
	AMC2-8IOE	AMC2-16IOE
1	1/ 01 - 08	1/ 01 - 16
2	2/ 01 - 08	2/ 01 - 16
3	3/ 01 - 08	3/ 01 - 16

Table 4.2: Signals numbering

4.9 Connecting Relay Outputs

To operate locks or alarm systems, the AMC2-16IOE has 16 form C relay outputs. The outputs will be connected to the 3-pin pluggable screw connectors S6 - 9, S14 - 17, S24 - 27, and S32 - 35 - refer to *Connecting Diagrams, page 48*.

The AMC2 8I-8O-EXT has the connectors S6 - 9 and S14 - 17, only.

There are no outputs for the AMC2-16IE.




Figure 4.11: Location of the relay output connectors

Each relay output can operate in 'wet' mode, using the AMC2-16IOE's internal 12/24 Vdc power supply for external devices or 'dry' mode with potential free contacts for externally powered systems.




Figure 4.12: Wet mode and dry mode of the AMC2 relay outputs

**Notice!****Risk of damage to equipment**


To prevent damage to the relays note the following specifications.

- the maximum switching current is 1.25 A
- the maximum switching voltage is 30 Vdc
- only ohm resistive load can be connected to the relay
- inductive loads have to be short circuited using recovery diodes, see image below. These diodes (1N4004) are supplied with every AMC2-16IOE package.
- If you need higher voltage for special applications you can connect external relays to the outputs. Recommended, depending on the power supply mode, are the relay types from the Wieland company:
 - Flare move 12DC1W10A
 - Flare move 24DC1W16A


If using locally manufactured products, please ensure that the specifications of the product are identical with the those listed above.

A complete connection diagram of the relay output connectors is shown in *Connecting Diagrams*, page 48.

wet mode:



dry mode:

**Figure 4.13: Recovery diode schematic**

1	normally open/ normally closed	1	normally open/ normally closed
2	common	2	common
3	load	3	load
4	diode	4	diode
		5	voltage source

**Notice!****Risk of damage to equipment**

Do not connect externally powered devices in wet mode. This can damage the AMC2-16IOE.

Each relay output has a separate jumper setting on the underside of the circuit board to select dry (B 1) or wet (B 2) mode.




Figure 4.14: Location of relay output jumpers

4.10 Connecting Analog Input Devices

The AMC2-16IOE has 16 analog inputs, for example, for potential-free lock mechanisms, or to detect whether a lock is closed or open. The inputs will be connected to the 2-pin pluggable screw connectors: S2 - 5, S10 - 13, S20 - 23, and S28 - 31 - refer to *Connecting Diagrams*, page 48.

The AMC2-8IOE has the connectors S2 - 5 and S10 - 13, only.

Notice!

Risk of damage to equipment

Do not connect external power supply to the AMC2 inputs.

When connecting a relay output to an AMC2 input use dry mode with potential-free contact - refer to *Connecting Relay Outputs*, page 33.





Figure 4.15: Location of the analog input connectors

The AMC2-16IOE can also detect the wiring conditions 'short circuit' and 'broken', and hence trigger an alarm if the appropriate devices are connected.



1. Door open: $R_S + R_P$
2. Door closed: R_S
3. Open wire: $R_S + R_P = \infty$
4. Short circuit: $R_S + R_P = 0$

The resistor values can vary and depend on the used lock system.

The extension package includes 2,2 k Ω resistors which can be used to replace R_S and R_P resistor.

To detect the four states, the voltage drop in the connecting cable may not exceed special values. The following table shows the maximum values of permissible cable resistance depending on the used resistor combination.

R _P	1k	1k2	1k5	1k8	2k2	2k7	3k3	3k9	4k7	5k6	6k8	8k2
R _S												
1k	220	220	220	210	200							
1k2	260	270	270	270	260	240						
1k5	310	330	340	350	350	340	310	280				
1k8	340	380	390	410	410	410	400	370	330	290	200	
2k2		430	460	490	510	520	510	500	460	420	340	240
2k7		490	540	570	620	630	640	640	620	580	510	420
3k3			610	650	700	740	770	780	770	750	700	620
3k9				720	790	850	890	910	910	910	880	810
4k7					880	960	960	970	1100	1100	1050	1050
5k6						1050	1100	1200	1200	1300	1300	1250
6k8							1300	1400	1500	1500	1500	1500
8k2								1500	1650	1700	1800	1900

Table 4.3: Maximum values of cable resistance per used resistor combination in Ohm



Notice!

We recommend using serial resistors (R_S) no higher than 5K6 in order to obtain clear measurements.

4.11 Tamper Protection

To protect the AMC2-16IOE against unauthorized access and so prevent tampering with sensitive data, the AMC2-16IOE provides an additional interface to connect external tamper contacts. This interface is a potential-free 2-pin pluggable screw connector marked with **T**. When not in use this tamper contact should be shorted.




Figure 4.16: Location of the tamper protection contact

5 Operating

5.1 Status Display of the AMC2

Because the AMC2-16IOE has no display of its own, the AMC2 controller displays status information about the input and output settings of the AMC2 extension boards.

The selected display mode remains set until the next time the button is pressed. The order of the display pages is shown in the following table. Display pages 3a to 3c include the information about the I/O-Boards' signals. For each I/O-Board connected there is a separate display page.

Push	Display (Example)	Description
0	V01.00 02.03.07	Software versions and date of the firmware.
1a	S/N1: 0910019212	BOSCH serial number
1b	S/N2: 00000001	
2	02.06 15:35:15 (S)	Current date and time (S) = Summer; (W) = Winter
3	Dig. IO: ::::::::::	Display of the digital contacts: the input signals set will be shown with an extension above - output signals with an extension below.
3a	Dig. I1: ::::::::::	If there are I/O-Boards connected the signals will be shown on separate pages.
3b	Dig. I2: ::::::::::	
3c	Dig. I3: ::::::::::	
4	MAC 0010174C8A0C	Network device address (MAC)

Push	Display (Example)	Description
5	N AMC-1234-5678	Network name of the AMC2
6	I 192.168.10.18	IP-address of the AMC2
7	G 192.168.10.255	IP-address of the gateway (Version V 00.44 or higher)
8	M 255.255.255.0	Subnetmask (Version V 00.44 or higher)
9	H 192.168.10.10	IP-address of the host computer
10	DHCP 1	DHCP-status: 1 = on 0 = off
11	D 192.168.10.1	IP-address of the DNS server
12	Host: + "C"	Host activity: + = online - = offline "C" = Counter of the received data packages from the host interface. RS 485 Bus connection: A = Address 1 ... H = Address 8

6 Technical Data

- 16 resp. 8 relay outputs
 - maximum ratings (wet and dry):
switching voltage: 30 Vdc
switching current: 1,25 A
 - operating ratings (wet and dry):
1,25 A @ 30 Vdc
2 A @ 12 Vdc
1,5 A @ 24 Vdc
- 16 resp. 8 analog inputs with tamper detection; only connect dry contacts
- RS-485 extension interface:
Transfer rate: 9,6 kBit/s,
no parity, 8 bit, 2 stop bit
- Tamper contact for external enclosures

Power supply

10 to 30 Vdc

or via the AMC2-4W

Power consumption

AMC: 5 VA

Peripheral devices: using the PSU-60

- up to 55 VA
- constant load: 25 VA

Connectors

Pluggable screw connectors

Protection class

IP30

Environment temperature

0° C to 50° C (32° F to 122° F)

Humidity

Up to 95%, without condensation

Housing material

ABS with OC (UL 94 V-0)

Dimensions

(W/H/D) 232 x 90 x 46mm (8.9 x 3.5 x 1.8 in)

Weight

approx. 0.4kg (0.9lb)

**Notice!**

The voltage drop from the power supply to the AMC2-16IOE affects the AMC interfaces. The total drop must not exceed 2V!

**Notice!**

To determine the environmental impact of an installation, take into account the most extreme values of all participating devices.

To determine the vulnerability of an installation, take into account the most restrictive values of all participating devices.

7 Appendices

7.1 Connecting Diagrams




Figure 7.1: Connector blocks of the AMC2-16IOE




Figure 7.2: Connector blocks of the AMC2-8IOE




Figure 7.3: Connector blocks of the AMC2-16IE


	1	Power supply, DC positive (10V - 30V)
	2	Shield
	3	Power supply (0V)
	4	UPS (power good signal) - AC
	5	UPS (power good signal) - Battery
	6	UPS (power good signal) - DC
	7	UPS (power good signal) - Common

Table 7.1: Power supply


	1	Analog Input, in
	2	Analog Input, out

Table 7.2: Analog input


	1	Relay Output, normally open
	2	Relay Output, common
	3	Relay Output, normally closed

Table 7.3: Relay output


	1	Power supply for external devices (10V - 30V)
	2	Power supply for external devices (0V)
	3	Shield
	4	Data RxTx+
	5	Data RxTx-
	6	Ground (PAG)

Table 7.4: Host / Extension interface

	1	Tamper Contact, in
	2	Tamper Contact, out

Table 7.5: External tamper contact

Index

A

addressing, 33

C

cabling, 23

D

Dauerlast, 30

description

16 I/O-board, 12

16 I-board, 14

8 I/O-board, 13

E

extension interface, 44

I

inputs, 15, 16, 38

interfaces

extension, 44

M

mounting, 19

O

opening, 21

outputs, 15, 16, 33, 44

overview, 17

P

power supply, 23, 27

R

resistor, 39

S

system overview, 17

T

tamper, 41

U

unmounting, 20

Bosch Sicherheitssysteme GmbH

Robert-Bosch-Ring 5

85630 Grasbrunn

Germany

www.boschsecurity.com

© Bosch Sicherheitssysteme GmbH,
2016