

# User manual

## DAHUA DH-ARA11 Indoor Siren

### Introduction

Thank you for choosing the DAHUA DH-ARA11 Indoor Siren! This device is designed to provide powerful audible alarms and rotating alarm lights to alert you to indoor emergency situations. Made from environmentally friendly plastics, this product is a safe and reliable option for the security of your home or business.

### Package content

- DAHUA DH-ARA11 Indoor Siren
- User manual
- Screws and anchors for mounting
- Power adapter

### Technical specifications

- **Model:**DH-ARA11
- **Alarm Type:**Sound and visual
- **Alarm Sound:**High sound pressure
- **Alarm Light:**rotating light
- **Material:**Environmentally friendly plastics
- **Dimensions:**73.0mm × 43.0mm × 124.6mm,
- **Weight:**126g
- **Feeding:**10–15 VDC

### Facility

#### Installation Requirements

- A space suitable for mounting on an interior wall or ceiling.
- Access to a nearby power outlet.
- Tools needed: drill, screwdriver.

### Installation procedure

#### 1.Installation Location Selection:

- Choose a visible, centralized location to maximize the effectiveness of the audible and visual alarm.
- Make sure there is a power outlet nearby.

## 2.Mounting:

- Use the included mounting bracket to mark drill points on the selected surface.
- Drill the holes and place the anchors.
- Secure the siren using the screws provided.

## 3.Electric connection:

- Connect the power adapter to the siren and plug it into a power outlet.
- Check that the device is properly connected and turned on.

## Functioning

### On and off

- **Switched on:** Plug the siren into the power outlet. The rotating light and alarm sound will activate in case of an emergency.
- **Off:** Unplug the siren from the power outlet to turn it off.

### Test run

- Press the test button (if available) to make sure the siren and alarm light work properly.
- Verify that the siren emits a loud sound and that the rotating light activates.

## Maintenance

- **Cleaning:** Clean the surface of the siren with a dry cloth. Avoid using abrasive liquids or cleaners.
- **Regular Verification:** Perform periodic tests to ensure that the siren and alarm light are working properly.
- **Replacement of Parts:** In case of failure, contact authorized technical service for repair or replacement of parts.

## Troubleshooting

Problem	Possible cause	Solution
The siren does not make a sound	Power problem	Check electrical connection
The alarm light does not turn on	Bulb failure	Replace the bulb
The siren makes a weak sound	Obstruction in the speaker	Clean the speaker grill

**Warnings**

- Do not attempt to open or repair the siren yourself. This could void your warranty.
- Keep the siren out of the reach of children.
- Only use the supplied power adapter.