FLEXIDOME IP Mounting Options			FLEXIDOME IP micro 2000	FLEXIDOME IP micro 5000	FLEXIDOME IP indoor 4000-5000		FLEXIDOME IP outdoor 4000-5000		FLEXIDOME IP panoramic 5000 MP		FLEXIDOME IP panoramic 7000 MP	FLEXIDOME IP 7000 VR	FLEXIDOME IP 7000 RD	FLEXIDOME IP corner 9000
Rev 2.0 (March 2016)						(2) BOSCH	⊕ BOSON	() ROSCN	BOSCH	O TOTALIN		© BOSCH		
			NUC-21002 NUC-21012	NUC-51022 NUC-51051	NIx-40012-V3 NIx-50022-V3 NIx-50051-V3	NIx-41012-V3 NIx-51022-V3 NIx-500xx-A3	NDx-40012-V3 NDx-50022-V3 NDx-50051-V3	NDx-41012-V3 NDx-50022-A3 NDx-50051-A3	NUC-52051-F0	NUC-52051-F0E	NIN-70122	NIN-733 NIN-832 NIN-932	NDN-733 NDN-832 NDN-932	NCN-90022
WALL MOUNT	NDA-LWMT-DOME		•		-	•	-	•						
	NDA-WMT-MICDOME	7		•					•					
	VDA-832FHD-WMT	3											•	
	VDA-WMT-AODOME	7					-	-						
	VDA-WMT-DOME	2												
	VEZ-A2-WW	2			■ (with NDA-ADTVEZ-DOME)	■ (with NDA-ADTVEZ-DOME)								
PIPE MOUNT	NDA-PMT-MICDOME								•	■ (not IP66)				
	VDA-70112-PMT	I									•			
	VDA-832FHD-PMT												•	
	VDA-PMT-AODOME				■ (with NDA-ADTVEZ-DOME)		•	•						
	VDA-PMT-DOME											•		
	VEZ-A2-PW					■ (with NDA-ADTVEZ-DOME)								
POLE MOUNT	LTC 9213/01*			•	•	•	•	•	■ (with PMT/WMT)	■ (with included SMB)		•	•	
CORNER MOUNT	NDA-SMB-CMT	The Cast												•
	VDA-CMT-PTZDOME*								■ (with PMT/WMT)	■ (with included SMB)		■ (with SMB/WMT)	■ (with PMT/WMT)	
	VDA-CMT-DOME											-		
	NDA-FMT-DOME	6			-	-	-	-						
	NDA-FMT-MICDOME								-					
	VDA-PLEN-DOME										-	-		
	VGA-IC-SP										■ (with VDA-PLEN-DOME)	■ (with VDA-PLEN-DOME)		
	NDA-SMB-MICSMB	0		•										
	NDA-SMB-MINISMB	9												
	VDA-455SMB											-		
	VDA-455SMB-IP													
	VDA-70112-SMB										•			
ADAPTERS	NDA-ADT4S-MINDOME*					■ (with NDA-ADTVEZ-DOME)	•	•						
	NDA-ADTVEZ-DOME*					•								
	NDA-WMT4S-MICDOME		•											
	* use together with appropri	ate mount, if requi	red											