

Holder for DoubleButton | button

Support for fixing Button or DoubleButton on surfaces



Always at hand

Holder helps to install the panic button in a place that is quickly accessible in case of an emergency, and makes the use of the remote control even more practical for scenarios. The wireless device will remain portable: the button can be quickly removed from the holder and used as a remote control.

Designed by perfectionists

The design of the bracket does not compromise the ergonomics of the button and provides a secure fit. It could be fixed to a surface with two screws or with double-sided adhesive tape: thanks to the large flat area, even this installation method is reliable. [Button](#) and [DoubleButton](#) They can be attached and removed from the holder in one simple movement. No tools or time-consuming operations are required.

Technical specifications

| | |
|-----------------------------|---|
| Color | Black/white |
| Materials | Plastic |
| Operating temperature range | From -10°C to +40°C |
| Operating humidity | Up to 75% |
| Dimensions | 47.1 × 37.9 × 14.2 mm |
| Weight | 3.5 g |
| Warranty | Repair and replacement up to 24 months after the date of purchase. If the device does not work properly, we recommend that you first contact support, as technical problems can be resolved |
| Full team | Holder for Button/DoubleButton Installation Kit Quick guide |