



1




1x

b




2




3






4



1x

b



1x

c

M3




4x

d



4x

e




5





1x



1x



6




7

A




Internet




**UniFi Gateway
Console**






Switch



B



Internet




UniFi Gateway Console




C



Internet




UniFi Gateway Console




Switch






Switch




UniFi
Access Point



8





If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).

