

User Manual

DG03-A1D24

Date: March 2024

Doc Version: 1.0

English

Thank you for choosing our product. Please read the instructions carefully before operation. Follow these instructions to ensure that the product is functioning properly. The images shown in this manual are for illustrative purposes only.



For further details, please visit our Company's website
www.zkdigimax.com.

Copyright © 2024 ZKDIGIMAX PTE.LTD. All rights reserved.

Without the prior written consent of ZKDIGIMAX, no portion of this manual can be copied or forwarded in any way or form. All parts of this manual belong to ZKDIGIMAX (hereinafter the "Company" or "ZKDIGIMAX").

Trademark

ZKDIGIMAX is a registered trademark of ZKDIGIMAX. Other trademarks involved in this manual are owned by their respective owners.

Disclaimer

This manual contains information on the operation and maintenance of the ZKDIGIMAX equipment. The copyright in all the documents, drawings, etc. in relation to the ZKDIGIMAX supplied equipment vests in and is the property of ZKDIGIMAX. The contents hereof should not be used or shared by the receiver with any third party without express written permission of ZKDIGIMAX.

The contents of this manual must be read as a whole before starting the operation and maintenance of the supplied equipment. If any of the content(s) of the manual seems unclear or incomplete, please contact ZKDIGIMAX before starting the operation and maintenance of the said equipment.

It is an essential pre-requisite for the satisfactory operation and maintenance that the operating and maintenance personnel are fully familiar with the design and that the said personnel have received thorough training in operating and maintaining the machine/unit/equipment. It is further essential for the safe operation of the machine/unit/ equipment that personnel has read, understood and followed the safety instructions contained in the manual.

In case of any conflict between terms and conditions of this manual and the contract specifications, drawings, instruction sheets or any other contract-related documents, the contract conditions/documents shall prevail. The contract specific conditions/ documents shall apply in priority.

ZKDIGIMAX offers no warranty, guarantee or representation regarding the completeness of any information contained in this manual or any of the amendments made thereto. ZKDIGIMAX does not extend the warranty of any kind, including, without limitation, any warranty of design, merchantability or fitness for a particular purpose.

ZKDIGIMAX does not assume responsibility for any errors or omissions in the information or documents which are referenced by or linked to this manual. The entire risk as to the results and performance obtained from using the information is assumed by the user.

ZKDIGIMAX in no event shall be liable to the user or any third party for any incidental, consequential, indirect, special, or exemplary damages, including, without limitation, loss of business, loss of profits, business interruption, loss of business information or any pecuniary loss, arising out of, in connection with, or relating to the use of the information contained in or referenced by this manual, even if ZKDIGIMAX has been advised of the possibility of such damages.

This manual and the information contained therein may include technical, other inaccuracies or typographical errors. ZKDIGIMAX periodically changes the information herein which will be incorporated into new additions/amendments to the manual. ZKDIGIMAX reserves the right to add, delete, amend or modify the information contained in the manual from time to time in the form of circulars, letters, notes, etc. for better operation and safety of the machine/unit/equipment. The said additions or amendments are meant for improvement /better operations of the machine/unit/equipment and such amendments shall not give any right to claim any compensation or damages under any circumstances.

ZKDIGIMAX shall in no way be responsible (i) in case the machine/unit/equipment malfunctions due to any non-compliance of the instructions contained in this manual (ii) in case of operation of the machine/unit/equipment beyond the rate limits (iii) in case of operation of the machine and equipment in conditions different from the prescribed conditions of the manual.

The product will be updated from time to time without prior notice. The latest operation procedures and relevant documents are available on <http://www.zkdigimax.com>

If there is any issue related to the product, please contact us.

About the Company

ZKDIGIMAX is a new digital transformation platform company that comes from a joint venture company between PT Digital Mediatama Maxima Tbk ("DMMX") - an Indonesian public listed company focused on digital cloud advertising, and ZKTeco CO. LTD, a Chinese public listed company focused on biometric verification in security and time management solutions. ZKDIGIMAX strives to provide businesses end-to-end solutions, not only in digital cloud advertising, all biometric, computer vision hardware and SaaS software solutions but also in introducing a unique business model to transform retail, quick-service restaurants, offices, and buildings into a digitalized environment.

Our solution will help business owners focus more on their core business to achieve their growth potential, as all their digital needs are handled by us, not only for hardware and software but also managed service and maintenance solutions. ZKDIGIMAX provides a comprehensive total solution for the retail and quick service restaurant industries, from digital signage to AI business analysis, entrance control, time management, hardware leasing, software hosting, and more.

About the Manual

This manual introduces the operations of the **DG03-A1D24**.

All figures displayed are for illustration purposes only. Figures in this manual may not be exactly consistent with the actual products.


TABLE OF CONTENTS

1 INSTALLATION..... 5


2 OPERATION 6

1 Installation


Step 1: Open the package, take out the whole machine, and place the whole machine on a horizontal table.



Step 2: Connect the accessory power adapter, turn on the power, and power on the whole machine.



Step 3: Connect the relevant interface cables and equipment according to the user's environment.



2 Operation



Tips:

1. For more accurate remote control, use the remote control near the device and aim it at the device's remote control receiving position.
2. **Mouse Mode:** Press the **[Mouse Mode]** button once to show the mouse cursor on the screen. Use the Arrow keys to move the mouse, and press the **[Confirm]** button to execute commands.

Teletech Park #03/32, 20 Science Park Road,
117674, Singapore.
www.zkdigimax.com



Copyright@2024 ZKDIGIMAX PTE.LTD. All rights reserved.