



Quick Guide

CR60W

The CR60 series are accessories designed to read and write proximity cards. They connect to the PC through the USB port (Plug & Play). They allow high speed transactions and incorporate LED indicators. The CR60W reader is compatible with all types of Windows.

What is it for?

Its operation is to read proximity cards. It allows high speed transactions and incorporates LED indicators.

How does it work?

It must be connected to the PC through the USB port (plug & play).

