


# Quick Start Guide


---


Reader PROID10



## Conexión with Access Panel

### Access Control Panel





1- Make the connection with the Stand Alone equipment in the wiegand input as shown in the image.