


# Quick Start Guide


---


Reader PROID



## Conection with Acces Panel

### Access Control Panel





1-Make the connection with the StandAlone equipment at the Wiegand input as shown in the figure.