


Fast guide


KR500 Reader



Access Panel Connection

ACCESS CONTROL PANEL





1- Make the connection with the StandAlone equipment in the Wiegand input as shown in the figure.