



VIVOTEK mounting accessories

AM-414corner mount

Installation guide

Applicable order part numbers:

AM-414: 900046300G




Yo Compatible VIVOTEK cameras

Compatible accessories	Accessoriescompatible
feeding box	AA-351, AA-352, AM-718
surge protector	AP-PSP-050
Outdoor PoE Switch	AW-GEU-083A-240, AW-GET-083A-120, AW-GET-123A-240, AW-GEU-086A-240, AW-GET-086A-120, AW-GET-126A-240
Compatibledirectly	camerasIPcompatible
*	SD9361-EHL, SD9362-EH, SD9362-EHL, SD9363-EHL, SD9364-EH, SD9364-EHL , SD9365-EHL, SD9366-EHL, SD9366-EHL

* Direct connection configuration is less recommended due to lack of waterproof and wiring protection. If directly connected, you should properly wrap the rear cables and connectors with waterproof protection such as putty.


	package contents	
ĺ	Articles	1. Corner mounting bracket, 2. Screws 3. Hex key4.Nutyes
١		







Below is a general sample procedure with a corner mount bracket:


- 1. Combine the two pieces of metal with the M8 hex nuts and washers.
- 2. Align the assembled brackets with the desired position. Align the screw holes on the brackets against the wall. Drill holes in the wall to secure the bracket and to route the cables. Hammer the anchors into the wall. Please note that these screws and wall anchors are user supplied.





3. The 4 screw holes in the center are used to directly mount the camerasspeed dome PT. in the oriScrew holes on the edges are used to mount the box.power supply AA-351, AA-352, AM-718







AM-414corner mount bracket

