

User manual

DAHUA DHI-TF-C100/64GB - Micro SD Memory

1.Introduction

Thank you for purchasing the DAHUA DHI-TF-C100/64GB Micro SD Memory! This product is designed to offer secure and fast storage for a variety of electronic devices. Please read this manual carefully to maximize the use of your new memory card.

2. Product Specifications

- **Ability:**64GB
- **Guy:**Micro SD
- **Interface:**UHS-I
- **Speed class:**C10, U3, V30 **Reading**
- **speed:**Up to 95 MB/s **Writing**
- **speed:**Up to 30 MB/s **Dimensions:**
- 15mm x 11mm x 1mm **Weight:**
- 0.16g
- **Operating temperature:**0°C to 70°C
- **Storage temperature:**-25°C to 85°C

3. Main Features

High performance:Fast read and write speeds for high-resolution video recording and playback.

Durability:Resistant to water, shocks, X-rays and extreme temperatures.

Compatibility:Ideal for security cameras, smartphones, drones, and other devices that require reliable storage.

4. Instructions for Use

Facility

Step 1. Turn off your device before inserting the memory card.

Step 2. Locate the Micro SD card slot on your device.

Step 3. Insert the card with the metal contacts facing down and the label facing up.

Step 4. Turn on the device and follow the instructions to format the card if necessary.

Compatibility

Game consoles, mobile phones, tablets, digital stereo systems, computers and more.

Training

For optimal performance, it is recommended to format the card on the device that will use it for the first time. Consult your device's manual for specific instructions.

5. Maintenance and Care

- Avoid exposing the card to extreme temperatures, humidity, dust, or magnetic fields.
- Do not remove the card during the data transfer process to avoid file corruption.
- Store the card in its protective case when not in use.

6. Common Problem Solving

The card is not recognized by the device

Step 1. Make sure the card is inserted correctly.

Step 2. Check that your device supports cards up to 64 GB. Step 3. Try formatting the card on another device.

Transfer speed is slower than expected

Step 1. Make sure your device supports UHS-I, C10, U3 and V30 speeds. Step 2.

Verify that the device is configured correctly to take advantage of the card's speeds.